

OWNER'S MANUAL

340 DC



Everglades

TABLE OF CONTENTS

TABLE OF CONTENTS	3
SAFETY INFORMATION	7
BOAT INFORMATION	9
SPECIFICATIONS	10
INTRODUCTION & IMPORTANT INFORMATION	11
OWNER / OPERATOR INFORMATION	13

Chapter 1:

SAFETY EQUIPMENT

1.1 General	15
1.2 Engine Alarms	15
1.3 Neutral Safety Switch	15
1.4 Engine Stop Switch	15
1.5 Required Safety Equipment	16
1.6 Bilge & Fuel Fires	17
1.7 Carbon Monoxide Monitoring System	18
1.8 First Aid	19
1.9 Additional Safety Equipment	20
1.10 Caution & Warning Labels	21

Chapter 2:

OPERATION

2.1 General	23
2.2 Rules of the Road	23
2.3 Pre-Cruise Check	26
2.4 Operating Your Boat	27
2.5 Docking, Anchoring & Mooring	28
2.6 Controls, Steering or Propulsion System Failure	30
2.7 Collision	31
2.8 Grounding, Towing & Rendering Assistance	31
2.9 Flooding or Capsizing	31
2.10 Fishing	32
2.11 Man Overboard	32
2.12 Water Skiing & Wakeboarding	32
2.13 Teak Surfing	34
2.14 Trash Disposal	34
2.15 Yacht Certification Plate	34
2.16 Trailering Your Boat	35

Chapter 3:

PROPULSION SYSTEM

3.1 General	37
3.2 Drive System Corrosion	37
3.3 Engine Lubrication	38
3.4 Engine Cooling System	38
3.5 Propellers	38
3.6 Performance Issues & Propellers	38
3.7 Engine Instrumentation	40

TABLE OF CONTENTS

Chapter 4:

HELM CONTROL SYSTEMS

4.1 General	43
4.2 Engine Throttle & Shift Controls	43
4.3 Neutral Safety Switch	44
4.4 Engine Power Tilt & Trim	45
4.5 Engine Stop Switch	45
4.6 Steering System	46
4.7 Joystick Controls	47
4.8 Trim Tabs	48
4.9 Control Systems Maintenance	49

Chapter 5:

FUEL SYSTEM

5.1 General	51
5.2 Outboard Engine Fuel System	52
5.3 Diesel Generator Fuel System	53
5.4 Fueling Instructions	54
5.5 Fuel System Maintenance	55

Chapter 6:

ELECTRICAL SYSTEM

6.1 General	57
6.2 DC System Overview	57
6.3 Engine Starting/House Batteries & Battery Switches	58
6.4 SeaKeeper Batteries & Main Switch (Optional).....	60
6.5 Ignition Switch Panels.....	61
6.6 12 Volt Helm Switch Panel.....	62
6.7 Additional Switches & Switch Panels	64
6.8 DC System Circuit Protection	66
6.9 120 Volt AC Electrical System	70
6.10 Cabin 120 volt AC Circuit Breaker Panel.....	73
6.11 Generator (Optional).....	76
6.12 Bonding System & Galvanic Isolator	78
6.13 Electrical System Maintenance	78
6.14 AC Line Load Estimator	80

Chapter 7:

Fresh Water System

7.1 General	81
7.2 Fresh Water System Operation.....	81
7.3 Water Heater (Optional).....	83
7.4 Fresh Water System Maintenance.....	84

TABLE OF CONTENTS

Chapter 8:

RAW WATER SYSTEM

8.1 General	87
8.2 Raw Water System Operation	88
8.3 Baitwell	88
8.4 Air Conditioning Pump (Optional)	89
8.5 Generator Raw Water Supply	90
8.6 SeaKeeper Cooling Pump	90
8.7 Raw Water System Maintenance.....	90

Chapter 9:

DRAINAGE SYSTEMS

9.1 General	93
9.2 Cockpit & Deck Drainage	93
9.3 Hardtop Drains	94
9.4 Bilge Drainage.....	94
9.5 Cabin Drainage.....	95
9.6 Drainage System Maintenance	96

Chapter 10:

VENTILATION SYSTEM

10.1 Cabin Ventilation	97
10.2 Windshield & Helm Ventilation	97
10.3 Carbon Monoxide & Proper Ventilation	99
10.4 Bilge & System Compartment Ventilation.....	101
10.5 Maintenance	101

Chapter 11:

EXTERIOR EQUIPMENT

11.1 Deck	103
11.2 Rope Locker & Windlass	103
11.3 Hull	107
11.4 Cockpit Features	109
11.5 Cockpit Galley	115
11.6 Cabin Doors & Bow Seating Area	117
11.7 Hardtop	120
11.8 Weather Enclosure.....	121
11.9 Aftermarket Hardtop or Tower	121

Chapter 12:

INTERIOR EQUIPMENT

12.1 Head Compartment & Marine Toilet.....	123
12.2 Port Console Cabin	126
12.3 Forward Air Conditioner.....	127
12.4 Cabin Woodwork	129

TABLE OF CONTENTS

Chapter 13:

ROUTINE MAINTENANCE

13.1 Exterior Hull & Deck	131
13.2 Upholstery, Canvas & Enclosures	134
13.3 Interior	136
13.4 Engines and Fuel	137
13.5 Generator.....	137
13.6 Bilge, Pumps & Components	137
13.7 Drainage System.....	138

Chapter 14:

SEASONAL MAINTENANCE

14.1 Storage & Lay-up	139
14.2 Winterizing.....	141
14.3 Recommissioning	143

Appendix A:

GLOSSARY OF TERMS	145
-------------------------	-----

Appendix B:

MAINTENANCE LOG	149
-----------------------	-----

Appendix C:

BOATING ACCIDENT REPORT	155
-------------------------------	-----

Appendix D:

FLOAT PLAN.....	159
-----------------	-----

Appendix E:

TROUBLESHOOTING GUIDE	161
-----------------------------	-----

SAFETY INFORMATION

Your Everglades owner's manual has been written to include a number of safety instructions to assure the safe operation and maintenance of your boat. These instructions are in the form of **DANGER**, **WARNING** and **CAUTION** statements. The following definitions apply:



All instructions given in this book are as seen from the stern looking toward the bow, with starboard being to your right and port to your left. A glossary of boating terms is included.

IMPORTANT NOTE: Your boat uses an internal combustion engine and flammable fuel. Every precaution has been taken by Everglades to reduce the risks associated with possible injury and damage from fire or explosion, but your own precaution and good maintenance procedures are necessary in order to enjoy safe operation of your boat.

SAFETY INFORMATION

State of California Safety Requirements



WARNING



PROPOSITION 65

OPERATING, SERVICING AND MAINTAINING A RECREATIONAL MARINE VESSEL CAN EXPOSE YOU TO CHEMICALS INCLUDING ENGINE EXHAUST, CARBON MONOXIDE, PHTHALATES, AND LEAD, WHICH ARE KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. TO MINIMIZE EXPOSURE, AVOID BREATHING EXHAUST, SERVICE YOUR VESSEL IN A WELL-VENTILATED AREA AND WEAR GLOVES OR WASH YOUR HANDS FREQUENTLY WHEN SERVICING THIS VESSEL. FOR MORE INFORMATION GO TO WWW.P65WARNING.CA.GOV/MARINE.

California Health & Safety Code §§ 25249.5-.13

State of California Emission Requirements

Your boat may be equipped with an engine that meets the special requirements outlined by the California Air Resources Board (CARB). If so, the engine is designed to meet strict requirements and the boat will have a special tag and one of the following labels affixed to it.

The tag and the label are required by CARB. The label has 1, 2, 3 or 4 stars and must be affixed to your boat if it is to be operated in the state of California and/or bordering waters. For more information visit: <http://www.arb.ca.gov>.



BOAT INFORMATION

Please fill out the following information section and leave it in your Everglades owner's manual. This information will be important for you, your dealer and/or Everglades service personnel to know, if you may need to call them for technical assistance or service.

BOAT	
MODEL:	HULL ID #:
PURCHASE DATE:	DELIVERY DATE:
IGNITION KEYS #:	REGISTRATION #:
DOOR KEYS #:	OTHER KEYS #:
ENGINES	
MAKE:	MODEL:
PORT SERIAL #:	STARBOARD SERIAL #:
GENERATOR	
MAKE:	MODEL:
SERIAL #:	KILOWATTS:
PROPELLERS	
MAKE:	BLADES:
RH DIAMETER/PITCH:	LH DIAMETER/PITCH:
AIR CONDITIONERS	
MAKE:	MODEL:
SERIAL #:	BTU OUTPUT:
SERIAL #:	BTU OUTPUT:
ADDITIONAL EQUIPMENT	
DEALER	EVERGLADES
NAME:	REPRESENTATIVE:
DEALER/PHONE:	EVERGLADES PHONE:
SALESMAN:	ADDRESS:
SERVICE MANAGER:	
ADDRESS:	
DEALER E- MAIL:	EVERGLADES E- MAIL:

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. Everglades Boats reserves the right to make changes at anytime, without notice, in colors, materials, equipment, specifications and models.

SPECIFICATIONS

340 DC Specifications

LENGTH OVERALL W/O ENGINE	33' 6"
LENGTH OVERALL W/ ENGINE	36" 1"
BEAM	11' 1"
WEIGHT DRY - NO ENGINES (Approx)	13,000 lbs
DEADRISE AVERAGE	30°
DEADRISE AT TRANSOM	20°
DRAFT - HULL ONLY	21.5"
DRAFT WITH ENGINES DOWN	35.25"
TRANSOM HEIGHT	30" / 30"
BRIDGE CLEARANCE W/HARDTOP	8' 11"
FUEL CAPACITY GASOLINE	300 gal
FUEL CAPACITY DIESEL	20 gal
WATER TANK CAPACITY	38 gal
WASTE TANK CAPACITY	15 gal
WATER HEATER	6 gal
FISHBOX CAPACITY	71 gal
LIVEWELL CAPACITY	24 gal
COCKPIT AREA	96 sq ft
MAXIMUM HORSEPOWER	850 hp

Notice:

Dry weight is the average weight of the base boat without engines, fuel, water, waste or gear.

Specifications and weights are approximate and may differ from boat to boat.

INTRODUCTION & IMPORTANT INFORMATION

All instructions given in this book are as seen from the stern looking toward the bow with starboard being to your right and port to your left. The information and precautions listed in this manual are not all inclusive. It may be general in nature in some cases and detailed in others and is designed to provide you with a basic understanding of your Everglades boat and some of the responsibilities that go along with owning/operating your boat.

The suppliers of some of the major components such as the engines, pumps and appliances, provide their own owner's manuals which have been included with your boat. You should read the information in this manual and the manuals of other suppliers completely and have a thorough understanding of all component systems and their proper operation before operating your boat.

REMEMBER - IT IS YOUR RESPONSIBILITY TO ENSURE THAT YOUR BOAT IS SAFE FOR YOU AND YOUR PASSENGERS. ALWAYS EXERCISE GOOD COMMON SENSE WHEN INSTALLING EQUIPMENT AND OPERATING THE BOAT.

Warranty and Warranty Registration Cards

The Everglades Limited Warranty Statement is included with your boat. It has been written to be clearly stated and easily understood. If you have any questions after reading the warranty, please contact the Everglades Boats Customer Service Department.

Everglades, engine manufacturers and the suppliers of major components maintain their own manufacturer's warranty and service facilities. It is important that you properly complete the warranty registration cards included with your boat and engine and mail them back to the manufacturer to register your ownership. This should be done within 15 days of the date of purchase and before the boat is put into service. A form for recording this information for your records is provided at the beginning of this manual. This information will be important for you and service personnel to know, if and when you may need service or technical information.

The boat warranty registration requires the Hull Identification Number "HIN" which is located on the starboard side of the transom, just below the rubrail. The engine warranty registration requires the engine serial numbers. Please refer to the engine owner's manual for the location of the serial numbers.



Hull ID # On Starboard Side of Transom

IMPORTANT:

The terms and conditions of the Everglades Boats Limited Warranty are outlined in the warranty statement included in this manual. The manufacturer will automatically honor the warranty to the original purchaser for 15 days from the date of purchase. However, during that 15 day period, owners must comply with the steps outlined in the warranty statement to validate their warranty.

All boat manufacturers are required by the Federal Boat Safety Act of 1971 to notify first time owners in the event any defect is discovered "which creates a substantial risk of personal injury to the public." It is essential that we have your warranty registration card complete with your name and mailing address in our files so that we can comply with the law if it should become necessary.

Your Everglades Boats Dealer will assist you in filling in the hull number and other data required on your Registration Card. Check to see that your card is complete and signed. Detach and mail. Your Warranty Registration Card will be added to our permanent files.

Transferring the Limited Structural Warranty

For a transfer fee, Everglades Boats will offer to extend a Transferable Limited Structural Hull Warranty to subsequent owners of Everglades Boats. Please refer to the Everglades Limited Warranty Statement for the terms and conditions of the Transferable Limited Structural Hull Warranty and the procedure to transfer the warranty.

Product Changes

Everglades is committed to the continuous improvement of our boats. As a result, some of the equipment described in this manual or pictured in the catalog may change or no longer be available. All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. Everglades Boats reserves the right to make changes at anytime, without notice, in colors, materials, equipment, specifications and models. If you have questions about the equipment on your Everglades, please contact the Everglades Boats Customer Service Department.

Service

All warranty repairs must be performed by an authorized Everglades Dealer. Should a problem develop that is related to faulty workmanship or materials, as stated in the Limited Warranty, you should contact your Everglades dealer to arrange for the necessary repair. If you are not near your dealer or another authorized Everglades dealer or the dealer fails to remedy the cause of the problem, then contact Everglades within 15 days.

Everglades will not reimburse boat owners for warranty repairs performed without prior authorization provided in writing.

It is the boat owner's responsibility to deliver the boat to the dealer for warranty service.

Registration and Numbering

Federal law requires that all undocumented vessels equipped with propulsion machinery be registered in the state of principal use. A certificate of number will be issued upon registering the boat. These numbers must be displayed on your boat. The owner/operator of a boat must carry a valid certificate of number whenever the boat is in use. When moved to a new state of principal use, the certificate is valid for 60 days.

In order to be valid, the numbers must be installed to the proper specifications. Check with your dealer or state boating authority for numbering requirements. The Coast Guard issues the certificate of number in Alaska; all others are issued by the state.

Insurance

In most states the boat owner is legally responsible for damages or injuries he or someone else operating the boat causes. Responsible boaters carry adequate liability and property damage insurance for their boat. You should also protect the boat against physical damage and theft. Some states have laws requiring minimum insurance coverage. Contact your dealer or state boating authority for information on the insurance requirements in your boating area.

Reporting Boating accidents

All boating accidents must be reported by the operator or owner of the boat to the proper marine law enforcement authority for the state in which the accident occurred. Immediate notification is required if a person dies or disappears as a result of a recreational boating accident.

If a person dies or there are injuries requiring more than first aid, a formal report must be filed within 48 hours.

A formal report must be made within 10 days for accidents involving more than \$500.00 damage or the complete loss of a boat.

A Boating Accident Report form is located near the back of this manual to assist you in reporting an accident. If you need additional information

regarding accident reporting, please visit the U.S. Coast Guard Boating Safety web site, www.uscgboating.org,

Education

If you are not an experienced boater, we recommend that the boat operator and other people that normally accompany the operator, enroll in a boating safety course. Organizations such as the U.S. Power Squadrons, United States Coast Guard Auxiliary, State Boating Authorities and the American Red Cross offer excellent boating educational programs. These courses are worthwhile even for experienced boaters to sharpen your skills or bring you up to date on current rules and regulations. They can also help in providing local navigational information when moving to a new boating area. Contact your dealer, State Boating Authority or visit the U.S. Coast Guard Boating Safety web site, www.uscgboating.org, for information on boat safety courses.

Required Equipment

U.S. Coast Guard regulations require certain equipment on each boat. The Coast Guard also sets minimum safety standards for vessels and associated equipment. To meet these standards some of the equipment must be Coast Guard approved. "Coast Guard Approved Equipment" has been determined to be in compliance with USCG specifications and regulations relating to performance, construction or materials. The equipment requirements vary according to the length, type of boat and the propulsion system. Some of the Coast Guard equipment is described in the Safety Equipment chapter of this manual. For a more detailed description, obtain "Federal Requirements And Safety Tips For Recreational Boats" by visiting the U.S. Coast Guard Boating Safety web site, www.uscgboating.org.

Some state and local agencies impose similar equipment requirements on waters that do not fall under Coast Guard jurisdiction. These agencies may also require additional equipment that is not required by the Coast Guard. Your dealer or local boating authority can provide you with additional information for the equipment requirements for your boating area.

NOTES

SAFETY EQUIPMENT

1.1 General

Your boat and outboard engines have been equipped with safety equipment designed to enhance the safe operation of the boat and to meet U.S. Coast Guard safety standards. The Coast Guard or state, county and municipal law enforcement agencies require certain additional accessory safety equipment on each boat. This equipment varies according to length and type of boat and type of propulsion. The accessory equipment typically required by the Coast Guard is described in this chapter. Some local laws require additional equipment. It is important to obtain "Federal Requirements And Safety Tips for Recreational Boats," published by the Coast Guard and copies of state and local laws, to make sure you have the required equipment for your boating area.

Your boat is equipped with engine alarms. The alarm systems are designed to increase your boating safety by alerting you to potentially serious problems in the primary power system. Alarm systems are not intended to lessen or replace good maintenance and pre-cruise procedures.


This chapter also describes safety related equipment that could be installed on your boat. This equipment will vary depending on the type of engines and other options installed by you or your dealer.

1.2 Engine Alarms

Most outboard engines are equipped with an audible alarm system mounted in the helm area that monitors selected critical engine systems. The alarm will sound if one of these systems begins to fail. Refer to the engine owner's manual for information on the alarms installed with your engines.

If the alarm sounds:

- Immediately throttle the engines back to idle.
- Shift the transmissions to neutral.
- Monitor the engine gauges to determine the cause of the problem.
- If necessary, shut off the engine and investigate until the cause of the problem is found.



Throwable Device & Personal PFD

1.3 Neutral Safety Switch

Every control system has a neutral safety switch incorporated into it. This device prohibits the engines from being started while the shift levers are in any position other than the neutral position. If an engine will not start, slight movement of the shift lever may be necessary to locate the neutral position and disengage the safety cutout switch. Control adjustments may be required to correct this condition should it persist. See your Everglades dealer for necessary control adjustments. Please refer to the Helm Control Systems chapter for more information on the neutral safety switch.

1.4 Engine Stop Switch

Your boat is equipped with an engine stop switch and lanyard. When the lanyard is pulled it will engage the switch and shut off the engines. We strongly recommend that the lanyard be attached to the driver and the stop switch whenever the engines are running. If the engines will not start, it could be because the lanyard is not properly inserted into the engine stop switch. Always make sure the lanyard is properly attached to the engine stop switch before attempting to start the engine.

Notice:

In some states, a lanyard attached to the driver at all times is required by law.

Notice:

You should carry an extra stop switch lanyard and instruct at least one other crew member on the operation of the stop switch and location of the extra lanyard.

1.5 Required Safety Equipment

Besides the equipment installed on your boat by Everglades, certain other equipment is required by the U.S. Coast Guard to help ensure passenger safety. Items like a sea anchor, working anchor, extra dock lines, flare pistol, life vests, a line permanently secured to your ring buoy, etc., could at some time save your passengers' lives or save your boat from damage. Refer to the "Federal Requirements And Safety Tips For Recreational Boats" pamphlet for a more detailed description of required equipment. You also can visit the U.S. Coast Guard Boating Safety web site, www.uscgboating.org, for information on boat safety courses and brochures listing the Federal equipment requirements. Also, check your local and state regulations.

The Coast Guard Auxiliary offers a "Courtesy Examination." This inspection will help ensure that your boat is equipped with all of the necessary safety equipment. The following is a list of the accessory equipment required on your boat by the U.S. Coast Guard:

Personal Flotation Devices (PFDs)

PFDs must be Coast Guard approved, in good and serviceable condition and of appropriate size for the intended user. Wearable PFDs must be readily accessible, meaning you must be able to put them on in a reasonable amount of time in an emergency. Though not required, the Coast Guard emphasizes that PFDs should be worn at all times when the vessel is underway. Throwable devices must be immediately available for use. All Everglades boats must be equipped with at least one Type I, II or III PFD for each person on board, plus one throwable device (Type IV).

Notice:

Many state laws now require that children 13 years old and under must wear a PFD at all times.

Anyone being towed on skis, wakeboards and other water sports equipment is considered a passenger on the boat and must wear a Coast Guard approved life jacket at all times.



Visual Distress Signals

All boats used on coastal waters, the Great Lakes, territorial seas and those waters connected directly to them, must be equipped with Coast Guard approved visual distress signals. These signals are either Pyrotechnic or Non-Pyrotechnic devices.

Pyrotechnic Visual Distress Signals:

Pyrotechnic visual distress signals must be Coast Guard approved, in serviceable condition and readily accessible. They are marked with a date showing the service life, which must not have expired. A minimum of three are required. Some pyrotechnic signals meet both day and night use requirements. They should be stored in a cool, dry location. They include:

- Pyrotechnic red flares, hand held or aerial.
- Pyrotechnic orange smoke, hand-held or floating.
- Launchers for aerial red meteors or parachute flares.

	WARNING	
<p>PYROTECHNICS ARE UNIVERSALLY RECOGNIZED AS EXCELLENT DISTRESS SIGNALS. HOWEVER, THERE IS POTENTIAL FOR INJURY AND PROPERTY DAMAGE IF NOT PROPERLY HANDLED. THESE DEVICES PRODUCE A VERY HOT FLAME AND THE RESIDUE CAN CAUSE BURNS AND IGNITE FLAMMABLE MATERIAL. PISTOL LAUNCHED AND HAND-HELD PARACHUTE FLARES AND METEORS HAVE MANY CHARACTERISTICS OF A FIREARM AND MUST BE HANDLED WITH CAUTION. IN SOME STATES THEY ARE CONSIDERED A FIREARM AND PROHIBITED FROM USE. ALWAYS BE EXTREMELY CAREFUL AND FOLLOW THE MANUFACTURER'S INSTRUCTIONS EXACTLY WHEN USING PYROTECHNIC DISTRESS SIGNALS.</p>		

Non-Pyrotechnic Devices

Non-Pyrotechnic visual distress signals must be in serviceable condition, readily accessible and certified by the manufacturer as complying with U.S. Coast Guard requirements. They include:

- Orange Distress Flag (Day use only)
The distress flag is a day signal only. It must be at least 3 x 3 feet with a black square and ball on an orange background. It is most distinctive when attached and waved from a paddle or boat hook.

- Electric Distress Light (Night use only)

The electric distress light is accepted for night use only and must automatically flash the international SOS distress signal. Under "Inland Navigation Rules," a high intensity white light flashing at regular intervals from 50-70 times per minute is considered a distress signal.

Sound Signaling Devices

The navigation rules require sound signals to be made under certain circumstances. Recreational vessels also are required to sound fog signals during periods of reduced visibility. Therefore, you must have some means of making an efficient sound signal.

Navigation Lights

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.) Navigation lights are intended to keep other vessels informed of your presence and course. Your boat is equipped with navigation lights required by the U.S. Coast Guard at the time of manufacture. It is up to you to make sure they are operational and turned on when required.

Fire Extinguishers

Your boat is required to have three Marine Type USCG approved fire extinguishers. Coast Guard approved fire extinguishers are hand-portable, either B-I or B-II classification and have a specific marine type mounting bracket. It is recommended that the extinguishers be mounted in a readily accessible position.





Fire extinguishers require regular inspections to ensure that:

- Seals & tamper indicators are not broken or missing.
- Pressure gauges or indicators read in the operable range.
- There is no obvious physical damage, corrosion, leakage or clogged nozzles.



Refer to the "Federal Requirements And Safety Tips For Recreational Boats" pamphlet or visit the U.S. Coast Guard Boating Safety web site, www.uscgboating.org, for information on the type and size fire extinguisher required for your boat.

Please refer to the information provided by the fire extinguisher manufacturer for instructions on the proper maintenance and use of your fire extinguisher.

	CAUTION	
<p>INFORMATION FOR HALON, AGENT FE-241 AND AGENT FM 200 FIRE EXTINGUISHERS IS PROVIDED BY THE MANUFACTURER. IT IS ESSENTIAL THAT YOU READ THE INFORMATION CAREFULLY AND COMPLETELY UNDERSTAND THE SYSTEM, IN THEORY AND OPERATION, BEFORE USING YOUR BOAT.</p>		

1.6 Bilge & Fuel Fires

Fuel compartment and bilge fires are very dangerous because of the presence of gasoline in the various components of the fuel system and the possibility for explosion. You must make the decision to fight the fire or abandon the boat. If the fire cannot be extinguished quickly or it is too intense to fight, abandoning the boat may be your only option. If you find yourself in this situation, make sure all passengers have a life preserver on and go over the side and swim well upwind of the boat. This will keep you and your passengers well clear of any burning fuel that could be released and spread on the water as the boat burns or in the event of an explosion. When clear of the danger, check about and account for all those who were aboard with you. Give whatever assistance you can to anyone in need or in the water without a buoyant device. Keep everyone together in a group for morale and to aid rescue operations.

	WARNING	
<p>GASOLINE CAN EXPLODE. IN THE EVENT OF A FUEL COMPARTMENT OR BILGE FIRE, YOU MUST MAKE THE DIFFICULT DECISION TO FIGHT THE FIRE OR ABANDON THE BOAT. YOU MUST CONSIDER YOUR SAFETY, THE SAFETY OF YOUR PASSENGERS, THE INTENSITY OF THE FIRE AND THE POSSIBILITY OF AN EXPLOSION IN YOUR DECISION.</p>		

Safety Equipment

1.7 Carbon Monoxide Monitoring System

⚠ DANGER ⚠

CARBON MONOXIDE IS COLORLESS, ODORLESS AND DANGEROUS. ALL ENGINES, GENERATORS AND FUEL BURNING APPLIANCES EXHAUST CARBON MONOXIDE (CO). DIRECT AND PROLONGED EXPOSURE TO CO WILL CAUSE BRAIN DAMAGE OR DEATH. SIGNS OF EXPOSURE TO CO INCLUDE NAUSEA, DIZZINESS AND DROWSINESS.

The carbon monoxide (CO) detector is installed in the cabin as standard equipment and warns the occupants of dangerous accumulations of carbon monoxide gas. If excess carbon monoxide fumes are detected, the detector will sound an alarm indicating the presence of the toxic gas.

Should a very high level of carbon monoxide exist, the alarm will sound in a few minutes. However, if small quantities of CO are present or high levels are short-lived, the alarm will accumulate the information and determine when an alarm level has been reached.

The carbon monoxide detector is automatically activated whenever the House battery is connected. The power light on the carbon monoxide detector should be lit to indicate that the carbon monoxide detector is activated.

Always make sure the power light on the carbon monoxide detector is lit whenever the cabin is occupied.

A by-product of combustion, carbon monoxide (CO) is invisible, tasteless, odorless and is produced by all engines, heating and cooking appliances. The most common sources of CO on boats are the engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping.

A slight buildup of carbon monoxide over several hours causes headache, nausea and other symptoms that are similar to food poisoning, motion sickness or flu. High concentrations can be fatal within minutes. Many cases of carbon monoxide poisoning indicate that while victims are aware they are not well, they become so disoriented they are unable to save themselves by either exiting the area or calling for help. Also, young children, elderly persons and pets may be the first affected.



Typical Carbon Monoxide Detector

Drug or alcohol use increases the effect of CO exposure. Individuals with cardiac or respiratory conditions are very susceptible to the dangers of carbon monoxide. CO poisoning is especially dangerous during sleep when victims are unaware of any side effects. The following are symptoms which may signal exposure to CO: (1) Headache (2) Tightness of chest or hyperventilation (3) Flushed face (4) Nausea (5) Drowsiness (6) Fatigue or Weakness (7) Inattention or confusion (8) Lack of normal coordination.

Persons who have been exposed to carbon monoxide should be moved into fresh air immediately. Have the victim breathe deeply and seek immediate medical attention. To learn more about CO poisoning, contact your local health authorities.

Low levels of carbon monoxide over an extended period of time can be just as lethal as high doses over a short period. Therefore, low levels of carbon monoxide can cause the alarm to sound before the occupants of the boat notice any symptoms of carbon monoxide poisoning. CO detectors are very reliable and rarely sound false alarms. If the alarm sounds, always assume the hazard is real and move persons who have been exposed to carbon monoxide into fresh air immediately.



Typical First Aid Kit

Never disable the CO detector because you think the alarm may be false. Always contact the detector manufacturer or your local fire department for assistance in finding and correcting the situation.

Remember, carbon monoxide detectors do not guarantee that CO poisoning will not occur. Do not use the CO detector as a replacement for ordinary precautions or periodic inspections of equipment. Never rely on alarm systems to save your life, common sense is still prudent and necessary.

You should read the owner's manual supplied by the CO detector manufacturer and included with this manual for operation instructions and additional information regarding the hazards of carbon monoxide gas. Refer to the Ventilation System chapter for information on ventilating your boat properly while underway and other precautions while at anchor or in a slip. This is especially essential if your boat is equipped with the optional generator.

Many manufacturers of carbon monoxide detectors offer a testing and recertification program. We recommend that you contact the manufacturer of your carbon monoxide detector and have it tested and recertified periodically.

1.8 First Aid

It is the operator's responsibility to be familiar with the proper first-aid procedures and be able to care for minor injuries or illnesses of your passengers. In an emergency, you could be far from professional medical assistance. We strongly recommend that you be prepared by receiving training in basic first aid and CPR. This can be done through classes given by the Red Cross or your local hospital.

Your boat should also be equipped with at least a simple marine first-aid kit and a first-aid manual. The marine first-aid kit should be designed for the marine environment and be well supplied. It should be accessible and each person on board should be aware of its location. As supplies are used, replace them promptly. Some common drugs and antiseptics may lose their strength or become unstable as they age. Ask a medical professional about the supplies you should carry and the safe shelf life of prescription drugs or other medical supplies that may be in your first-aid kit. Replace questionably old supplies whether they have been used or not.

In many emergency situations, the Coast Guard can provide assistance in obtaining medical advice

Safety Equipment

for treatment of serious injuries or illness. If you are within VHF range of a Coast Guard Station, make the initial contact on channel 16 and follow their instructions.

1.9 Additional Safety Equipment

Besides meeting the legal requirements, prudent boaters carry additional safety equipment. This is particularly important if you operate your boat offshore. You should consider the following items, depending on how you use your boat.

Satellite EPIRBs

EPIRBs (Emergency Position Indicating Radio Beacon) operate as part of a worldwide distress system. When activated, EPIRBs will send distress code homing beacons that allow Coast Guard aircraft to identify and find them quickly. The satellites that receive and relay EPIRB signals are operated by the National Oceanic and Atmospheric Administration (NOAA) in the United States. The EPIRB should be mounted and registered according to the instructions provided with the beacon, so that the beacon's unique distress code can be used to quickly identify the boat and owner.

Marine Radio

A marine radio is the most effective method of receiving information and requesting assistance. VHF marine radios are used near shore and single sideband radios are used for long range communication.

There are specific frequencies to use in an emergency. The VHF emergency channel is 16 in the United States. You should read the owners manual for your radio and know how to use it in an emergency or for normal operation. If you hear a distress call you should assist or monitor the situation until help is provided.


Additional Equipment to Consider:

Cell Phone	Spare Anchor
Fenders	Heaving Line
Mirror	First Aid Kit
Tool Kit	Flashlight & Batteries
Anchor	Search light
Boat Hook	Sunburn Lotion
Mooring Lines	Ring Buoy or Boat Cushion
Binoculars	Whistle or Horn
Extra Clothing	Portable Radio
Chart and Compass	Marine Hardware
Food & Water	Spare Keys
Sunglasses	Spare Parts
Spare Propellers	Spare Propeller Hub Kits

1.10 Caution & Warning Labels

The caution and warning labels shown are examples of the labels that could be on your boat. The actual labels and their location could vary on your boat.

Caution and warning labels must remain legible for the safety of you and your passengers. If a label becomes missing or damaged it must be replaced. Immediately contact your dealer or Everglades Customer Service for a replacement.



NOTES

OPERATION

2.1 General

Before you start the engines on your Everglades, you should have become familiar with the various component systems and their operation and have performed a "Pre-Cruise System Check." A thorough understanding of the component systems and their operation is essential to the proper operation of the boat. This manual and the associated manufacturers' information is provided to enhance your knowledge of your boat. Please read them carefully.

Your boat must have the necessary safety equipment on board and be in compliance with the U.S. Coast Guard, local and state safety regulations. There should be one Personal Flotation Device (PFD) for each person. Non-swimmers and small children should wear PFDs at all times. You should know and understand the "Rules of the Road" and have had an experienced operator brief you on the general operation of your new boat. At least one other person should be instructed on the proper operation of the boat in case the operator is suddenly incapacitated.

The operator is responsible for his safety and the safety of his passengers. When boarding or loading the boat, always step onto the boat, never jump. All passengers should be properly seated whenever the boat is operated above idle speed. Your passengers should not be allowed to sit on the seat backs, gunnels, bows or transoms whenever the boat is underway. The passengers should also be seated to properly balance the load and must not obstruct the operator's view, particularly to the front.

Overloading and improper distribution of weight can cause the boat to become unstable and are significant causes of accidents. Know the weight capacity and horsepower rating of your boat. Do not overload or overpower your boat.

You should be aware of your limitations and the limitations of your boat in different situations or sea conditions. No boat is indestructible, no matter how well it is constructed. Any boat can be severely damaged if it is operated in a manner that exceeds its design limitations. If the ride is hard on you and your passengers, it is hard on

the boat as well. Always modify the boat speed in accordance with the sea conditions, boat traffic and weather conditions.

Remember, it is the operator's responsibility to use good common sense and sound judgement in loading and operating the boat.

2.2 Rules of the Road

As in driving an automobile, there are a few rules you must know for safe boating operation. The following information describes the basic navigation rules and action to be taken by vessels in crossing, meeting or overtaking situations while operating in inland waters. These are basic examples and not intended to teach all the rules of navigation. For further information consult the "Navigation Rules" or contact the Coast Guard, Coast Guard Auxiliary, Department of Natural Resources or your local boat club. These organizations sponsor courses in boat handling, including rules of the road. We strongly recommend such courses. Books or videos on this subject also are available from your local library.

Notice:

Sailboats not under power, paddle boats, vessels unable to maneuver, vessels engaged in commercial fishing and other vessels without power have the right-of-way over motor powered boats. You must stay clear or pass to the stern of these vessels. Sailboats under power are considered motor boats.

Crossing Situations

When two motor boats are crossing, the boat on the right has the right-of-way. The boat with the right-of-way should maintain its course and speed. The other vessel should slow down and permit it to pass. The boats should sound the appropriate signals.

Meeting Head-On or Nearly-So Situations

When two motor boats are approaching each other head-on or nearly head-on, neither boat has the right-of-way. Both boats should reduce their speed and turn to the right so as to pass port side to port side, providing enough clearance for safe passage. The boats should sound the appropriate signals.

Overtaking Situations

When one motor boat is overtaking another motor boat, the boat that is being passed has the right-of-way. The overtaking boat must make the adjustments necessary to provide clearance for a safe passage of the other vessel. The boats should sound the appropriate signals.

The General Prudential Rule

In obeying the Rules of the Road, due regard must be given to all dangers of navigation and collision and to any special circumstances, including the limitations of the vessels, which may justify a departure from the rules that is necessary to avoid immediate danger or a collision.

Night Operation

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility such as fog, rain, haze, etc. When operating your boat at night you should:


- Make sure your navigation lights are on and working properly. Navigation lights warn others of your position and course and the position and course of other vessels.
- All navigation rules apply. If the bow light of another vessel shows red, you should give way to that vessel, if it shows green, you have the right-of-way.
- Slow down and never operate at high speeds when operating at night, stay clear of all boats and use good common sense. Always be ready to slow down or steer clear of other vessels, even if you have the right-of-way.
- Avoid bright lights that can destroy night vision, making it difficult to see navigation lights and the lights of other boats. You and your passengers should keep a sharp lookout for hazards, other boats and navigational aids.

Navigation Aids

Aids to navigation are placed along coasts and navigable waters as guides to mark safe water and to assist mariners in determining their position in relation to land and hidden dangers. Each aid to navigation is used to provide specific information. You should be familiar with these and any other markers used in your boating area.

Notice:

Storms and wave action can cause buoys to move. You should not rely on buoys alone to determine your position.



Navigational Aids Chart

REMEMBER THESE RULES

1. OVERTAKING - PASSING: Boat being passed has the right-of-way. KEEP CLEAR.
2. MEETING HEAD ON: Keep to the right.
3. CROSSING: Boat on right has the right-of-way. Slow down and permit boat to pass.

<p>← PORT</p> <p>Yield right-of-way to boats in your DANGER ZONE!</p> <p>STARBOARD →</p> <p>DANGER ZONE (Dead ahead to 2 points abaft your starboard beam)</p>	<p>STORM WARNINGS</p> <p>RED FLAG Small craft (winds to 33 knots)</p> <p>2 RED FLAGS Gale (winds up to 47 knots)</p> <p>SQUARE RED FLAG BLACK BOX (Storm)</p> <p>2 SQUARE RED FLAGS BLACK BOX (Hurricane)</p>																					
<p>WHISTLE SIGNALS</p> <p>ONE LONG BLAST: Warning signal (Coming out of slip)</p> <p>ONE SHORT BLAST: Pass on my port side</p> <p>TWO SHORT BLASTS: Pass on my starboard side</p> <p>THREE SHORT BLASTS: Engine(s) in reverse</p> <p>FOUR OR MORE BLASTS: Danger signal</p>	<p>BRIDGE SIGNALS</p> <table border="0"> <tr> <td></td> <td>DAY (Flag)</td> <td>NIGHT (Lights)</td> </tr> <tr> <td>SOUND</td> <td></td> <td></td> </tr> <tr> <td>VESSEL: Open</td> <td>— ●</td> <td>↑ □</td> </tr> <tr> <td>BRIDGE: OK</td> <td>— ●</td> <td>↓ □</td> </tr> <tr> <td>No</td> <td>● ● ● ● ● ●</td> <td>or</td> </tr> <tr> <td>VESSEL: Replies:</td> <td>● ● ● ● ● ●</td> <td>Same</td> </tr> <tr> <td>RADIO: VHF CH. 13</td> <td>No</td> <td>Same</td> </tr> </table>		DAY (Flag)	NIGHT (Lights)	SOUND			VESSEL: Open	— ●	↑ □	BRIDGE: OK	— ●	↓ □	No	● ● ● ● ● ●	or	VESSEL: Replies:	● ● ● ● ● ●	Same	RADIO: VHF CH. 13	No	Same
	DAY (Flag)	NIGHT (Lights)																				
SOUND																						
VESSEL: Open	— ●	↑ □																				
BRIDGE: OK	— ●	↓ □																				
No	● ● ● ● ● ●	or																				
VESSEL: Replies:	● ● ● ● ● ●	Same																				
RADIO: VHF CH. 13	No	Same																				

LATERAL AIDS AS SEEN ENTERING FROM SEAWARD

<p>PORT SIDE ODD NUMBERED AIDS</p> <p>GREEN LIGHT ONLY</p> <p>FLASHING: [diagram]</p> <p>OCCULTING: [diagram]</p> <p>QUICK FLASHING: [diagram]</p> <p>ISOPHASE: [diagram]</p> <p>LIGHTED BUOY: G "9" Fl G 4sec</p> <p>CAN: G "7"</p> <p>DAYMARK: SG 1 G "1"</p>	<p>SAFE WATER MID-CHANNELS OR FAIRWAYS NO NUMBERS — MAY BE LETTERED</p> <p>WHITE LIGHT ONLY MORSE CODE</p> <p>Mo (A) [diagram]</p> <p>SPHERICAL: RW SP "G"</p> <p>MR: RW "A"</p> <p>LIGHTED AND OR SOUND: RW "N" Mo (A)</p> <p>PREFERRED CHANNEL NO NUMBERS — MAY BE LETTERED</p> <p>COMPOSITE GROUP FLASHING (2 + 1)</p> <p>GREEN LIGHT ONLY</p> <p>RED LIGHT ONLY</p> <p>LIGHTED</p> <p>PREFERRED CHANNEL TO STARBOARD TOPMOST BAND GREEN: GR "C" Fl (2 + 1)</p> <p>PREFERRED CHANNEL TO PORT TOPMOST BAND RED: RG "B" Fl (2 + 1)</p> <p>CAN: GR "C" L</p> <p>NUN: RG "N" W</p> <p>DAYMARK: JG A GR "A"</p> <p>JR B RG "B"</p>	<p>STARBOARD SIDE EVEN NUMBERED AIDS</p> <p>RED LIGHT ONLY</p> <p>FLASHING: [diagram]</p> <p>OCCULTING: [diagram]</p> <p>QUICK FLASHING: [diagram]</p> <p>ISOPHASE: [diagram]</p> <p>LIGHTED BUOY: R "8" Fl R 4sec</p> <p>NUN: R "6"</p> <p>DAYMARK: TR 2 R "2"</p>
--	--	--

2.3 Pre-Cruise Check

Before Starting the Engines:

- Check the weather forecast and sea conditions before leaving the dock. Decide if the planned cruise can be made safely.
- Be sure all required documents are on board.
- Be sure all necessary safety equipment is on board and operative. This should include items like the running lights, spotlight, life saving devices, etc. Refer to the Safety Equipment chapter for additional information on safety equipment.
- Make sure you have signal kits and flare guns aboard. They must be current and in good operating condition.
- Be sure you have sufficient water and other provisions for the planned cruise.
- Leave a written message listing details of your planned cruise with a close friend ashore (Float Plan). The float plan should include a description of your boat, where you intend to cruise and a schedule of when you expect to arrive in the cruising area and when you expect to return. Keep the person informed of any changes in your plan to prevent false alarms. This information will tell authorities where to look and the type of boat to look for in the event you fail to arrive.
- Check the amount of fuel on board. Observe the "Rule of Thirds": one third of the fuel for the trip out, one third to return and one third in reserve. An additional 15% may be consumed in rough seas.
- Check the water separating fuel filters for leaks or corrosion.
- Check the crankcase oil level in each engine.
- Turn the battery switches on.
- Check the bilge water level. Look for other signs of potential problems. Monitor for the scent of fuel fumes.
- Test the automatic and manual bilge pump switches to make sure the systems are working properly. This is particularly important before running offshore.

- Have a tool kit aboard. The kit should include the following basic tools:

Hammer	Electrician's tape
Screwdrivers	Offset screwdrivers
Lubricating oil	Pliers
Jackknife	Adjustable wrench
Basic 3/8" ratchet set	Vise grip pliers
Hex key set	Needle nose pliers
Wire crimping tool	Wire connector Set
End wrench set	Medium slip-joint pliers
Diagonal cutting pliers	DC electrical test light



WARNING



THERE MUST BE AT LEAST ONE PERSONAL FLOTATION DEVICE ON BOARD FOR EVERY PERSON ON BOARD AND ONE THROW-OUT FLOTATION DEVICE. CHECK THE U.S. COAST GUARD STANDARDS FOR THE CORRECT TYPE OF DEVICE FOR YOUR BOAT.

- Have the following spare parts on board:

Extra light bulbs	Spark plugs
Fuses and circuit breakers	Main 12 volt fuses
Assorted stainless screws	Assorted stainless bolts
Flashlight and batteries	Drain plugs
Engine oil	Propellers
Fuel filters	Propeller hub kits
Fuel hose and clamps	Wire ties
Assorted hose clamps	Hydraulic steering fluid
Spare bilge pump	Rags
- Make sure all fire extinguishers are in position and in good operating condition.
- Check the engine and steering controls for smooth and proper operation. Be sure the shift controls are in the neutral position.
- Be sure the emergency stop lanyard is attached to the operator and the stop switch.
- Refer to the engine owner's manual for pre-operation checks specific to your engines.

2.4 Operating Your Boat

After Starting the Engines:

- Visibly check the engines to be sure there are no apparent water, fuel or oil leaks.
- Check the operation of the engine cooling systems by monitoring the water flowing from the bypass ports.
- Check the engine gauges. Make sure they are reading normally.
- Check the controls and steering for smooth and proper operation.
- Make sure all lines, cables, anchors, etc. for securing a boat are onboard and in good condition. All lines should be coiled, secured and off the decks when underway.
- Have a safe cruise and enjoy yourself.

Remember:

When you operate a boat, you accept the responsibility for the boat, for the safety of passengers and for others out enjoying the water.



- Alcohol and any drugs can severely reduce your reaction time and affect your better judgement.
- Alcohol severely reduces the ability to react to several different signals at once.
- Alcohol makes it difficult to correctly judge speed and distance or track moving objects.
- Alcohol reduces night vision and the ability to distinguish red from green.

YOU SHOULD NEVER OPERATE YOUR BOAT WHILE UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.

- Make sure one other person on the boat is instructed in the operation of the boat.
- Make sure the boat is operated in compliance with all state and local laws governing the use of a boat.


WARNING


DO NOT OPERATE THE BOAT UNLESS IT IS COMPLETELY ASSEMBLED. KEEP ALL FASTENERS TIGHT. KEEP ADJUSTMENTS ACCORDING TO SPECIFICATIONS.


WARNING


FAILURE TO FOLLOW THE BREAK-IN PROCEDURE MAY RESULT IN REDUCED ENGINE LIFE OR EVEN SEVERE ENGINE DAMAGE IN YOUR OUTBOARD ENGINES. MAKE SURE YOU FOLLOW THE BREAK-IN PROCEDURE EXACTLY.

- Always operate the blower whenever the generator is running to remove fumes and help cool the equipment compartment.
- Avoid sea conditions that are beyond the skill and experience of you and your crew. Learn to understand weather patterns and indications for change. You should monitor NOAA weather broadcasts before leaving port and periodically while boating. If the weather deteriorates or a storm approaches, seek shelter in a safe harbor.
- Use caution during periods of reduced visibility due to weather or operation conditions. Reduce speed and designate a passenger to be a lookout for other boats, obstacles and navigational markers until you reach port or conditions improve.
- Your Everglades is a heavy boat that will produce a large wake at certain speeds. You are responsible for damage and injury caused by your boat's wake. Always observe no wake zones and be aware that your wake can endanger small vessels and their passengers. Always be courteous and slow down to reduce your wake when passing smaller boats.
- Before operating the boat for the first time, read the engine break-in procedures. The break-in procedures are found in the owner's manual for the engines. The manual is in the literature packet.
- As different types of engines are used to power the boat, have the dealer describe the operating procedures for your boat. For more instructions on "How To Operate The Boat," make sure you read the instructions given to you in the owner's manual for the engines you have selected.

Notice:

For more instructions on safety, equipment and boat handling, enroll in one of the several free boating courses offered. For information on courses offered in your area go to the U.S. Coast Guard Boating Safety web site at www.uscgboating.org.

Notice:

If the running gear hits an underwater object, stop the engines. Inspect the propulsion system for damage. If the system is damaged, contact your dealer for a complete inspection and repair of the unit.

To stop the boat, follow this procedure:

- Allow the engines to drop to the idle speed.
- Make sure the shifting levers are in the neutral position.

Notice:

If the engines have been run at high speed for a long period of time, allow the engines to cool down by running the engines in the idle position for 3 to 5 minutes.

- Turn the ignitions to the "OFF" position.
- Raise the trim tabs to the full up position.

After Operation:

- If operating in saltwater, wash the boat and all equipment with soap and water. Flush the engines using fresh water. Refer to the engine owner's manual for instructions on flushing your outboard engines.
- Check the bilge area for debris and excess water.
- Fill the fuel tank to near full to reduce condensation. Allow enough room in the tank for the fuel to expand without being forced out through the vent.
- Turn off all electrical equipment except the automatic bilge pumps.
- If you are going to leave the boat for a long period of time, put the battery main switches in the "Off" position and close all seacocks.
- Make sure the boat is securely moored.

2.5 Docking, Anchoring & Mooring

Docking and Dock Lines

Maneuvering the boat near the dock and securing the boat require skill and techniques that are unique to the water and wind conditions and the layout of the dock. If possible, position a crew member at the bow and stern to man the lines and assist in docking operations. While maneuvering close to the dock, consideration must be given to the wind and current. You should anticipate the effect these forces will have on the boat and use them to help put the boat where you want it. It is important to practice in open water using an imaginary dock enough to develop a sense for the way your boat handles in a variety of docking scenarios. You must be able to foresee the possibilities and have solutions in mind before problems occur.

Approaching a dock or backing into a slip in high winds or strong currents requires a considerable amount of skill. If you are new to boat handling, you should take lessons from an experienced pilot to learn how to maneuver your boat in tight quarters in less than ideal conditions. You should also practice away from the dock during windy conditions.

Dock lines are generally twisted or braided nylon. Nylon is strong and stretches to absorb shock. It also has a long life and is soft and easy on the hands. The line's size will vary with the size of the boat. Typically a 30 to 40 foot boat will use 5/8-inch line and a 20 to 30 foot boat will use 1/2-inch line. The number of lines and their configuration will vary depending on the dock, the range of the tide and many other factors. Usually a combination of bow, stern and spring lines is used to secure the boat.

**CAUTION**

TO PREVENT DAMAGE TO THE BOAT, CLOSE ALL SEACOCKS BEFORE LEAVING THE BOAT.


Maneuvering to the Dock

Notice:


If your boat is equipped with a joystick integrated into the engine control system and you are using the joystick to maneuver the boat, you should leave both engines running while using the joystick control to maneuver the boat to the dock or back into the slip.

Note that most joystick controls will be deactivated if either throttle or shift control lever is moved while maneuvering the boat.

Electronic control system and joystick operation is unique to the engines installed on your boat. Operation manuals for the engines and control systems are included with this manual. You should read these manuals thoroughly and understand the control system in theory and operation before operating your boat. Additionally, your dealer should demonstrate the operation of the control system and instruct you in operating the controls properly.



Securing The Boat Along Side A Dock (Typical)



Securing The Boat In A Slip (Typical)

Approach the dock slowly at a 30 to 40 degree angle. Whenever possible, approach against the wind or current. Turn the engines straight & shift to neutral when you feel you have enough momentum to reach the dock. Use reverse on the outboard engine while turning the steering wheel towards the dock to slow the boat and pull the stern toward the dock as the boat approaches. Straighten the engines and use both engines to stop the boat if it is still moving forward against the pilings. If you executed your approach properly, the boat will lightly touch the pilings at the same time the forward momentum is stopped. Have the dock lines ready and secure the boat as soon as it stops. Use fenders to protect the boat while it is docked. Keep the engines running until the lines are secured.

Backing into a Slip

Approach the slip with the stern against the wind or current and the engines straight ahead. Use the engines and turn the steering wheel to maneuver the boat into alignment with the slip. Reverse the engines and slowly back into the slip. Shift from reverse to neutral frequently to prevent the boat from gaining too much speed. Move the stern

right and left by shifting the engines in and out of gear or turning the wheel. When nearly in the slip all the way, straighten the engines and shift to forward to stop. Keep the engines running until the lines are secured.

Securing Dock Lines

Securing a boat that is tied along side the dock typically requires a bow and stern line and two spring lines. The bow and stern lines are usually secured to the dock at a 40° angle aft of the stern cleat and forward of the bow cleat. The after bow spring line is secured to the dock at a 40° angle aft of the after bow spring cleat. The forward quarter spring is secured to the dock at a 40° angle forward of the stern cleat. The spring lines keep the boat square to the dock and reduce fore and aft movement while allowing the boat to move up and down with the tide.

Securing a boat in a slip is somewhat different. It typically requires two bow lines secured to pilings on each side of the bow, two stern lines secured to the dock and two spring lines that prevent the boat from hitting the dock. The bow lines are typically secured with enough slack to allow the

boat to ride the tide. The stern lines are crossed. One line runs from the port aft boat cleat to the starboard dock cleat and the other line runs from the starboard aft boat cleat to the port cleat on the dock. The stern lines center the boat, control the forward motion and allow the boat to ride the tide. Two forward quarter spring lines typically are secured to the stern cleats and to mid ship pilings or cleats. The spring lines keep the boat from backing into the dock while allowing it to ride the tide.

Leaving the Dock

Always start the engines and let them warm up for several minutes before releasing the lines. Boats steer from the stern and it is important that you achieve enough clearance at the stern to maneuver the boat as quickly as possible. Push the stern off and maneuver such that you get stern clearance quickly. Proceed slowly until well clear of the dock and other boats.

Mooring

Approach the mooring heading into the wind or current. Shift to neutral when you have just enough headway to reach the buoy. Position a crew member on the bow to retrieve the mooring line with a boat hook and secure the line. Keep the engines running until the line is secured.

Leaving a Mooring

Start the engines and let them warm up for several minutes before releasing the mooring line. The boat will already be headed into the wind, so move it forward enough to loosen the line and release it. Back the boat away from the mooring until you can see the buoy. Move the boat slowly away from the mooring.

Anchoring



Make sure the bitter end of the anchor line is attached to boat before dropping the anchor. Bring the bow into the wind or current and put the engine in neutral. When the vessel comes to a stop, lower the anchor over the bow. Pay out anchor line so that it is at least 5 to 7 times the depth of the water and secure the line to a cleat. Use caution to avoid getting your feet or hands tangled in the line. Additional scope of 10 times the depth may be required for storm conditions. Check landmarks on shore or your GPS position to make sure the anchor is not dragging. If it is dragging, you will have to start all over. It is prudent to use two anchors at the bow if your are anchoring overnight or in rough weather.

After the anchor is set, the windlass must not be left to take the entire force from the anchor line. Boats lying to their anchor in a high swell or heavy weather conditions will snub on the line. This can cause slippage or apply excessive loads to the windlass. The line should always be made fast to a bow cleat to relieve the load on the windlass.

Do not set a bow and stern anchor when mooring, only anchor from the bow. The stern anchor will not allow the boat to swing with the current and wind. If your are anchored in a mooring with other boats, your boat will not swing with the other boats in the mooring, creating a potential for contact with another boat when the tide or wind changes. Additionally, having the stern to the wind or tide creates a potentially hazardous situation for the boat and crew.

Releasing the Anchor

Release the anchor by driving the boat slowly to the point where the anchor line becomes vertical. It should release when you pass that point. If the anchor doesn't release right away, stop the boat directly above the anchor and tie the line to the cleat as tight as possible. The up and down movement of the boat will usually loosen the anchor within a minute. Make sure you secure the anchor and properly stow the line before operating the boat.

	WARNING	
NEVER ANCHOR THE BOAT BY THE STERN. THE STERN OF THE BOAT IS VULNERABLE TO SWAMPING FROM WAVE ACTION AND WIND AND CURRENT WILL PUT MORE STRESS ON THE ANCHOR WHEN IT IS ATTACHED TO THE STERN. ONLY ANCHOR THE BOAT BY THE BOW		

2.6 Controls, Steering or Propulsion System Failure

If the propulsion, control or steering system fails while you are operating the boat, bring the throttles to idle and shift to neutral. Decide whether you need to put out the anchor to prevent the boat from drifting or to hold the bow into the seas. Investigate and correct the problem if you can. Turn the engine off before opening the engine cowling to make repairs. If you are unable to correct the problem, call for help.

If only one engine has failed, you can usually run home on the other engine. Be careful not to apply too much power to the engine that is running. When

only one engine is used to power a twin engine boat, the engine is over propped and can be overloaded if too much throttle is applied. You should contact your dealer or the engine manufacturer for the maximum power settings when running without one engine.

2.7 Collision

If your boat is involved in a collision with another boat, dock, piling or a sandbar, your first priority is to check your passengers for injuries and administer first aid if necessary. Once your passengers situations are stabilized, thoroughly inspect the boat for damage. Check below decks for leaks and the control systems for proper operation. Plug all leaks or make the necessary repairs to the control systems before proceeding slowly and carefully to port. Request assistance if necessary. Haul the boat and make a thorough inspection of the hull and running gear for damage.

2.8 Grounding, Towing & Rendering Assistance

The law requires the owner or operator of a vessel to render assistance to any individual or vessel in distress, as long as his vessel is not endangered in the process.

If the boat should become disabled or if another craft that is disabled requires assistance, great care must be taken. The stress applied to a boat during towing may become excessive. Excessive stress can damage the structure of the boat and create a safety hazard for those aboard.

Freeing a grounded vessel or towing a boat that is disabled, requires specialized equipment and knowledge. Line failure and structural damage caused by improper towing have resulted in fatal injuries. Because of this, we strongly suggest that these activities be left to those who have the equipment and knowledge, e.g., the U.S. Coast Guard or a commercial towing company, to safely accomplish the towing task.

DANGER

THE MOORING CLEATS ON EVERGLADES BOATS ARE NOT DESIGNED OR INTENDED TO BE USED FOR TOWING PURPOSES. THESE CLEATS ARE SPECIFICALLY DESIGNED AS MOORING CLEATS FOR SECURING THE BOAT TO A DOCK, PIER, ETC. DO NOT USE THESE FITTINGS FOR TOWING OR ATTEMPTING TO FREE A GROUNDED VESSEL.

WARNING

WHEN TOWING OPERATIONS ARE UNDERWAY, HAVE EVERYONE ABOARD BOTH VESSELS STAY CLEAR OF THE TOW LINE AND SURROUNDING AREA. A TOW LINE THAT SHOULD BREAK WHILE UNDER STRESS CAN BE VERY DANGEROUS AND COULD CAUSE SERIOUS INJURY OR DEATH.

WARNING

RUNNING AGROUND CAN CAUSE SERIOUS INJURY TO PASSENGERS AND DAMAGE TO A BOAT AND ITS UNDERWATER GEAR. IF YOUR BOAT SHOULD BECOME GROUNDED, DISTRIBUTE PERSONAL FLOTATION DEVICES AND INSPECT THE BOAT FOR POSSIBLE DAMAGE. THOROUGHLY INSPECT THE BILGE AREA FOR SIGNS OF LEAKAGE. AN EXPERIENCED SERVICE FACILITY SHOULD CHECK YOUR UNDERWATER GEAR AT THE FIRST OPPORTUNITY. DO NOT CONTINUE TO USE YOUR BOAT IF THE CONDITION OF THE UNDERWATER EQUIPMENT IS QUESTIONABLE.

2.9 Flooding or Capsizing

Boats can become unstable if they become flooded or completely swamped. You must always be aware of the position of the boat to the seas and the amount of water in the bilge. Water entering the boat through the transom door or over the stern gunnels can usually be corrected by closing the door and turning the boat into the waves. If the bilge is flooding because of a hole in the hull or a defective hose, you may be able to plug it with rags, close the thru-hull valve or assist the pumps by bailing with buckets. Put a mayday call in to the Coast Guard or nearby boats and distribute life jackets as soon as you discover your boat is in trouble.

If the boat becomes swamped and capsizes, you and your passengers should stay with the boat as long as you can. It is much easier for the Coast Guard, aircraft or other boats to spot, than people in the water. If your boat is equipped with an EPIRB, make sure it is activated. When activated, EPIRBs will send distress code homing beacons that allow Coast Guard aircraft to identify your boat and find you quickly.

2.10 Fishing

Fishing can be very exciting and distracting for the operator when the action gets intense. You must always make sure the helm is properly manned and is never left unattended while trolling. Always be conscious of the fact that your primary responsibility is the safe operation of your boat and the safety of your passengers and other boats in the area.



If you are fishing in an area that is crowded with other fishing boats, it may be difficult to follow the rules of the road. This situation can become especially difficult when most boats are trolling. Being courteous and exercising good common sense is essential. Avoid trying to assert your right-of-way and concentrate on staying clear and preventing tangled or cut lines and other unpleasant encounters with other boats. Also keep in mind that fishing line wrapped around a propeller shaft can damage seals in the engine lower unit.

2.11 Man Overboard

If someone falls overboard, you must be prepared to react quickly, particularly when you are offshore. The following procedures will help you in recovering a person that has fallen overboard.

- Immediately stop the boat and sound a man overboard alarm and have all passengers point to the person in the water.
- Circle around quickly and throw a cushion or life jacket to the person, if possible, and another to use as a marker.
- Keep the person on the driver side of the boat so you can keep him in sight at all times.
- Make sure to approach the person from the downwind side and maneuver the boat so the propellers are well clear of the person in the water.
- Turn off the engines when the person is alongside and use a ring buoy with a line attached, a paddle or boat hook to assist him to the boat. Make sure you don't hit him with the ring buoy or the boat.
- Pull the person to the boat and assist him on board.

- Check the person for injuries and administer first aid if necessary. If the injuries are serious, call for help. Refer to the Safety chapter for more information on first aid and requesting emergency medical assistance.

 WARNING 	
MOVING PROPELLERS ARE DANGEROUS. THEY CAN CAUSE DEATH, LOSS OF LIMBS OR OTHER SEVERE INJURY. DO NOT USE THE SWIM PLATFORM OR SWIM LADDER WHILE THE ENGINES ARE RUNNING. STOP THE ENGINES IF DIVERS OR SWIMMERS ARE ATTEMPTING TO BOARD. ALWAYS PROPERLY STORE THE LADDER BEFORE STARTING THE ENGINES.	


2.12 Water Skiing & Wakeboarding

Your boat could be equipped for water skiing and wakeboarding. If you have never driven skiers before, you should spend some hours as an observer and learning from an experienced driver. If you are an experienced driver, you should take some time to become familiar with the boat and the way it handles before pulling a skier. The driver should also know the skier's ability and drive accordingly.

The following safety precautions should be observed while towing water skiers.

- Water ski only in safe areas, away from other boats and swimmers, out of channels and in water free of underwater obstructions. The area should be at least 5 feet deep, 3000 feet long and have at least 100 feet between each side of the boat and any obstructions.
- Make sure that anyone who skis can swim. Do not allow people who cannot swim to water ski.
- Be sure that the skier is wearing a proper life jacket. A water skier is considered onboard the boat and a Coast Guard approved life jacket is required. It is advisable and recommended for a skier to wear a flotation device designed to withstand the impact of hitting the water at high speed.
- Make sure to inspect the ski equipment and tow rope before each ski session. Never use equipment that is damaged or with loose screws, torn boots, severe corrosion or tears in the fabric. You should also inspect the ski tow rope and replace if it is frayed, has unnecessary knots or is damaged. Never use a ski tow line that is questionable.

- Secure the ski tow rope to an appropriate device intended for ski tow ropes.
- Always carry a second person on board to observe the skier or wakeboarder so that your full attention can be given to the safe operation of the boat. The operator should pay attention to driving the boat and have the observer keep him updated on the skier. Never ski after dark. It is hazardous and illegal. Neither the boat operator or skier can see well enough to navigate at skiing or wakeboarding speeds safely at night.
- Never spray swimmers, boats, rafts or other skiers. The risk for a collision makes this dangerous for the skier and people being sprayed.
- Never follow directly behind another boat while pulling skiers. Always stay a safe distance behind or off the side of other boat traffic. If the boat you are following stops unexpectedly, you may not be able to respond quick enough endangering your skier and occupants of both boats.
- Never follow behind another boat pulling a skier for any reason, even if you are not pulling a skier. If the skier you are following falls, you may not be able to respond quick enough and could run over the skier.
- When pulling multiple skiers, make sure the ropes are the same length. Never pull multiple skiers with tow ropes of different lengths.
- Always make sure to slowly pull the slack out of the ski rope and wait for the OK from the skier before advancing the throttle to ensure the rope is not wrapped around the skier and that the skier is ready. Never advance the throttle until the skier provides the ready signal.
- When turning around to pick up a fallen skier, make sure to look for other boat traffic in the direction of the turn before you turn the boat.
- Approach a skier in the water from the downwind side and be certain to stop the motion of the boat and your motor before coming in close proximity to the skier.
- Give immediate attention to a fallen skier. A fallen skier is very hard to see by other boats and is extremely vulnerable. When a skier falls, be prepared to immediately turn the boat and return to the skier.
- Never leave a fallen skier alone in the water for any reason and have an observer display a skier down flag to alert other boaters that your skier has fallen.



Common Hand Signals for Water Sports Activities

- Agree on hand signals to be used between the observer and skier to communicate. This is important to eliminate confusion and ensure the safety of your skiers, wakeboarders or tubers. Refer the Hand Signals drawing in this section for signals that are commonly used during water sports activities.
- Make sure the observer watches for the skier's signal to indicate he or she is OK. If the signal is not seen immediately, assume the skier is injured and in need of immediate assistance. Be prepared to respond quickly.

For additional information on water skiing, including hand signals and water skiing manuals, contact the American Water Skiing Association in Winter Haven, Florida, 813-324-4341.

⚠
WARNING
⚠

MOVING PROPELLERS ARE DANGEROUS. THEY CAN CAUSE DEATH, LOSS OF LIMBS OR OTHER SEVERE INJURY. DO NOT USE THE SWIM PLATFORM OR SWIM LADDER WHILE THE ENGINE IS RUNNING. STOP THE ENGINE IF DIVERS, SWIMMERS OR SKIERS ARE ATTEMPTING TO BOARD. ALWAYS PROPERLY STORE THE LADDER BEFORE STARTING THE ENGINE.

2.13 Teak Surfing

Teak Surfing is a new and dangerous boating fad that involves an individual holding on to the swim platform of a vessel while a wake builds up then lets go to body surf the wave created by the boat; hence the term "Teak Surfing." This activity puts that individual directly in the path of the boat's exhaust and poisonous carbon monoxide. Because of the multiple dangers associated with teak surfing and the carbon monoxide problem in particular, the Coast Guard has issued a safety alert that strongly advises the public not to engage in teak surfing and warns that teak surfing may cause carbon monoxide poisoning and even fatalities.

Teak surfing not only exposes an individual to potentially fatal concentrations of carbon monoxide from the engine exhaust, it exposes them unnecessarily and dangerously to the boat's propeller. The danger is compounded by the fact that individuals do not usually wear a life jacket when teak surfing.

Teak surfing is an extremely dangerous activity and you should never allow anyone to "Teak Surf" behind your boat or be in the water near the ladder or swim platform while the engine is operating.

⚠
WARNING
⚠





TEAK SURFING (HOLDING ONTO THE SWIM PLATFORM WHILE BOAT IS UNDERWAY) IS EXTREMELY DANGEROUS AND CAN CAUSE SEVERE INJURY OR DEATH. TEAK SURFING PUTS AN INDIVIDUAL DIRECTLY THE PATH OF THE BOAT'S EXHAUST AND EXPOSES THEM TO POISONOUS LEVELS OF CARBON MONOXIDE. IT ALSO EXPOSES AN INDIVIDUAL TO THE POSSIBILITY OF BEING THROWN INTO THE PROPELLERS. YOU SHOULD NEVER ALLOW ANYONE TO TEAK SURF BEHIND YOUR BOAT OR TO BE IN THE WATER NEAR THE LADDER OR SWIM PLATFORM WHILE THE ENGINE IS RUNNING.

2.14 Trash Disposal

The discharge of plastic trash or trash mixed with plastic is illegal anywhere in the marine environment. U.S. Coast Guard regulations also restrict the dumping of other forms of garbage. Regional, state and local restrictions on garbage discharges also may apply.

Responsible boaters store refuse in bags and dispose of it properly on shore. You should make sure your passengers are aware of the local waste laws and the trash management procedure on your boat.

It is illegal for any vessel to dump plastic trash ANYWHERE in the ocean or navigable waters of the United States. Annex V of the MARPOL TREATY is an International Law for a cleaner, safer marine environment. Violation of these requirements is a Class D felony and may result in civil penalty up to a \$25,000 fine and imprisonment.

 U.S. Lakes, Rivers, Bays sounds and 3 miles from shore ILLEGAL TO DUMP Plastic & Garbage Paper Metal Rags Crockery Glass Dummage Food	 3 to 12 miles ILLEGAL TO DUMP Plastic Dunnage, lining & packing materials that float, also if not ground to less than one inch Paper Crockery Rags Metal Glass Food	 12 to 25 miles ILLEGAL TO DUMP Plastic Dunnage, lining & packing materials that float	 Outside 25 miles ILLEGAL TO DUMP Plastic
---	--	--	--

Regional state and local regulations may further restrict the disposal of garbage. The discharge of all garbage into the Great Lakes or their connecting or tributary waters is prohibited.

Typical Trash Disposal Placard



Yacht Certification

Refer to the placard mounted on your boat for more specific information regarding solid waste disposal.

Federal law requires that vessels of 26 feet or longer must display in a prominent location, a durable placard at least 4 by 9 inches notifying the crew and passengers of the discharge restrictions (Marpol Treaty). A label for this purpose has been shipped with the boat and is attached to the starboard side of the cockpit. It is the boat owner's responsibility to make sure this placard remains mounted and legible in accordance with the law.

2.15 Yacht Certification Plate

Coast Guard rules require boats less than 20 feet (6 meters) to display a gross weight and person-capacity plate provided by the manufacturer. The person/load capacity is determined by the US Coast Guard.

Boat manufacturers in the National Marine Manufacturers Association (NMMA) program will display a gross weight and person-capacity plate on boats up to 26 feet (7.9 meters). Larger boats, including your boat, will display a Yacht Certification plate indicating compliance with the NMMA and U.S. Coast Guard requirements instead of a capacity plate.

The yacht certification plate is usually located on the starboard side of the cockpit.

2.16 Trailering Your Boat

If you trailer your boat, make sure that your tow vehicle is capable of towing the weight of the trailer, boat and equipment and the weight of the passengers and equipment inside the vehicle. This may require that the tow vehicle be specially equipped with a larger engine, transmission, brakes and trailer tow package. Additionally, the laws in your state may require special permits to tow a boat this large on some or all highways.

The boat trailer is an important part of your boating package. The trailer should be matched to your boat's weight and hull. Using a trailer with a capacity too low will be unsafe on the road and cause abnormal wear. A trailer with a capacity too high, can damage the boat. Contact your trailer dealer to evaluate your towing vehicle and hitch and to make sure you have the correct trailer for your boat.

Important Note:

Your Everglades is a heavy boat and care must be taken when selecting the trailer. We recommend that you use a bunk style trailer that incorporates a combination of heavy duty rollers or bunks, to support the keel and long bunks running under and parallel to the stringers to support the hull. Avoid using a full roller trailer that does not have bunks. Roller trailers have a tendency to put extreme pressure points on the hull, especially on the lifting strakes and have damaged boats. The situation is worse during launching and haul out. Damage resulting from improper trailer support or the use of a full roller trailer will not be covered by the Everglades Warranty.

Notice:


Contact your trailer dealer to evaluate your towing vehicle and hitch and to make sure you have the correct trailer for your boat.

- Make sure the trailer is a match for your boat's weight and hull design. More damage can be done to a boat by the stresses of road travel than by normal water operation. A boat hull is designed to be supported evenly by water. So, when it is transported on a trailer it should be supported structurally as evenly across the hull as possible allowing for even distribution of the weight of the hull, engines and equipment.

- Make sure the trailer bunks and/or rollers properly support the hull and do not put pressure on the lifting strakes. The rollers and bunks must be kept in good condition to prevent scratching and gouging of the hull.
- The capacity rating of the trailer should be greater than the combined weight of the boat, motor and equipment. The gross vehicle weight rating must be shown on the trailer. Make sure the weight of the boat, engine, gear and trailer is not more than the gross vehicle weight rating.
- Make sure the boat is securely fastened on the trailer to prevent movement between the boat and trailer. The bow eye on the boat should be secured with a rope, chain or turnbuckle in addition to the winch cable. Additional straps may be required across the beam of the boat or from the transom eyes to the trailer.

Notice:

Your trailer dealer will give instructions on how to load, fasten and launch your boat.




Before Going Out On The Highway:

- Side curtains, clear connector, backdrop and aft curtain must be removed when trailering. Canvas enclosures are not designed to withstand the extreme wind pressure encountered while trailering and will be damaged. Always remove and properly store the enclosure before trailering your boat.
- Make sure the tow BALL and TRAILER COUPLER are the same size and bolts and nuts are tightly secured.
- The COUPLER MUST BE COMPLETELY OVER THE BALL and the LATCHING MECHANISM LOCKED DOWN.

Operation

- Make sure the TRAILER IS LOADED EVENLY from front to rear as well as side to side and has the correct weight on the hitch. Too much weight on the hitch will cause the rear of the tow vehicle to drag and may make steering more difficult. Too little weight on the hitch will cause the rig to fishtail and will make controlling the tow vehicle difficult. Contact your trailer manufacturer or dealer for the correct weight on the hitch for your trailer.
- The SAFETY CHAINS must be attached crisscrossing under the coupler to the frame of the tow vehicle. If the ball was to break, the trailer would follow in a straight line and prevent the coupler from dragging on the road. Make sure the trailer emergency brake cable or chain is also installed to the tow vehicle frame.
- Make sure the LIGHTS on the trailer function properly.
- CHECK THE BRAKES. On a level parking area roll forward and apply the brakes several times at increasing speeds to determine if the brakes on the tow vehicle and trailer are working properly.
- Make sure the tow vehicle has SIDE VIEW MIRRORS that are large enough to provide an unobstructed rear view on both sides of the vehicle.



Backing Procedure for Boat Trailers

- CHECK THE TIRES and WHEEL BEARINGS.

Notice:

Make sure your towing vehicle and trailer are in compliance with all state and local laws. Contact your state motor vehicle bureau for laws governing the towing of trailers.

PROPULSION SYSTEM

3.1 General

Your Everglades is designed to be powered with 4-cycle outboard motors. 4-cycle outboard engines do not use an oil injection system and are not equipped with remote oil tanks. They have an oil sump in the crankcase that must be kept full of the type of oil recommended by the engine manufacturer. The oil must be checked before each use and changed regularly.

Each manufacturer of the various outboard motors provides an owner's information manual with its product. It is important that you read the manual(s) very carefully and become familiar with the proper care and operation of the engines and drive systems. A warranty registration card has been furnished with each new engine and can be located in the engine owner's manual. All information requested on this card should be filled out completely by the dealer and purchaser and then returned to the respective engine manufacturer as soon as possible.



Outboard Engines



WARNING



DO NOT ATTEMPT TO SERVICE ANY ENGINE OR DRIVE COMPONENT WITHOUT BEING TOTALLY FAMILIAR WITH THE SAFE AND PROPER SERVICE PROCEDURES. CERTAIN MOVING PARTS ARE EXPOSED AND CAN BE DANGEROUS TO SOMEONE UNFAMILIAR WITH THE OPERATION AND FUNCTION OF THE EQUIPMENT.



WARNING



DO NOT INHALE EXHAUST FUMES! EXHAUST CONTAINS CARBON MONOXIDE THAT IS COLORLESS AND ODORLESS. CARBON MONOXIDE IS A DANGEROUS GAS THAT IS POTENTIALLY LETHAL.

3.2 Drive System Corrosion

Each outboard motor is a complete drive system with the gear case being just forward of the propeller and connected to the power head with a vertical drive shaft. All engines require some maintenance. Routine maintenance recommended for your engine is outlined in the engine owner's manual. Routine maintenance is normally

the primary concern unless the boat is to be kept in saltwater for extended periods of time. Then the main concerns are marine growth and galvanic corrosion.

Marine growth occurs when components are left in the water for extended periods and can cause poor performance or permanent damage to the exposed components. The type of growth and how quickly it occurs is relative to the water conditions in your boating area. Water temperature, pollution, current, etc. can have an effect on marine growth.

Galvanic corrosion is the corrosion process occurring when different metals are submerged in an electrolyte. Seawater is an electrolyte and submerged engine components must be properly protected. Outboard motors are equipped with sacrificial anodes to prevent galvanic corrosion problems. The anodes must be monitored and replaced as necessary. For locations and maintenance, please refer to the engine owner's manual. When leaving the boat in the water, tilt the motors as high as possible. This will decrease the risk of marine growth around the cooling inlets, propeller and exhaust ports and damage from galvanic corrosion.



CAUTION



DO NOT PAINT THE OUTBOARD MOTOR WITH ANTI-FOULING PAINTS DESIGNED FOR BOAT HULLS. MANY OF THESE PAINTS CAN CAUSE SEVERE DAMAGE TO THE ENGINE. CONTACT YOUR EVERGLADES DEALER OR ENGINE MANUFACTURER FOR INFORMATION ON THE PROPER PAINTING PROCEDURES.



CAUTION



NEVER RUN AN OUTBOARD MOTOR WITHOUT WATER FLOWING TO THE WATER PUMP. SERIOUS DAMAGE TO THE WATER IMPELLER OR ENGINE COULD RESULT.

3.3 Engine Lubrication

4-cycle outboard engines incorporate a pressure-type lubrication system with an oil sump in the crankcase that must be kept full of the type and grade of oil recommended by the engine manufacturer. It is normal for 4-cycle engines to consume a small amount of oil. Therefore, the oil must be checked before each use and changed at regular intervals as instructed by the engine owner's manual.

Notice:

Always monitor the oil level in the crankcase and only use the type of oil specified by the engine manufacturer. Yamaha engines specify Yamalube engine oil.

3.4 Engine Cooling System

Outboard engines are raw water (seawater) cooled. Water is pumped through the water inlets, circulated through the engine block and relinquished with the exhaust gases through the propeller hub. The water pump uses a small impeller made of synthetic rubber. The impeller and water pump cannot run dry for more than a few seconds. In most outboard motors, some cooling water is diverted through ports below the engine cowling. This allows the operator to visually check the operation of the cooling system. When the engine is started, always check for a steady stream of water coming out of those ports.

Notice:

If the boat is used in salt or badly polluted water, the engines should be flushed after each use. Refer to the engine owner's manual for the proper engine flushing procedure.

3.5 Propellers

The propellers convert the engine's power into thrust. They come in a variety of styles, diameters and pitches. All boats powered by Yamaha engines are equipped with Yamaha propellers. The propellers that will best suit the needs of your boat will depend somewhat on your application and expected average load. Propeller sizes are identified by two numbers stamped on the prop in sequence. The 1st number in the sequence (example 14" x 21") is the diameter of the propeller and the 2nd number is the pitch. Pitch is the theoretical distance traveled by the propeller in each revolution.

Always repair or replace a propeller immediately if it has been damaged. A damaged and therefore out of balance propeller can cause vibration that can be felt in the boat and could damage the engine gear assembly. Refer to the engine owner's manual for information on propeller removal and installation.

3.6 Performance Issues & Propellers

It is extremely important that the boat is propped to run at or very near the recommended top RPM with an average load. If the top RPM is above or below the recommend range, the propellers must be changed to prevent loss of performance and possible engine damage.

Your boat is equipped from the factory with counter rotating engines that are mounted to achieve quicker planning and optimum performance. Therefore, the left rotation engine is mounted on the port side of the transom and the right rotation engine is mounted on the starboard side.

Notice:

Before changing propellers to correct boat performance problems, be sure other factors such as engine tuning, bottom and running gear growth, etc. are not the source of performance changes. Always be sure the load conditions are those normally experienced, before changing propellers.

Your boat was shipped with propellers that typically provide optimum performance for your boat. However there are factors that can affect performance and propeller requirements.

Some are as follows:


- You should be sure the load conditions are those normally experienced. If the boat ran in the required RPM range when it was new and you have not added any additional gear or heavy equipment and have not damaged the propellers, there is a good chance the propellers are not the problem.
- The addition of heavy equipment like a tower, life rafts, additional coolers, etc., will cause additional load on the engines. Consequently, different propellers may be required.
- Boats operated at high altitudes (above 2000 feet). Engines operated at high altitudes will not be able to develop as much horsepower as they do at or near sea level. Consequently, different propellers may be required.

Notice:

Outboard engines can be damaged and the warranty void if the boat is not propped correctly. Always consult your Everglades dealer or authorized engine service dealer when making changes to the propellers or if the boat does not run near the top recommended RPM.



Yamaha Propeller



Typical Twin Engine Display

3.7 Engine Instrumentation

The helm station is equipped with a set of engine instruments and/or alarms. These instruments allow the operator to monitor the operational condition of the engines. Close observation of these instruments allows the operator to operate the engines at the most efficient level and could save them from serious costly damage.

Most Everglades boats are equipped with Yamaha engines and Command Link Plus[®] LCD multifunction display. This system can be integrated with the optional electronic navigation equipment installed on your boat. A brief description of the Command Link Plus[®] system integrated gauges and their basic functions are listed in this section. Other functions that are dependent on the electronics installed on your boat may be available. Refer to the Yamaha engine and Command Link Plus[®] owner's manuals and the manuals for the electronics installed on your boat for detailed information on the operation of the instruments and additional functions available.

The instrumentation is unique to the type of outboard motors installed on your Everglades.

Some or all of the following gauges may be present.

Tachometers

The tachometers display the speed of the engines in revolutions per minute (RPM). This speed is not the boat speed or necessarily the speed of the propeller.

The tachometer display also contains the engine trim meters, oil pressure gauge, fuel gauge, water temperature and the overheat warning indicator.

CAUTION

NEVER EXCEED THE MAXIMUM RECOMMENDED OPERATION RPM OF THE ENGINES. MAINTAINING MAXIMUM OR CLOSE TO MAXIMUM RPM FOR EXTENDED PERIODS CAN REDUCE THE LIFE OF THE ENGINES.

Speedometer

Yamaha Command Link Plus[®] speedometers can indicate boat speed via the engine pickup or an optional GPS or depth sounder triducer, if these



Typical Engine Gauge Display On A Garmin Chartplotter Screen

options are installed in your boat. Refer to the engine gauge and electronics operating manuals for more information on the speedometer options available for your boat.

Overheat Warning Indicator

The temperature warning indicates that the temperature of the engine is too high. A sudden increase in the temperature could indicate an obstructed water inlet or an impeller failure. On Yamaha engines the overheat warning indicator is built into the LCD display. It will start to blink and sound an alarm if the engine temperature is too high.

CAUTION

CONTINUED OPERATION OF AN OVERHEATED ENGINE CAN RESULT IN ENGINE SEIZURE. IF AN UNUSUALLY HIGH TEMPERATURE READING OCCURS, SHUT THE ENGINE OFF IMMEDIATELY. THEN INVESTIGATE AND CORRECT THE PROBLEM

Fuel Gauge

The fuel gauge indicates the amount of fuel in the fuel tanks. On boats equipped with Yamaha Command Link Plus®, the fuel gauge is built into the LCD Display. The fuel indicator on the display will begin to blink if the fuel in the tank drops too low. The system can monitor up to 4 fuel or water tanks.

Voltmeters

The voltmeters display the voltage for the battery and the charging system for each engine. The normal voltage is 11 to 12 volts with the engines off and 13 to 14.5 volts with the engines running. The Yamaha engine voltmeter is built into the LCD display. It will begin to blink if the voltage in the battery drops too low.

Hour Meters



The hour meters keep a record of the operating time for each engine.

Engine Tilt/Trim Gauges

The tilt/trim gauges monitor the position of each outboard engine. The upper range of the gauge indicates the tilt, which is used for trailering and shallow water operation. The lower range indicates the trim position. This is the range used to adjust the hull angle while operating your boat on plane. The Yamaha engine trim indicator is built into the LCD display. Please refer to the engine and Command Link Plus® owner's manuals for more information on the operation of the outboard power tilt and trim.

Engine Alarms

All outboards are equipped with an audible alarm system mounted in the helm area that monitors selected critical engine systems. The alarm will sound if one of these systems begins to fail. Refer to the engine owner's manual for information on the alarms installed with your engines.

 **CAUTION** 

IF THE ENGINE ALARM SOUNDS, IMMEDIATELY SHUT OFF THE ENGINE UNTIL THE PROBLEM IS FOUND AND CORRECTED.

Fuel Management

Fuel management systems are standard equipment with some outboard engines. On Yamaha engines, the fuel management gauge is built into the Command Link Plus® display and can monitor miles per gallon, total gallons used and total gallons remaining.

Refer to the engine or fuel management manual for detailed information on that system.

Compass

All boats are equipped with a compass on the top of the instrument panel. The compass cannot be adjusted accurately at the factory as it must be compensated for the influence of the electrical equipment and electronics unique to your boat. Therefore, the compass should be adjusted by a professional after the electronics and additional electrical accessories are installed and before operating the boat. To adjust the compass for your area, read the instructions on "Compass Compensation" given to you in the literature packet.

Instrument Maintenance

Electrical protection for instruments and ignition circuitry is provided by a set of fuses or circuit breakers located on each engine. The ignition switches should be sprayed periodically with a contact cleaner/lubricant. The ignition switches and all instruments, controls, etc. should be protected from the weather when not in use. Excessive exposure can lead to gauge and ignition switch difficulties.

HELM CONTROL SYSTEMS

4.1 General

The helm controls consist of three systems: the engine throttle and shift controls, the steering system, and the trim tab control switches. These systems provide the operator with the ability to control the direction and attitude of the boat from the helm station.

Each manufacturer of the control components provides an owner's manual with its product. It is important that you read the manuals and become familiar with the proper care and operation of the control systems.

4.2 Engine Throttle & Shift Controls Electronic Engine Controls

The shift and throttle controls on your boat may vary depending on the engines used and control system selected. Refer to the engine or control manuals for specific information on the controls installed on your boat.

The helm is designed for a binnacle style control with a single lever for each engine. The electronic control system consists of three major components: the electronic control head, instruments and keypad, the control processors and applicable harnesses. The controls are completely electronic and there are no cables.

The controls have a single lever for each engine that operates as a gearshift and a throttle. General operation will include a position for neutral (straight up and down or slightly aft of vertical), a forward position (the 1st detent forward of neutral), and a reverse position (the 1st detent aft of neutral). Advancing the control lever beyond the shift range advances the throttle in forward or reverse. Each control is equipped with a means of permitting the engine to be operated at a higher than idle RPM while in neutral for cold starting and warm-up purposes. The control levers are equipped with adjustable control head detent and friction settings.

The engine controls and key pads have integrated switches and indicator lights which allow the operator to control all aspects of the boat's propulsion system. LED lights on the control pad indicate



Typical Yamaha Twin Engine Electronic Control



that the control is activated and the engines can be started.

The most common features activated or monitored by the keypad are:

- Starter lockout, which prevents the engine from being started in gear.
- Gear lockout, which allows engine RPM to be advanced in neutral safely.
- Battery voltage warning indicator that warns the operator of high or low voltage supplied to the system (audible alarm)

- An engine synchronization feature that automatically keeps both engines at the same RPM while cruising. Refer to Engine Synchronizer in this section and the control systems owner's manual for more information regarding engine synchronization.
- Trolling feature that allows the operator to increase the engine speed in 50 RPM increments while operating at trolling speeds between 600 - 1000 RPM.

These features and others not mentioned require specific procedures to activate and operate them properly. Some of the procedures and features are unique to the engines and other options installed on your boat. It is essential that you read the owner's manual for the controls and be completely familiar with their operation before using your boat.

 **CAUTION** 

ALWAYS RETURN THE ENGINE THROTTLE LEVER TO THE EXTREME LOW SPEED POSITION BEFORE SHIFTING. NEVER SHIFT THE UNIT WHILE ENGINE SPEED IS ABOVE IDLE RPM.

Engine Synchronizer

During most operations of a twin engine boat, it is advantageous for both engines to be operated at the same RPM. This reduces noise and vibration and can increase engine efficiency. Setting the throttles so that the engines are running the same RPM (synchronized) can be done by listening to the engine sounds at low RPM and with the automatic synchronizer feature built into the electronic engine controls when the engines are operating above 1000 RPM. Attempting to synchronize the engines solely by using the tachometer readings or control lever placement generally will not work. When the engines are in proper synchronization, the throttle levers may not necessarily be even.

Refer to the engine or control owner's manuals for more information on the engine synchronizer and other features for the electronic controls installed on your boat.

4.3 Neutral Safety Switch

Every control system has a neutral safety switch incorporated into it. This device prohibits an engine from being started while the shift lever is in any position other than the neutral position. If the engine will not start, slight movement of the shift lever may be necessary to locate the neutral position and disengage the safety cutout switch. Control adjustments may be required to correct this condition should it persist. See your Everglades dealer for necessary control adjustments.



The neutral safety switches should be tested periodically to ensure that they are operating properly. To test the neutral safety switches, make sure the engines are tilted down and move the shift levers to the forward position.

Make sure the throttle control levers are not advanced past the idle position. Press the Start Button or turn the key just long enough to briefly engage the starter for the engine.

Notice:

Some outboard control systems are equipped with a computer controlled start feature that will keep the starter engaged until the engine starts if the neutral safety switch fails and allows the starter to engage.

The starter should not engage for any engine. Repeat this test with the shift levers in reverse and the engine throttles at idle. Again, the starter should not engage for any engine. If the starter for any engine engages with the shift controls in any position other than the neutral position, then the neutral safety switch is not functioning properly and you should contact your dealer to have the neutral safety switch repaired by a qualified marine mechanic before using the boat. If an engine starts in gear during this test, immediately move the control lever to the neutral position and turn the engine off.

 **WARNING** 

IN SOME SITUATIONS, IT MAY BE POSSIBLE TO ACCIDENTALLY START THE ENGINES IN GEAR WITH THE THROTTLES ABOVE IDLE IF THE NEUTRAL SAFETY SWITCH IS NOT OPERATING PROPERLY. THIS WOULD CAUSE THE BOAT TO ACCELERATE UNEXPECTEDLY IN FORWARD OR REVERSE AND COULD RESULT IN LOSS OF CONTROL, DAMAGE TO THE BOAT OR INJURY TO PASSENGERS. ALWAYS TEST THE NEUTRAL SAFETY SWITCH PERIODICALLY AND CORRECT ANY PROBLEMS BEFORE USING THE BOAT.

4.4 Engine Power Tilt & Trim

All outboard engines have a tilt and trim feature. Most outboard engines have tilt/trim switches built into the engine shift and throttle controls that allow the operator to control the position of the outboards from the helm. Typically, a switch or switches on the port control lever grip activates the tilt/trim for the engines. Yamaha engine controls have two switches on the cover that activate each engine tilt/trim individually. If necessary, the maximum tilt angle can be adjusted by your Everglades or Yamaha dealer by reprogramming the settings using the Yamaha engine diagnostic system.

Moving the outboard closer to the boat transom is called trimming "in" or "down." Moving the outboard further away from the boat transom is called trimming "out" or "up." In most cases, the boat will run best with the outboard adjusted so the hull will run at a 3 to 5 degree angle to the water.

The term "trim" generally refers to the adjustment of the outboard within the first 20° range of travel. This is the range used while operating your boat on plane. The term "tilt" is generally used when referring to adjusting the outboard further up for shallow water operation or trailering. For information on the proper use and maintenance of the power tilt and trim, refer to the engine owner's manual.



Yamaha Control Trim Switches

CAUTION

THE ENGINE HOSES AND CABLES OR THE TRANSM GEL COAT CAN BE DAMAGED BY TILTING THE ENGINES TO THE FULL UP POSITION WITH THE ENGINES TURNED TO THE WRONG POSITION. MOST BOATS REQUIRE THE STEERING WHEEL TO BE TURNED COMPLETELY TO STARBOARD BEFORE TILTING THE ENGINES TO THE FULL UP POSITION. YOU SHOULD MONITOR EACH ENGINE AS IT TILTS TO DETERMINE BEST FULL TILT ENGINE POSITION FOR YOUR BOAT.

CAUTION

SOME AUTOPILOTS HAVE ENGINE POSITION SENSORS THAT ARE MOUNTED TO THE HYDRAULIC STEERING CYLINDER. WITH THESE AUTOPILOTS, THE ENGINE POSITION SENSOR BRACKET COULD HIT THE TRANSM WHEN THE ENGINES ARE TILTED TO THE FULL UP POSITION AND CAUSE DAMAGE TO THE ENGINE RIGGING, THE AUTOPILOT OR THE TRANSM. IF YOU HAVE AN AUTOPILOT INSTALLED ON YOUR BOAT, YOU SHOULD MONITOR THE LOCATION OF THE ENGINE CABLES AND AUTOPILOT BRACKETS AS THE ENGINES ARE TILTED TO DETERMINE THE BEST ENGINE POSITION AND MAXIMUM ENGINE TILT FOR YOUR APPLICATION.



Ignition Switch, Emergency Stop Switch, Lanyard & Start/Stop Buttons

4.5 Engine Stop Switch

Your boat is equipped with an engine stop switch and lanyard. When the lanyard is pulled it will engage the switch and shut off the engines. We strongly recommend that the lanyard be attached to the driver whenever the engines are running. If an engine will not start, it could be because the lanyard is not properly inserted into the engine stop switch. Always make sure the lanyard is properly attached to the engine stop switch before attempting to start the engines.

Refer to the engine owner's manual for more information on the engine stop switch.

Helm Control Systems

4.6 Steering System

Electronic Steering

Your boat is equipped with an electronic steering system that provides precise and responsive steering. Electronic steering is available with or without a joystick control.

Notice:

Some engines with Helm Master electronic steering do not have external electronically controlled steering pumps. All steering components that move each engine are mounted inside the engine cowling.

The system is 100% electronic and there are no mechanical connections between the steering wheel and the drives. Each engine is turned independently allowing improved tight quarter maneuvering and the convenience of an optional Joystick control at the helm.

For safety and improved tight quarter maneuvering, the controlling software on most systems senses engine speed and adjusts maximum steering angle and steering wheel resistance to preset limits as the engine speed increases or decreases. The steering angles and steering wheel resistance at specific engine speeds are programmed into the system at the factory and are not adjustable.


The steering on each motor is totally independent with full redundancy built into the system. If the steering fails on one engine, the other unit will continue to operate. Should a failure in one steering system occur, the controlling software will sense the failure, limit the engine RPM as a safety precaution and alert the operator.

Each steering control system has emergency procedures that are specific to the steering system and type of failure. It is very important to follow the correct procedure to avoid damage to the engine cowlings if a steering system failure occurs.

Refer to the engine manufacturer owner's manuals for specific information on the operation, maintenance and emergency procedures for the steering system installed in your boat.



Typical Helm



External Electronically Controlled Steering Pumps



Helm Master Engine Mounted Electron Steering

Tilt Steering Wheel

The steering wheel can be tilted to five different positions by activating the tilt lock lever located on the bottom of the helm station. When the lever is released, it automatically locks the steering wheel at or close to that angle. Refer to the steering manufacturer owner's manual for specific information on the steering system.

4.7 Joystick Controls

A joystick control system is an option on some engine installations with electronic steering. The joystick can only be used at slow speeds. It is engaged by moving the shift and throttle controls to the neutral position and pressing the ON/OFF button on the base of the joystick control or the keypad on the main engine controls. Once activated, the boat moves in the direction the joystick is pushed with the engine speed increasing the further the stick is pushed, up to preset limits. Turning the knob on the top of the joystick rotates the boat in the direction the knob is turned. Another button on the joystick or engine control keypad raises the preset engine speed for maneuvering in high winds and/or strong tides.

When the joystick is released, it automatically returns to center, the engines shift to neutral, rotate to the straight ahead position, and the engine speed is reduced to idle. It is deactivated by pressing the ON/OFF button at the base of the joystick or control keypad or by moving the shift and throttle control levers.

Both engines must be running for the joystick control to maneuver boat properly.

Always refer to the engine manufacturer owner's manuals for specific information on the operation and maintenance for the joystick and steering control systems on your boat.



Typical Tilt Steering Wheel



Typical Joystick

DANGER

SOME JOYSTICKS AND ELECTRONIC CONTROL SYSTEMS ARE EQUIPPED WITH A FEATURE WHICH USES THE ENGINES TO AUTOMATICALLY HOLD THE BOAT IN POSITION. THIS FEATURE CAN CAUSE SERIOUS INJURY OR DEATH TO PERSONS SWIMMING NEAR THE BOAT OR ATTEMPTING TO BOARD WHEN IT IS ACTIVATED.

WHEN THE POSITION HOLDING FEATURE IS ACTIVATED: THE PROPELLERS ROTATE AUTOMATICALLY; PROPELLER ROTATION MAY NOT BE OBVIOUS; THE BOAT MAY SUDDENLY MOVE IN ANY DIRECTION; THE PROPELLERS CAN INJURE PEOPLE IN THE WATER ANYWHERE AROUND THE BOAT.

IF YOUR BOAT IS EQUIPPED WITH A POSITION HOLDING FEATURE, THE FOLLOWING PRECAUTIONS APPLY:

ALWAYS ASK THE CAPTAIN BEFORE ENTERING THE WATER.

UNLESS THE CAPTAIN GIVES YOU PERMISSION: DO NOT GO IN THE WATER; WIND OR WATER CURRENT CAN MOVE SWIMMERS INTO THE PROPELLERS. DO NOT SIT OR STAND WHERE YOU COULD FALL OVERBOARD; YOU MAY LOSE YOUR BALANCE IF THE BOAT MOVES SUDDENLY.



Typical Trim Tab Switches

4.8 Trim Tabs

The recessed trim tabs are mounted to the hull below the swim platform and integrated transom engine mounting system. A dual rocker switch is used to control the trim tabs. The switch controls bow up and down movements. It also controls starboard and port up and down movements. Bow up and bow down will control the hull planing attitude, while port and starboard up and down provides control for the hull listing.

A LED indicator built into the switch displays the position of the trim tabs. When one LED is flashing at the top of the display, the tabs are in the "full-up" (bow up) position. When all LED lights are lit from the top to the bottom of the display, the tabs are fully extended (bow down).

The trim tabs are programmed to automatically retract when the engines are shutdown to keep the actuators clean and set the tabs in the full "UP" position when leaving the dock. Refer to the trim tab operating manual for more information on the operation and programming of the trim tabs.

Before leaving the dock, make sure that the tabs are in the full "UP" position. If they are not, press and hold the control in the bow up position for ten (10) seconds to fully retract the tabs.

Always establish the intended heading and cruise speed before attempting to adjust the hull attitude with the trim tabs. After stabilizing speed and direction, move the trim tabs to achieve a level side to side running attitude being careful not to over trim.

After depressing a trim tab switch, always wait a few seconds for the change in the trim plane to take effect. Avoid depressing the switch while awaiting the trim plane reaction. By the time the effect is noticeable the trim tab plane will have moved too far and thus the boat will be in an overcompensated position.

When running at a speed that will result in the boat falling off plane, lowering the tabs slightly, bow down, will improve the running angle and operating efficiency. Too much bow down tabs can reduce operating efficiency and cause substantial steering and handling difficulties.

Be extremely careful when operating in a following sea. The effect of trim tabs is amplified under such conditions. Steering and handling difficulties can result from improper trim tab usage, particularly in a following sea. Always raise the tabs to the full bow up position in these conditions.

When running at high speeds be sure that the tabs are in the full "UP" position. Only enough trim plane action should be used to compensate for any listing. Trim tabs are extremely sensitive at high speeds. Adjust for this and be prepared to slow down if difficulties arise.

When running into a chop, a slight bow down attitude will improve the ride. Be careful not to over trim. Handling difficulties may result.



4.9 Control Systems Maintenance

Control Maintenance

Periodic inspection of the control systems and all connections should be made. Signs of rust, corrosion, wear or other deterioration should immediately be serviced. Generally, periodic lubrication of all moving parts and connections with a light waterproof grease is in order.

Lubrication should be performed as often as necessary to keep the system operating smoothly.

Control system adjustments may become necessary. If adjustments become necessary, see your Everglades dealer.

	WARNING	
DO NOT ATTEMPT CONTROL ADJUSTMENTS UNLESS YOU ARE FAMILIAR WITH SERVICING CONTROL SYSTEM PROCEDURES. CONTROL MISADJUSTMENT CAN CAUSE LOSS OF CONTROL AND SEVERE ENGINE OR LOWER UNIT DAMAGE.		

Hydraulic Steering System Maintenance

A periodic inspection of all steering hoses, linkage and helm assemblies should be made. Signs of corrosion, cracking, loosening of fasteners, excessive wear or deterioration should be corrected immediately.

The fluid level for the hydraulic steering should be checked frequently and maintained at the proper level. The steering fluid level should be maintained at no less than 1/2" below the bottom of the fill plug hole on the reservoir at the helm or hydraulic power assist pump located in the mechanical systems compartment. Only use power steering fluid recommended by the steering system manufacturer when adding fluid.



Generally, periodic lubrication of all moving parts and connections with a light waterproof grease is in order. Check the hydraulic hoses and fittings for chaffing, rub marks and leaks. Replace if necessary. Failure to do so could lead to steering system failure that would result in loss of control. When new or after repairs, hydraulic steering systems may need to have all air purged from the system. Only use hydraulic steering fluid recommended by the steering system manufacturer. Difficult steering and premature seal failure can result if the wrong fluid is used in the steering system. Review the information provided by the steering system manufacturer for proper specifications and details on system service and maintenance.

Electronic Steering and Control Systems Maintenance

Electronic steering and control systems are supplied by the engine manufacturer. The systems have maintenance requirements that are specific to the engines and control options installed in your boat.

You should refer to the engine and controls systems owner's manuals for information and maintenance on the control and steering system installed in your boat. Their recommendations should be followed exactly.

The engine controls and steering systems are fully electronic and activated by micro processors and controlling software in each drive unit. If adjustment becomes necessary do not attempt to address the problem yourself. You should contact your Everglades or outboard engine dealer for assistance.

	WARNING	
IMPROPERLY ADJUSTED ELECTRONIC ENGINE CONTROLS CAN CAUSE LOSS OF CONTROL AND SEVERE ENGINE DAMAGE. IF YOUR CONTROLS ARE NOT OPERATING PROPERLY, DO NOT ATTEMPT CONTROL SYSTEM ADJUSTMENTS YOURSELF. CONTACT YOUR EVERGLADES OR ENGINE DEALER FOR ASSISTANCE AND DO NOT USE THE BOAT UNTIL THE SITUATION IS CORRECTED.		

Engine Lubrication

Refer to the engine owner's manual for maintenance and lubrication instructions for the outboard engines.

Trim Tab Maintenance

The trim tab actuators are electric and require no routine maintenance except to periodically inspect the tab actuators for corrosion or marine growth and test the system to ensure that it is operating properly.

Marine growth can interfere with the proper operation of the trim tab planes and actuators. To reduce problems due to marine growth, always return the trim tabs to the full "UP" position after operating the boat and periodically inspect and clean marine growth from the actuators and planes.

If the boat is kept in the water, the trim tabs must be equipped with a zinc anode to prevent galvanic corrosion. Galvanic corrosion is the corrosion process occurring when different metals are submerged in an electrolyte. Seawater is an electrolyte and submerged metal components must be properly protected. The anodes will need to be changed when they are 75% of their original size. Refer to the Routine Maintenance chapter of this manual for information on maintaining zinc anodes.

To discourage any marine growth on the tabs or actuators, antifouling paint can be applied. When applying paint to the actuator, make sure it is fully retracted. Do not paint the stainless ram above the area that is exposed when retracted. The bottom paint will damage the O-ring seals when



Typical Trim Tab Dual Actuators

the ram is retracted and allow seawater to enter the actuator motor. Contact your dealer or the trim tab manufacturer for information regarding the correct bottom paint for the trim tabs.

Refer to the trim tab owner's manual for additional maintenance information, specifications, troubleshooting and operating instructions.

FUEL SYSTEM

5.1 General

The Gasoline fuel system used in Everglades boats sold in the United States is designed to meet or exceed the emission control standards of the Environmental Protection Agency (EPA) and the requirements of the U.S. Coast Guard, the Boating Industry Association and the American Boat and Yacht Council in effect at the time of manufacture.

All gasoline fuel systems have been factory inspected and pressure tested in accordance with regulations in effect at the time of manufacture. This inspection assures that the system is air tight, leak proof and safe. It is the responsibility of the purchaser to maintain it in that condition. Make frequent inspections to assure that no deterioration or loosening of connections is resulting from vibration.

! **DANGER** !

DO NOT LET THE ODOR OF GASOLINE GO UNCHECKED. ANY ODOR OF GASOLINE MUST BE IMMEDIATELY INVESTIGATED AND STEPS TAKEN TO PROTECT THE BOAT AND ITS OCCUPANTS UNTIL THE PROBLEM IS CORRECTED. IF THE ODOR OF GASOLINE IS NOTED, SHUT OFF ALL ENGINES AND ELECTRICAL EQUIPMENT. INVESTIGATE AND CORRECT THE SITUATION IMMEDIATELY. HAVE ALL PASSENGERS PUT ON PERSONAL FLOTATION DEVICES AND KEEP A FIRE EXTINGUISHER READY UNTIL THE SITUATION IS RESOLVED.

Fuel Withdrawal Tubes

The fuel withdrawal tubes are positioned in the fuel tank to achieve optimum fuel usage, fuel line routing, etc. At certain speeds and hull trim angles, the fuel supply at the withdrawal tank location can increase or decrease accordingly. Be extremely careful when attempting to operate the boat when low on fuel. Though some fuel may be in the tank, the relative trim angle of the boat may cause the fuel to flow away from the withdrawals.

Fuel Gauge

Indicates the amount of fuel in the tank. Due to the mechanical nature of the fuel sender, variations in readings during various speeds of operation may occur. This system is merely a relative indication of the available fuel supply and not a calibrated instrument.



Typical Fuel Fill

Fuel Fill

The fuel tank is vented through the fill fitting and cap. The system is equipped with a "keyless" fuel cap located on the port side gunnel that is marked "GAS." The fuel fill cap is designed to seal out water and allow the fuel tank to vent to the atmosphere when the cap is closed.

The fuel fill is opened by pressing the release button on the side of the cap. After fueling, make sure to close and latch the cap. Be sure to use the proper type and grade of fuel. Refer to the engine owner's manual for additional information.

Fuel Tank Vent

Your boat is equipped with a fuel tank vent system incorporated into the fuel fill. The fuel fill cap is designed to seal out water and allow the fuel tank to vent to the atmosphere when the cap is closed.

While the tank is being filled, air displaced by the fuel escapes through the vent and fuel fill. When the tank is full, special valves incorporated in the vent and fill hoses close and activate the automatic shutoff valve on the marina fuel pump

Fuel System

to prevent the tank from being overfilled and/or fuel from being ejected from the fuel fill/venting. You should never attempt to “top off” the tank after the pump shutoff has activated. The shutoff valves will not allow additional fuel to be added after they close and could be damaged by attempts to force additional fuel into the tank.

After fueling, close and latch the fill cap. Then wash spilled fuel from the areas around the fuel fill if necessary. Residual fuel left on the deck and hull sides can be dangerous and will yellow the fiberglass or damage the striping.

5.2 Outboard Engine Fuel System

The gasoline fuel system has one fuel tank. The starboard engine is supplied by the starboard fuel line and the port engine is supplied by the port fuel line.

There is an on/off valve for each supply line located on the fuel tank near each withdrawal tube. The valves provide a means to turn off the fuel supply to service the fuel system. The fuel valves are accessed through an access plate in the cockpit sole.

Fuel withdrawal lines are equipped with anti-siphon valves where the lines attach to the fuel tanks. These valves prevent gasoline from siphoning out of the fuel tank should a line rupture.



WARNING



DO NOT REMOVE THE ANTI-SIPHON VALVES FROM THE SYSTEM. SHOULD AN ANTI-SIPHON VALVE BECOME CLOGGED, CLEAN AND REINSTALL OR REPLACE. IF A FUEL LINE SHOULD LEAK, ANTI-SIPHON VALVES PREVENT A SUBSTANTIAL AMOUNT OF FUEL FROM FLOWING INTO THE BILGE. ANTI-SIPHON VALVES ARE REQUIRED TO BE INSTALLED IN ALL BOATS EQUIPPED WITH GASOLINE ENGINES BY THE U.S. COAST GUARD.



Yamaha Engine Fuel Filters

Engine Fuel Filters

On most engine installations, the fuel filter for each engine is installed in the stern systems compartment. The filters are accessed through the hatch at the rear of the cockpit sole. The fuel filters for Mercury Verado engines are mounted on each engine. The filters are the water separator type and should be serviced frequently to assure an adequate supply of clean, dry fuel to the engines. It is recommended that the filters are inspected periodically and the elements changed as needed.

There is a primer bulb in each fuel line located near the rear of the hatch that is used to prime the fuel system after service or as required. See Fuel System Maintenance and the engine owner’s manual for additional information regarding fuel filters and the outboard engine fuel system.

Notice:

Clean fuel is especially important in fuel injected engines. The engine manufacturer’s recommendations for fuel filter maintenance must be followed exactly.

Notice:

The procedure to prime the fuel system on outboard engines is specific to the type and model of engines on your boat. You should refer to engine manufacturer owner’s manual for the priming procedure for your engines.

5.3 Diesel Generator Fuel System

The diesel fuel system for the optional generator is completely separate from the gasoline system. The diesel fuel tank is located in the stern bilge below the cockpit and is filled from a fuel fill deck plate on the starboard gunnel labeled "Diesel." The diesel fuel system is not equipped with an anti-siphon valve and there is a fuel return line from the engine that returns unused fuel to the fuel tank.

Proper diesel engine operation requires a good supply of clean, dry diesel fuel. Improper marina fuel storage techniques, limited boat usage, etc. can cause the fuel to become contaminated. Periodically, it may be necessary to pump accumulating water and contaminated fuel from the bottom of the fuel tank. If the generator fuel system on your boat becomes contaminated, contact your dealer or Everglades Customer Service for assistance.

Algae can grow in the accumulated water in diesel fuel tanks. This condition is most prevalent in warm climates. Periodically adding a high quality diesel fuel additive containing an algicide may be required to control algae in your boating area. You should contact your dealer or the generator manufacturer for additional information regarding fuels and additives.

Notice:

Do not allow the generator to sit unused for an extended period with the fuel tank less than full. Changes in temperature and weather conditions can cause condensation in diesel fuel tanks that are less than 3/4 full.

Diesel Fuel Filter

A water separator type fuel filter is mounted near the generator in the aft systems room. Another filter is typically installed on the generator inside the sound shield. Replace the filter cartridges as recommended by the generator manufacturer or as needed.

It is particularly important to monitor the condition of the fuel filters frequently because diesel engines circulate much more fuel than they consume. Because of the volume of fuel that flows through the filters, they typically must be changed at least twice a season or more frequently depending on the quality of the fuel and the hours run. Follow the generator manufacturer's instructions for replacing the filters.



Diesel Fuel Fill



Diesel Fuel Filter

Notice:

Diesel fuel systems may need to be primed after servicing. Refer to the generator owner's manual for information on priming the fuel system.

5.4 Fueling Instructions

WARNING

FUEL IS VERY FLAMMABLE. BE CAREFUL WHEN FILLING THE FUEL TANKS. NO SMOKING. NEVER FILL THE TANK WHILE AN ENGINE IS RUNNING. FILL THE FUEL TANKS IN AN OPEN AREA. DO NOT FILL THE TANKS NEAR OPEN FLAMES.

CAUTION

TO PREVENT DAMAGE TO THE FUEL SYSTEM, USE ONLY A GOOD GRADE OF GASOLINE FOR GASOLINE ENGINES OR DIESEL FUEL FOR DIESEL ENGINES. DO NOT USE FUEL THAT CONTAINS HARSH ADDITIVES OR IS AN ALCOHOL BLEND. ANY DAMAGE DONE TO THE FUEL SYSTEM THAT IS THE RESULT OF USE OF AN ALCOHOL BLEND IS NOT COVERED BY THE EVERGLADES WARRANTY. REFER TO THE ENGINE MANUFACTURER OWNER'S MANUAL REGARDING FUEL REQUIREMENTS FOR YOUR ENGINES.

WARNING

DO NOT CONFUSE THE FUEL FILL DECK PLATES WITH THE WATER OR WASTE PUMP OUT DECK PLATE. THESE PLATES ARE LABELED ACCORDINGLY. THE DIESEL FUEL FILL DECK PLATE IS LOCATED ON THE SAME SIDE OF THE BOAT AS THE WASTE PUMP OUT DECK PLATE AND YOU SHOULD BE CAREFUL NOT TO ACCIDENTLY PUMP DIESEL FUEL INTO THE WASTE HOLDING TANK. IF GASOLINE OR DIESEL FUEL IS ACCIDENTALLY PUMPED INTO THE WATER OR WASTE TANK, DO NOT ATTEMPT TO PUMP IT OUT YOURSELF. WATER AND WASTE PUMPS ARE NOT DESIGNED TO PUMP FUEL AND A FIRE OR EXPLOSION COULD RESULT. CONTACT YOUR DEALER OR THE EVERGLADES CUSTOMER SERVICE DEPARTMENT FOR ASSISTANCE IN HAVING THE FUEL PROFESSIONALLY REMOVED.

Preparing The Boat For Fueling

Use the following procedure to prepare the boat for fueling at a marina fuel pump:

- Make sure the boat is securely moored and all engines are off.
- Make sure all switches are in the OFF position.
- Make sure all passengers leave the boat.
- Close all doors and hatches.

WARNING

GASOLINE FUEL VAPORS THAT ACCUMULATE IN THE BILGE, AFT SYSTEMS COMPARTMENT, ELECTRICAL EQUIPMENT COMPARTMENT OR CABIN WHILE FUELING CAN EXPLODE!! FUEL VAPORS ARE HEAVIER THAN AIR AND CAN ACCUMULATE IF THEY ARE CARRIED BY THE WIND INTO THE BILGE OR CABIN THROUGH OPEN DOORS, HATCHES OR VENTS. ALWAYS CLOSE DOORS AND HATCHES BEFORE FUELING.

- Estimate how much fuel is needed and avoid overfilling the fuel tank.

Fueling The Boat

In order to comply with U.S. EPA emission regulations, boats sold in the United States are equipped with special gasoline fuel systems that reduce the flow of fuel vapors from the fuel system to the atmosphere when fueling operations are complete.

These fuel systems meet U.S. EPA emission standards and are designed to maintain a specific air space at the top of the fuel tank that provides proper tank ventilation and protection for emission control components. Special valves in the fuel tank vent and fill systems and a shutoff valve in marina fuel pump nozzles are designed to automatically stop the fuel flow when the tank is full and maintain this air space.

Notice:



When the fuel tank is full, the shutoff valve in the marina fuel pump nozzle will activate and automatically shut off the flow, indicating that the tank is filled to the maximum level. You should stop filling the tank at this point and never attempt to "top off" the tank. Attempting to "top off" the tank could damage fuel level control valves.

WARNING



STATIC ELECTRICITY GENERATED BY FLOWING FUEL CAN CAUSE A FIRE OR EXPLOSION. TO PREVENT STATIC SPARKS WHEN FILLING THE TANK, MAKE SURE THE NOZZLE IS ALWAYS IN CONTACT WITH THE FUEL FILL OPENING

To fill the fuel tank, follow this procedure:

- The fuel caps are hinged and do not require a key. Press the release button on the side of the cap and swing it open.
- Make sure the nozzle is equipped with an automatic shutoff valve. Then put the nozzle in the fuel fill opening and make sure it stays in contact with the fuel fill fitting during the entire fueling operation.
- Fill the tank until the shutoff valve in the pump nozzle clicks and automatically stops the fuel flow.
- Remove the nozzle and close the cap. Make sure to press down firmly until the cap clicks, indicating that it is secure and the system is sealed.

 **WARNING** 

FUEL TANK CONTENTS CAN BE UNDER PRESSURE. TO AVOID SERIOUS INJURY OR DEATH FROM FIRE OR EXPLOSION, OPEN FUEL CAP SLOWLY IN A WELL VENTILATED AREA. NO SMOKING OR OPEN FLAMES.

 **WARNING** 

SPILLED FUEL CAN CAUSE A FIRE OR AN EXPLOSION. MAKE SURE YOU DO NOT SPILL ANY FUEL. IF A SMALL AMOUNT OF FUEL IS SPILLED ON THE FIBERGLASS, USE A CLOTH TO REMOVE THE FUEL AND PROPERLY DISPOSE OF THE CONTAMINATED CLOTH. IF FUEL IS SPILLED ON THE WATER, EXERCISE EXTREME CAUTION. FUEL FLOATS ON THE SURFACE OF THE WATER AND CAN IGNITE. IF FUEL IS SPILLED INTO THE WATER, IMMEDIATELY EVACUATE THE AREA AND NOTIFY THE MARINA AND THE PROPER OFFICIALS.

Preparing The Boat For Operation

Use the following procedure to prepare the boat for operation when fueling operations are complete:

- Open all hatches, windows and doors.
- Check the fuel compartment and below the deck for fuel odors. If you smell fuel, do not start the engines.

5.5 Fuel System Maintenance

Outboard Gasoline Fuel System

Periodically inspect all primer bulbs, connections, clamps and hoses for leakage, damage or deterioration. Replace as necessary. Spray the valves, tank fuel gauge senders and ground connections with a metal protector.

Frequently inspect and lubricate the fuel fill cap seal with Teflon or silicone grease. The seal prevents water from entering the fuel system through the fuel fill cap and it should be immediately replaced if there is any sign of damage or deterioration.

Contaminated fuel may cause serious damage to your engines. Fuel filters must be checked for corrosion and deterioration frequently. Fuel filters must be changed at least once a season or more frequently depending on the type of engine and the quality of the fuel. Refer to the engine or fuel filter manufacturer's instructions for information on servicing and replacing the fuel filter.

The age of gasoline can effect engine performance. Chemical changes occur as the gasoline ages that can cause deposits and varnish in the fuel system as well as reduce the octane rating of the fuel. Severely degraded fuel can damage the engines and boat fuel tanks and lines. Therefore, if your boat is not being run enough to require at least one full tank of fresh fuel a month, a fuel stabilizer should be added to the gasoline to protect the fuel from degradation. Your dealer or the engine manufacturer can provide additional information on fuel degradation and fuel stabilizers recommended for your engine.

In many states, most gasoline is blended with ethanol alcohol. Ethanol is a strong solvent and can absorb water during periods of storage. You should refer to the engine operating manual for information regarding alcohol blended fuels and how it affects the operation of your marine engine.



Diesel Generator Fuel System



Algae can grow in the accumulated water in diesel fuel tanks. This condition is most prevalent in warm climates. Periodically adding a high quality diesel fuel additive containing an algaecide may be required to control algae in your boating area. Since algae also can grow in accumulated water in the fuel filters, it is important to run the generator for at least 30 minutes after the algaecide has been added so it will be circulated throughout the fuel system. This is even more important during



Fuel System

periods of storage or if the generator is not used enough to require refueling at least once a month.

Severe algae in a diesel fuel system can be extremely difficult and expensive to clean. You should be diligent in monitoring the fuel system by changing the fuel filter as recommended and being alert for signs of algae in fuel that is drained from the filter. Most algae appears as black, carpet like, fibers suspended in fuel and water drained from the filter. Severe cases of algae will produce a black jelly like substance that quickly clogs the filter and starves the engine for fuel.

 WARNING 	
<p>DO NOT DRAIN ANY FUEL INTO THE BILGE WHEN SERVICING THE FUEL SYSTEM. THIS COULD LEAD TO A FIRE OR EXPLOSION.</p>	
<p>AFTER THE FILTER ELEMENTS HAVE BEEN CHANGED, PRIME THE FUEL SYSTEM AND CHECK ALL FITTINGS FOR LEAKS BEFORE AND AFTER STARTING THE ENGINES.</p>	
<p>BEFORE STARTING THE ENGINES, ALWAYS OPEN ALL HATCHES, WINDOWS AND DOORS TO COMPLETELY VENTILATE THE BOAT AFTER SERVICING THE FUEL SYSTEM.</p>	

 WARNING 	
<p>TO REDUCE THE POSSIBILITY OF A FIRE OR EXPLOSION, MAKE SURE ALL ELECTRICAL SWITCHES ARE IN THE "OFF" POSITION BEFORE SERVICING THE FUEL SYSTEM.</p>	

 DANGER 	
<p>AVOID SERIOUS INJURY OR DEATH FROM FIRE OR EXPLOSION RESULTING FROM LEAKING FUEL, INSPECT SYSTEM FOR LEAKS AT LEAST ONCE A YEAR.</p>	

ELECTRICAL SYSTEM

6.1 General

Your Everglades is equipped with 120 volt AC and 12 volt DC electrical systems. The AC system can draw current from one of two sources, either shore power outlets at dockside or the optional generator. The DC system draws current from onboard batteries.

Your boat and engine charging systems are designed for 12 volt wet cell marine batteries, AGM (Absorbed Glass Mat) or gel cell marine batteries. AGM batteries are sealed, maintenance free batteries.

All wires in the electrical systems are color coded to make identifying circuits easier.

6.2 DC System Overview

The 12 volt system is a fairly standard marine system. Your boat is equipped with four batteries, one for each engine and two for the house, generator and electronics. If your boat is equipped with the optional SeaKeeper stabilizing system, it will be equipped with 2 additional batteries dedicated to that system.

The house and engine batteries are located in a battery box below the passenger seat. The system is controlled by three battery switches, one for each engine and one for the house 12 volt accessories, generator and the electronics. The batteries are charged by the engines or a battery charger when connected to shore power or when the generator is operating.


If your boat is equipped with a Seakeeper, there will be two batteries dedicated to that system located in the compartment below the port companion seat. The system is activated by a battery switch and charged by a battery charger in the compartment near the batteries.

Most 12 volt power is distributed to the 12 volt accessories through individual fuses located in the battery switch panel and fuse panels below the helm. All circuit breakers and fuses are labeled by the name of the circuit they protect.

Main circuit breakers near the battery switches protect the primary circuits for the DC main, electronics, windlass, sunshade and amplifiers. Additional fuses near the main circuit breakers protect continuous power circuits for the stereo memory, automatic switches for bilge pumps, shower sump automatic switch, CO monitors, the helm battery switches and the carbon monoxide monitors.

Most 12 volt accessories are operated directly by switches in the helm switch panel, cockpit or the cabin. Most accessory circuits are protected by fuses in fuse panels near the battery switches.

Main breakers or fuses located on each engine protect the ignition systems and gauge panel display. Yamaha engine electrical circuits are protected by fuses located in a fuse panel on the side of the engine. The fuse panel is equipped with a spare fuse for each circuit. Always replace fuses used with the fuse specified by Yamaha or your engine manufacturer. Refer to the engine owner's manual for more information on the fuses, fuse panels or circuit breakers on your engines.





Battery Switches, Emergency Parallel Switch, Main Circuit Breakers & Fuse Panels

6.3 Engine Starting/House Batteries & Battery Switches

The DC electrical system on your boat is designed for absorbed wet cell, absorbed glass mat or gel cell marine batteries. You should not mix the size type or brand of batteries. Always consult your Everglades dealer before changing the type of batteries in your boat.

The batteries should be of the size and capacity recommended by the manufacturer of your engines. These specifications should be considered the minimum size battery required. Refer to the engine owner's manual for additional information on the battery requirements for your engines.

Batteries and Battery Switches

Your boat is equipped with four batteries located in the battery compartment below the passenger seat. There is one battery for each engine and two in parallel for the house, generator and electronics circuits.

There are three remotely activated battery switches and a remotely activated emergency parallel switch located in the battery switch panel. The remote battery switches and emergency parallel switch are activated by special switches in helm. Each battery switch has a manual override that can activate (enable) or deactivate (disable) the switch if the remote switch or relay fails. The manual override is a yellow knob on each battery switch that can be pressed to manually activate



Engine & House Batteries

the switch or rotated to reactivate remote activation of the switch or to lockout the switch in the OFF position when servicing the electrical system. The normal operating position for each switch is the "Enabled" Position. Refer to the instructions printed on each switch and/or the battery switch operating manual for additional information on the remotely activated switches.

Remote Battery Switch Operation

Each battery switch and the emergency parallel switch are controlled by a single switch in the battery switch panel. Slide the label down and press the top of the remote switch to engage the battery switch. A red light will illuminate to indicate that the battery is now ON. To turn off, simply slide the label up and press the bottom of the momentary switch. The red light may not turn off immediately or will slowly fade out if there are

no loads present on the system. This is normal as the capacitors in the system drain.

The engine main and auxiliary charging systems control the charging of the engine and house batteries whenever the engines are operating. The engine batteries can be temporarily connected in parallel by the emergency parallel switch in the helm to provide additional starting current for the engines. The engine and house batteries are also charged by the battery charger when plugged into shore power or when running the generator.

The engine charging systems manage the charging current for the 12 volt system whenever the engines are running. The systems automatically sense the condition of each battery and direct the available current to the batteries that require charging. When the engines are started, the engine alternators start to recharge the batteries. The charging circuits sense the charge and it is split between the batteries, with the lowest batteries receiving the most charge. When the engines are turned off, charging stops and the sensing circuits disconnect the batteries from the charging circuits, thereby automatically isolating the batteries from one another.

When in port or at anchor, the engine switches should be off. Only the battery switch that activates the House circuit and generator should be on. This will keep the engine starting batteries in reserve for starting the engines.

Battery Parallel Switch Operation

A momentary switch in the battery switch panel that activates the circuit that connects the engine starting batteries in parallel for extra battery power while starting the engines. When the switch is pressed, a relay is engaged that connects the engine starting batteries, when the switch is released, the relay is deactivated and the batteries are isolated.

Notice:


Current is supplied to the automatic switches for the bilge pumps when the batteries are connected and the battery switches are off.

Notice:

The manual battery switches completely bypass the remote switches at the helm when they are activated. The circuits cannot be turned off using the remote battery switches if the circuits have been activated by the manual switches.



Remote Battery Switches At Helm



Typical Remote Battery Switch

Electrical System

6.4 SeaKeeper Batteries & Main Switch (Optional)

Seakeeper Battery Bank

The optional SeaKeeper system requires 2 additional batteries and a battery charger dedicated to the operation of the stabilizer system located below the port companion seat. The batteries are the size and capacity recommended by the manufacturer. The location of the batteries may vary, depending on the features and equipment installed on your boat.

A dedicated battery charger recharges the batteries when connected to shore power or while operating the optional generator, which is required when a SeaKeeper is installed.

Remote Battery Switch and Circuit Protection


A panel located below the helm seat includes an ON/OFF switch that activates the battery switch to supply high amperage DC power to the Seakeeper circuit, a heavy duty circuit breaker that protects the circuit for the SeaKeeper cooling pump and a push to reset circuit breaker that protects the circuit for the switch.

To activate the Stabilizing system, make sure the main breaker is on. Slide the label down and press the top of the switch. A red light will illuminate to indicate that the SeaKeeper is on. To turn the system off, slide the label up and press the bottom of the switch. The system will shutdown and the red light will fade out.

Refer to the SeaKeeper operation manual for more information.



Seakeeper Battery Switch & Circuit Breaker Panel



SeaKeeper Battery Switch & Battery Charger



Typical Yamaha Twin Engine Ignition Switch & Start/Stop Buttons

6.5 Ignition Switch Panels

Ignition switch panels are unique to each engine manufacturer and the engine control options selected. The information in this section provides a general overview of the most common ignition system for Yamaha outboard engines.

Your dealer will provide you with the proper starting procedure for your boat at the time of delivery. Additional information for the ignition switch system installed in your boat is located in the engine and control system operating manuals included in your information packet.

Most Everglades boats equipped with twin Yamaha engines are equipped with Command Link Plus® ignition panels that offer advanced technology and durability. This is a “key” activated ignition panel which energizes the ignition system of multiple outboards with only one key.

The START/STOP panel is used in conjunction with the ignition key panel and features lights that indi-

cate when the engines are running and a START/STOP button for each engine. This system greatly simplifies the starting and stopping process of your engines while providing the simplicity and security of a keyed ignition. For convenience and protection, engines can not be restarted while running.

Starting and stopping procedure

Make sure the engines are shutdown with the shift levers in the neutral position and your hand is on the control levers. Turn the ignition key to the ON position to activate the ignition and START/STOP buttons for the engines. Press and release the START/STOP button for the port engine. It is not necessary to hold the button, just press it once and release it. The computer will automatically check all engine systems and start the engine. Once the engine stabilizes, repeat the starting procedure for the starboard engine. Stop the engines by pressing the START/STOP buttons again. Then turn the key switch to OFF and remove the key to deactivate the START/STOP panel and secure the engines.



Helm Accessory Switch Panel

6.6 12 Volt Helm Switch Panel

The main accessory switch panel is located at the helm. Most of the circuit breakers or fuses that protect the accessories are located in the battery switch panel or fuse panels behind the helm.

The switch panel is equipped with push button switches that are labeled for the accessories they control. An LED light in each switch indicates that the circuit is activated.

The switches have built in circuit protection. If a switch senses an overload, it will turn off to protect the circuit and the LED light will turn red to indicate a fault. Press the switch to reset it. If it trips again, find and correct the problem before attempting to activate the accessory again.

The following is a description of the accessories typically controlled by the helm switch panel. Some of the accessories described in this section are optional and may not be installed on your boat.

AUX

Reserved for additional 12 volt accessories.

Horn

A momentary switch that activates the boat horn.

Nav/Anc

Pressing the switch once will activate the navigation lights. Press the switch again to activate the anchor light. Press the switch again to turn the anchor light off.

Fwd Bilge

Manually activates the forward bilge pump located in the forward bilge. The pump moves water out a thru-hull fitting in the hull. The pump is also activated by an automatic switch that is activated whenever the batteries are connected. This pump will run as needed whenever the water in the bilge accumulates high enough to cause the switch to activate and turn off when the water is removed.

Aft Bilge 1

Manually activates the aft bilge pump located in the aft systems compartment bilge near the transom. The pump moves water out a thru-hull fitting in the hull. The pump is also activated by an automatic switch that is activated whenever the batteries are connected. This pump will run as needed whenever the water in the bilge accumulates high enough to cause the switch to activate and turn off when the water is removed.

Aft Bilge 2

Manually activates the aft emergency bilge pump located in the aft systems compartment bilge. The pump moves water out a thru-hull fitting in the hull.

This pump will run to assist the forward and aft bilge pumps if water in the bilge accumulates above the normal operating range of the main bilge pumps or if the main pumps fail to operate. The high water alarm in the helm will sound when this pump is automatically activated to alert the operator of unusually high water in the bilge.

Notice:

The bilge pumps will start automatically when there is sufficient water in the bilge to activate the automatic switch. Each automatic switch is protected by a fuse located near the battery switches and is always supplied current when the batteries are connected.

Shower Pump

Overrides the automatic switch to manually activate the sump pump system for the head compartment shower and air conditioner condensation pan drain system. During normal operation the automatic switch in the sump controls the pump.

Wiper

Activates the windshield wiper.

Washer

A momentary switch that activates the solenoid that sprays water on the windshield washer from the fresh water system.

Notice:

The fresh water system must be activated for the windshield washers to work.

Windshield OPEN/CLOSE

Momentary switches that control the electric actuator for the sliding windshield vent/access panel. Press and hold the OPEN switch to open the panel. Press and hold the CLOSE switch to close panel. The switches automatically return to the OFF position when released.

Refer to the Exterior Equipment chapter for additional information on the operation of the vent/access panel.

Windlass UP/DOWN Switches

Momentary switches that control the windlass which is mounted to the deck forward of the rope locker. Press and hold the UP switch to pull the anchor line in. Press and hold the DOWN switch to pay the anchor line out. The switches automatically return to the OFF position when released.

Helm Light

Activates the red overhead lights above the helm. Press the switch again to turn the lights off.

Deck Lights

Activates the lights below the gunnels that illuminate the cockpit sole. Press the switch once to activate white lights. Turn the switch off/on again for red lights. Turn the switch off/on again for blue lights. Press the switch again to turn the lights off.

Hardtop Lights

Activates the lights in the hardtop. Press the switch once to activate white lights. Turn the switch off/on again for red lights. Turn the switch off/on again for blue lights. Press the switch again to turn the lights off.

Blue and Red lights have less effect on night vision and should be selected if you need to illuminate the helm area and cockpit while navigating at night.

Aft Flood

Activates the overhead light at the rear of the hardtop that illuminates the aft cockpit.

Docking Lights

Activates the lights in the hull on each side of the bow that illuminate the area in front of the boat for better visibility while docking at night.

U/W Lights

Activates the lights in the transom below the waterline. Press the switch once to activate the white lights. Turn the switch off/on again for blue lights. Press the switch again to turn the lights off.

Light Bar (Optional)

Activates the LED light bar at the front of the hardtop that illuminate the area in front of the boat for better visibility while operating the boat at night.

Fresh Water

Activates the pump that supplies water pressure for the fresh water system. The pump is the pressure demand type. A pressure switch automatically controls the water pump when the system is activated and properly primed.

Raw Water

Activates the raw water system pump that supplies the raw washdown hose connector in the cockpit. The pump is the pressure demand type. A pressure switch automatically controls the water pump when the system is activated and properly primed.

Electrical System

Baitwell Pump

Activates the pump that supplies seawater to the baitwell.

Baitwell Recirc

Activates the pump that recirculates the water in the baitwell.

Baitwell Light

Activates the light in the baitwell.

AUX

Reserved for additional 12 volt accessories.

6.7 Additional Switches & Switch Panels

Trim Tab Switch

Located in the helm. This switch controls the trim tab planes located on the transom of the boat. It is protected by a fuse located in the accessory fuse panel near the batteries. Refer to the Helm Control Systems chapter for detailed information on the operation of the trim tab controls.

Engine Trim and Tilt Switches

Located in the helm. These switches are typically installed in the engine throttle and shift controls. They control the trimming and tilting of the engines. Refer to the Helm Control Systems chapter and the engine owner's manual for information regarding the proper use of the tilt and trim switches.

Spot Light (Optional)

Located in the hardtop electronics panel. Controls the spot light that is mounted on the hardtop. It is protected by a fuse located in the accessory fuse panel behind the helm. Refer to the spot light owner's manual for details on operating the control pad.

Awning (Optional)

A momentary switch that activates the actuators that extend and retract the sunshade on the rear of the hardtop. Press and release the top of the switch to extend the sunshade. Press the bottom of the switch to retract the sunshade.

Limit switches in the electric actuators that extend and retract the sunshade will automatically stop the actuators when the sun shade reaches the fully extended or retracted positions.



Typical Trim Tab Switches



Remote Windlass Switch

Windlass Switch

A corded remote switch located in the windlass compartment below a hatch in the deck at the bow. This switch controls the windlass which is mounted in the compartment near the switch. It is protected by a circuit breaker of the type and rating recommended by the windlass manufacturer that is located near the battery switches.

Press and hold the UP switch to pull the anchor line in. Press and hold the DOWN switch to pay the anchor line out. The switches automatically return to the OFF position when released.

Marine Toilet and Waste Discharge Switch Panel

This panel is located in the head compartment. The marine toilet switch is a three position momentary switch that controls the filling and flushing of the toilet.

The waste discharge switch is a key activated, momentary switch located in the head compartment that controls the overboard discharge pump system for the holding tank and marine head system. Monitor the waste level in the tank while pumping and turn the waste discharge switch off immediately when pumping is complete.


The key must be turned off and removed from the switch whenever the discharge pump is not being operated.

SeaKeeper Display Panel (Optional)


The display is the user interface to the Seakeeper. It is used to start, operate, monitor and shutdown the Seakeeper. Sensors, alarms and shutdowns are provided to allow unattended operation.

The display also provides information in the event of an alarm. Alarms cause precession to stop and the Seakeeper to start coasting down.


Refer to the Seakeeper operation manual for more information.



Waste Discharge Switch Panel & Marine Toilet Control Switch



SeaKeeper Control Panel



Main Circuit Breakers & Fuse Panels in the Battery Switch Panels

- | | |
|---|--------------------------|
| 1. Battery Switch Continuous Power Fuse Panel | 4. Accessory Fuse Panel |
| 2. Accessory Continuous Power Fuse Panel | 5. Main Circuit Breakers |
| 3. Accessory Fuse Panel | 6. Battery Switches |

6.8 DC System Circuit Protection


Overview

Power is distributed to most of the 12 volt accessories through circuit breakers and fuses located in the battery switch panel. The "Main" circuit breaker protects primary accessory circuits from an overload.

The circuits for most accessories activated by the switches in the helm switch panel are protected by circuit protection built into the switches. If a switch senses an overload, it will turn off to protect the circuit and the LED light will turn red to indicate a fault. Press the switch to reset it. If it trips again, find and correct the problem before attempting to activate the accessory again.

The fuses are labeled for the accessory circuit they protect. Blank fuse holders are reserved for additional accessories not usually installed by the factory.

If a fuse blows, it must be replaced with a fuse of the same amperage as the original. The fuses are labeled and color coded. Never try to correct a problem with a 12 volt accessory by installing a larger fuse. This could cause the accessory or circuit with a problem to overheat, which could result in an electrical fire.



Color Coded Fuses

CAUTION

PROPER FUSE OR BREAKER PROTECTION MUST BE PROVIDED FOR ALL 12 VOLT EQUIPMENT ADDED. DO NOT OVERLOAD THE ACCESSORY CIRCUIT BREAKERS, FUSE PANELS OR OTHER CIRCUITRY THROUGH ADDITIONAL 12 VOLT EQUIPMENT.

The following is a description of the most common circuit breakers and fuse panels. Some accessory circuit breakers and fuses described in this section provide protection for optional equipment that may not be installed on your boat.

Main Circuit Breakers

DC Power is distributed to the fuse panels, helm switch panel, electronics and other main circuits through heavy duty circuit breakers located in the battery switch panel. These main circuits are deactivated when the house battery switch is off. The breakers are supplied power whenever the House battery switch is on.

Heavy duty breakers are equipped with a red "push to test" button and a black or yellow reset lever. If the circuit breaker is tripped by an overload, the yellow or black lever near the center of the breaker will be visible and pointing downward. Reset the breaker by pushing the lever until it resets and locks in the "ON" position. The circuit breaker can be tested for proper operation by pressing the red test button.

Notice:

If a main circuit breaker trips, always make sure the problem that caused the breaker to trip is found and corrected before resetting the breaker.

The following are the main circuits supplied and protected by heavy duty circuit breakers:

Main

Protects the circuit that supplies 12 volt current to the cabin DC panel, accessory switch panels and most DC accessories in the cabin and cockpit. This circuit is deactivated when the House battery switch is off.

Hardtop

Protects the circuit that supplies 12 volt current to the hardtop accessory circuits. This circuit is deactivated when the House battery switch is off.

Electronics

Protects the main circuit that supplies 12 volt current to the electronics fuse panels below the helm. This circuit is deactivated when the House battery switch is off.

Windlass

Protects the circuit that supplies 12 volt current to the windlass main circuit. This circuit is deactivated when the House battery switch is off.

Amp 1

Protects the circuit that supplies 12 volt current to the stereo amplifier. This circuit is deactivated when the House battery switch is off.



Main Circuit Breakers

Amp 2

Protects the circuit that supplies 12 volt current to the stereo amplifier. This circuit is deactivated when the House battery switch is off.

Optimus Power Steering Main Circuit Breakers

Boats with Optimus electronic steering are equipped with a heavy duty circuit breaker for each engine steering pump in the aft systems compartment. These breakers protect the steering pumps from an overload.

Helm Master Main Circuit Breakers

Boats with Yamaha Helm Master Electronic Steering systems are equipped with a heavy duty circuit breaker for each engine steering pump in the aft systems compartment. These breakers protect the steering pumps from an overload.

Yamaha Main Fuses

Power is distributed to the Yamaha Helm Master Control System through individual heavy duty blade type fuses located near the battery switches. Other engine control and/or charging systems could also be protected by heavy duty fuses. Refer to the engine owner's manual for information on circuit protection and amperage requirements for the engines and controls on your boat.

If a main fuse blows, it must be replaced with a fuse of the same size and amperage as the original. The fuses are labeled and color coded. Never try to correct a problem by installing a fuse with a higher amperage rating. This could cause the circuit with a problem to overheat, which could result in an electrical fire or permanent damage to sensitive engine and control components.

Notice:

Circuit protection for other engines, controls, and steering systems may be different. Refer to the engine owner's manual for information on circuit protection and amperage requirements for the engines and control systems on your boat.

Battery Switch Continuous Power Fuse Panel

Located in the battery switch panel. The fuses in the panel protect the circuits for the remote battery switches that are always active and not turned off by the battery switches. These continuous power circuits are always supplied current when the house batteries are connected.

The following are the circuits supplied and protected by fuses in the battery switch continuous power fuse panel:

Port Battery

Protects the continuous power circuit for the switch that activates the port engine battery switch. This circuit is always supplied current when the house batteries are connected.

STBD Battery

Protects the continuous power circuit for the switch that activates the starboard engine battery switch. This circuit is always supplied current when the house batteries are connected.

House Battery

Protects the continuous power circuit for the switch that activates the house battery switch. This circuit is always supplied current when the house batteries are connected.

EMER Battery


Protects the continuous power circuit for the switch that activates the emergency parallel relay. This circuit is always supplied current when the house batteries are connected.

Spare

Reserved for additional 12 volt accessories.

Accessory Continuous Power Fuse Panel

Located in the battery switch panel. These fuses protect the circuits that are always active and not turned off by the battery switches. The continuous power circuits are always supplied current when the house batteries are connected.



Continuous Power Fuse Panels

The following are the circuits supplied and protected by fuses in the accessory continuous power fuse panel:

Fwd Bilge

Protects the circuit for the automatic switch that activates the bilge pump located in bilge below the cabin sole. An LED light next to the FWD Bilge switch in the helm switch panel will be lit whenever the pump is activated.

Shower

Circuit for the automatic switch that activates the shower and cabin drain sump pump located in the forward bilge.

Aft 1

Protects the circuit for the automatic switch that activates aft bilge pump 1 located in the bilge below the systems compartment. An LED light near the AFT Bilge switch will be lit whenever the pump is activated.

Aft 2

Protects the circuit for the automatic switch that activates the emergency bilge pump located in the bilge below the systems compartment. An LED light near the AFT Bilge switch will be lit whenever the pump is activated.

Alarm

Protects the circuit for the automatic switch that activates the high water alarm. The high water alarm will sound to alert the operator of unusually high water in the bilge.

Stereo Memory

Protects the circuit that supplies continuous 12 volt electrical current to the memory circuit in the stereo.

Spare

Reserved for additional 12 volt accessories.

Electronics and Accessory Fuse Panels

Fuses in panels located in the battery switch panel, hardtop and behind the helm protect the circuits for electronics and other accessories not protected by the helm switches. The fuse panels are supplied power by the Main or Electronics main breakers.

Fuses in the panels protect the individual circuits for electronics or other accessories mounted in the helm and cockpit lounge area of your boat not protected by circuit protection built into the helm switches. Each fuse is labeled by the circuit of the accessory or electronics equipment they protect. The fuses in your boat will vary, depending on the equipment and optional equipment selected.

Generator Fuse Panel

A fuse panel is typically installed on the generator near the controls to protect the DC circuits.



Accessory Fuse Panels



Electronics Fuse Panels Below Helm

Electrical System

6.9 120 Volt AC Electrical System

Overview

The AC electrical system is supplied 120 volt, 60 cycle current by 30 amp shore power inlets at dockside or by the generator. It is wired totally separate from the 12 volt DC system and is equipped with an onboard isolation system.

There are one or two 30 amp inlet plugs, depending on the options selected, mounted on the starboard deck, just forward of the windshield. The SHORE inlet (Shore 1) for the 120 volt AC system and the HVAC inlet (Shore 2) for the optional cabin and cockpit air conditioning systems.

Notice:

If the optional cabin and cockpit air conditioners option is not selected, there will only be one inlet plug and shore power cable.

Main circuit breakers that protect each circuit from the shore inlets to the cabin AC panel and Equipment Leakage Circuit Interrupters (ELCI) are located in the forward storage compartment in the head.

Equipment Leakage Circuit Interrupters provide whole-boat ground fault protection (electrical shock protection from stray current) for the entire AC shore power system. They also protect the system from reverse polarity problems due to an improperly wired shore power supply.

The AC system can be fed by either the shore power inlets or by the optional generator. A SHORE/OFF/GENERATOR selector switch in the AC panel is used to select the source of power desired. All AC accessory circuit breakers should be switched to the OFF position before selecting a different power source.

All AC current is distributed to the AC accessories through individual circuit breakers located in the cabin AC panel. The inlet main breakers protect the system from an overload. All AC outlets in the cabin and cockpit are protected by ground fault interrupters to protect against electrical shock.

While moored dockside, 120 volt AC power should be utilized from dockside power, if available. Cord sets are provided to supply power from the shore power outlets to the boat's 120 volt AC and HVAC systems.



Shore Power Inlet Plugs

⚠ DANGER ⚠

TO REDUCE THE RISK OF ELECTRICAL SHOCK IN WET WEATHER, AVOID MAKING CONTACT WITH THE SHORE CABLES OR MAKING A CONNECTION TO A LIVE SHORE OUTLET. NEVER SPRAY WATER ON ELECTRICAL CABLES WHILE WASHING DOWN DECKS.

TO REDUCE THE POSSIBILITY OF AN ELECTRICAL SHOCK, IT IS IMPORTANT THAT THE AC GROUND SYSTEM IS FUNCTIONING PROPERLY AND THAT A PROPER CONNECTION EXISTS BETWEEN THE SHORE POWER CORDS, THE SHORE POWER INLETS, THE BOAT BONDING SYSTEM AND THE OUTLET GROUND CIRCUITS. IF THERE IS ANY DOUBT ABOUT THE INTEGRITY OF THE GROUND CIRCUIT, A QUALIFIED MARINE ELECTRICIAN SHOULD BE CONTACTED IMMEDIATELY AND AC POWER SHOULD BE DISCONNECTED UNTIL THE NECESSARY REPAIRS ARE COMPLETED.

Recommended procedure for making a shore connection:

Turn the AC shore inlet Main breakers and the SHORE/OFF/GENERATOR selector switch in the cabin AC panel to the OFF position. If the dockside outlets include a disconnect circuit breaker, turn them off as well.

To avoid strain on the cables, make sure they have more slack than the mooring lines. Dress the cables so they cannot be damaged by chafing between the boat and the dock. Make sure the cables don't come in contact with the water and connect them to the boat inlet plugs and then the dockside outlets, making sure the connection plugs include a three-prong plug with a ground



ELCI Panels



Shore Power Inlet Circuit Breakers

wire. Press the cords firmly into the boat inlet plugs until the side locks on the cord snap to the inlet plug. Close the cover on the cord to engage the cover lock. Secure lock rings on the shore connector plugs.

Turn the dockside disconnect circuit breakers to the ON position. Then turn the circuit breakers for the boat inlet connection on and check for proper polarity. If reversed polarity has been achieved, the red "FAULT" light on the ELCI panel will light and the main inlet breaker will automatically trip. If this should happen, make sure the inlet main breakers and SHORE/OFF/GENERATOR selector switch in the cabin AC panel are in the OFF position, then turn the dock power breaker off. If the green "POWER" light illuminates and neither main inlet breaker trips when power is supplied to the panel, polarity is correct and the SHORE/OFF/GENERATOR selector switch on the cabin AC panel can be moved to the "SHORE" position.

After activating the system, check the ELCI panels at the inlet main breakers for faults. The green "POWER" LED should show steady illumination and the red "FAULT" LED should remain off. The ELCI trips and opens the main circuit when there is a ground fault condition. If the red "FAULT" LED is continuously illuminated, the ELCI has tripped due to a ground fault condition. Some faults are self-clearing. Try resetting the ELCI once. If the green LED shows steady illumination and the ELCI does not trip again, the circuit is correct and activated.

If the ELCI continues to trip and the red "FAULT" LED is lit after being reset, there is a problem with

the AC electrical system and it is unsafe to use. Make sure the inlet connection main breakers and the SHORE/OFF/GENERATOR selector switch on the cabin panel are in the "OFF" position and turn the dock power breakers off. Disconnect the shore power supply cords from the boat and notify a qualified marine electrician to check the wiring and correct the problem.

⚠ DANGER ⚠

REVERSED POLARITY AND GROUND FAULT CONDITIONS WILL DAMAGE THE SYSTEM AND EXPOSE PASSENGERS TO ELECTROCUTION HAZARDS THAT WILL CAUSE SEVERE INJURY OR DEATH. THIS CONDITION COULD ALSO CAUSE A FIRE IN THE ELECTRICAL SYSTEM. NEVER OPERATE THE AC ELECTRICAL SYSTEM WITH REVERSED POLARITY OR A GROUND FAULT CONDITION.

⚠ WARNING ⚠

ELECTRIC SHOCK CAN CAUSE SEVERE INJURY OR EVEN DEATH. DO NOT ATTEMPT TO CORRECT THE WIRING YOURSELF. ALWAYS HAVE A QUALIFIED ELECTRICIAN CHECK WIRING.

KEEP CHILDREN AWAY FROM ANY ELECTRICAL CABLES OR EQUIPMENT AND ALWAYS USE GROUNDED APPLIANCES ONBOARD YOUR BOAT.

UNDETECTED FAULTS IN THE AC ELECTRICAL SYSTEM COULD CAUSE THE WATER AROUND THE BOAT TO BECOME ENERGIZED. THIS COULD CAUSE A SEVERE SHOCK OR EVEN DEATH TO SOMEONE IN THE WATER NEAR THE BOAT. NEVER SWIM OR ALLOW SWIMMING AROUND THE BOAT WHEN THE AC SYSTEM IS ACTIVATED BY THE SHORE POWER CONNECTION OR THE GENERATOR.

Disconnecting procedure for shore power connection:

Turn the AC panel accessory breakers and SHORE/OFF/GENERATOR selector switch to the OFF position. Turn the main inlet breakers off then turn the disconnect breakers on the dockside outlets to the OFF position.

Disconnect the cables from the dockside outlets and replace the outlet caps. Disconnect the cables from the boat and close the inlet caps. Store cables.

Equipment Leakage Circuit Interrupter (ELCI)

The ELCI provides whole-boat ground fault protection (electrical shock protection from stray current) for the entire AC shore power system. The ELCI face plates are equipped with TEST and RESET buttons. There are also two LED lights that indicate circuit status. When the 120 volt AC system is activated, the green "POWER" LED should show steady illumination and the red "FAULT" LED should remain off.

The ELCI trips and opens the main circuit when there is a ground fault condition. If the red "FAULT" LED is continuously illuminated, the ELCI has tripped due to a ground fault condition. Some faults are self correcting. If it trips, try resetting the ELCI once. If the green LED shows steady illumination and the ELCI does not trip again, the circuit is OK. If the ELCI continues to trip and the red LED is lit after being reset there is a problem with the AC electrical system and it is unsafe to use. Make sure all main breakers are turned off and notify a qualified marine electrician to check the wiring and correct the problem.

It is important that each ELCI is working properly to provide protection against electric shock. They should be tested at least once each month to ensure proper operation by pressing the TEST/RESET buttons in the faceplate. Refer to the ELCI instructions for the testing procedure.



ELCI Panel

6.10 Cabin 120 volt AC Circuit Breaker Panel

The AC panel is located on the rear cabin bulkhead. The following is a description of the AC panel equipment and the breakers that protect the accessories:

AC Multimeter

The multifunction meter monitors the voltage, current load or frequency for each circuit when the boat is connected to AC power. Buttons below the meter allow you to select display options.

The voltage should be checked each time the AC system is activated. The AC system and accessories can be damaged by voltage that is below 105 volts or above 125 volts. You should monitor the voltage and never operate your AC electrical system if the voltage is below or above this range.

The amp or current load should be monitored particularly when operating the air conditioners and water heater. You should always be aware of the electrical load needed to activate accessories and manage the amperage being supplied so the load can be kept within safe limits. Avoid excessive current load that can overload the circuits or the generator. If you have any questions about managing the power in your boat, contact your authorized Everglades dealer.

The frequency should be monitored when the optional generator is operating. In the United States, AC accessories are designed to operate on a frequency of 60 cycles per second. The generator should be able to maintain this frequency within + or - 3 cycles. Do not operate the AC electrical system if the frequency is not in the proper range.

Refer to the meter owner's manual for more information on the features and operation of the AC Multimeter.

SHORE/OFF/GENERATOR Selector Switch

The shore AC system includes one or two power cords and inlet connectors, depending on the options selected. One cord that supplies Shore main breaker 1 is standard. The other cord is optional and supplies Shore main breaker 2 (HVAC). This switch is used to select the main power source, either shore power or generator.

A power surge can occur when changing or activating the AC power source. The resulting power surge that occurs may cause the inlet main break-



120 Volt AC Panel, SHORE/OFF/GENERATOR Selector Switch, Multimeter & Accessory Circuit Breakers

ers or generator main breaker to trip. To avoid this surge, always turn all AC panel accessory breakers to the OFF position before changing or activating the power source.

When connected to dockside power, turn the switch to the SHORE position to energize the panel. When using the generator, turn the switch to the GENERATOR position to energize the panel. Turn the switch to the OFF position when shore power or the generator are not being used.

Shore 1, Shore 2/HVAC and Generator Main Breakers

The shore inlet breakers in the head storage compartment protect primary 120 volt circuits when SHORE is selected. A main circuit breaker on the generator protects primary 120 volt circuits when GENERATOR is selected. Remember that these breakers are very sensitive. The resulting power surge that occurs when connecting dockside cords or switching the power source may cause a breaker to trip. To avoid this surge, always turn all AC panel accessory breakers off before activating or switching the power source.

Electrical System

Care must be taken when operating the AC system from the optional generator or shore power supply lines. In some situations, it may be possible to overload the generator or shore power circuits if too many AC accessory breakers are activated. Too much amperage being supplied through the panel will cause the Shore main breakers or Generator main breaker to trip and could damage the system. This is particularly important when operating the air conditioners and water heater.

You should always be aware of the electrical load needed to activate accessories and manage the amperage being supplied so the load can be kept within safe limits. If you have any questions about managing the power in your boat, contact your authorized Everglades dealer.

Reversed Polarity Lights

The red lights indicate reverse polarity current supplied to the panel for each circuit. This situation will cause the red light to remain lit. If reverse polarity is achieved, immediately turn off all cabin AC breakers, power selector switch and dockside outlet breakers. Disconnect the power cables from the dockside outlets and notify a qualified marine electrician to check the dockside wiring.

Battery Charger 1 & 2

Supplies electrical current directly to the automatic battery chargers. The battery chargers will charge and maintain the 12 volt batteries simultaneously when activated. They are fully automatic.

There are one or two battery chargers, a 60 amp charger for the engine starting and house batteries and an optional 40 amp charger for the batteries that power the SeaKeeper when this option is installed. The wires that supply DC charging current to the batteries are protected by an internal fuse in the battery chargers and external fuses, one for each battery output wire near the batteries. The external fuses protect the DC charging circuit from the batteries to the charger. The internal fuses in the chargers protect the DC charging circuit from the charger to the batteries. Refer to the battery charger owner's manual for more information on the features and operation of the battery charger.

The charge to the engine batteries can be monitored by using the volt meters in the engine gauge cluster or the meter on the charger. To monitor the engine batteries with the volt meters in the engine gauge cluster, activate the charger and



Typical Battery Charger

turn the engine battery switches on. Turn the ignition switch for each engine to the "ON" position (DO NOT START THE ENGINES) and read the voltage on the volt meter for each engine. If the batteries are in good condition and charging properly, the volt meters will indicate between 12 and 14.5 volts. If the reading is below 12 volts, then the battery is not accepting a charge or the charger is not working properly. Always turn the ignition switches off immediately after the monitoring is complete when using the voltmeters in the engine gauge cluster. The charge to the house or Seakeeper batteries is monitored using the meter on the charger.

Water Heater (Optional)


Supplies electrical current directly to the hot water heater circuit. A thermostat in the water heater control panel automatically controls the water temperature. Before operation, you must have water in the water heater. (See the water heater manual for details)

Outlets

Supplies 120 volt AC electrical current to the cabin Ground Fault Interrupter (GFI) outlets.

Notice:

All AC electrical outlets are provided with ground fault interrupts to protect against electric shock. These outlets should be tested periodically to ensure proper operation by pressing the test/reset buttons in the center of the faceplate. GFI outlets do not protect against short circuits and overloads. This is done by the Outlets breaker on the AC panel.



GFI Outlet Test & Reset Buttons



WARNING



GFI OUTLETS DO NOT PROVIDE 100% PROTECTION FROM ELECTRIC SHOCK. EVEN THOUGH GROUND FAULT INTERRUPTERS PROVIDE PROTECTION BY REDUCING EXPOSURE TIME FROM LINE TO GROUND SHOCK HAZARDS, IT IS STILL POSSIBLE TO RECEIVE AN ELECTRIC SHOCK FROM DEFECTIVE APPLIANCES OR POWER TOOLS AND MISUSED ELECTRICAL EQUIPMENT.

TV/KVH

Supplies 120 volt AC electrical current to the TV and satellite antenna.

AUX

Reserved for additional AC equipment.

Grill (Optional)

Supplies 120 volt AC electrical current to the electric grill in the cockpit.

Refrigerator

Supplies 120 volt electrical current directly to the refrigerator in the cockpit when AC power is available and chosen over the 12 volt power supply. See the refrigerator manual for more information.

HVAC Unit Forward (Optional)

Supplies electrical current to the air conditioner compressor and control panel located in the port console cabin.

HVAC Unit Cockpit (Optional)

Supplies electrical current to the cockpit air conditioner compressor and control panel.

HVAC Pump (Optional)

Supplies electrical current to the seawater pump in the mechanical systems compartment that circulates seawater through the air conditioning units. The pump runs whenever an air conditioning unit is operating.

Notice:

After a certain amount of time without water flow, the air conditioning unit will automatically power down. If this occurs, reset the unit and check for water flow out of the air conditioning thru-hull. Refer to the air conditioner owner's manual for more information.

Electrical System

6.11 Generator (Optional)

The generator is supplied 12 volt power for the ignition and starter motor by the House battery bank and is located in the aft systems compartment. The generator oil and coolant should be checked whenever you check the oil in the main engines.

A switch in the cabin generator control panel controls the starting, running and stopping of the generator. Lights or an LED screen in the panel monitor engine temperature, exhaust temperature and oil pressure.

The generator can also be operated from a control panel on the generator. The circuit breakers and fuses that protect the generator AC and DC circuits are also on this panel or on the side of the panel control box. An owner operator's manual for the generator has been supplied with this manual. Please refer to it for details on generator operation and circuit protection.

The generator engine uses a closed cooling system with a seawater-cooled heat exchanger. A sacrificial anode in the seawater cooling system protects generator components that are in contact with seawater. There is coolant recovery tank for the engine coolant mounted on the bulkhead near the generator. Make sure the fluid level in the coolant recovery tank is kept between the maximum and minimum lines of the tank. **You should also check the exhaust port for water flow each time the generator is started.** If there is no discharge within thirty seconds, shut down the generator, then find and correct the problem.

The seawater cooling system includes a strainer that prevents debris in the seawater from entering the cooling pump. The strainer and a seacock



Generator



Generator Onboard Control Switch & Engine Monitor, Fuses & Circuit Breaker



Cabin Generator Control Switch & Monitor

valve is located in the mechanical systems compartment bilge near the generator. It is important to check and clean the strainer regularly to ensure the seawater system can circulate enough water to provide cooling for the closed cooling and exhaust systems on the generator. You should also make sure the generator seacock valve is open and

check the exhaust port for water flow each time the generator is started. If there is no discharge within thirty seconds, shut down the generator and find and correct the problem.

Refer to the Raw Water Systems Maintenance section in the Raw Water System Chapter of this manual for instructions on cleaning the generator sea strainer.

Notice

The generator may not be able to operate all 120 volt accessories at the same time. POWER MANAGEMENT PRACTICES may need to be observed depending on the AC power load.

Notice:

Generators consume DC electrical current and charge the House batteries just enough to compensate for the DC electrical current the engine requires to operate. Therefore, it is important to activate the battery chargers to maintain the House and Engine batteries whenever the generator is running.

The generator diesel fuel system is different than the fuel system for the main engines. Refer to the Fuel System chapter for more information on generator fuel system.

You also should read the generator owner's manual for detailed information on the safe operation and maintenance of the generator.



Generator Strainer & Seacock



Generator Fuel Filter



DANGER




GENERATOR ENGINES PRODUCE CARBON MONOXIDE WHICH IS A LETHAL, TOXIC GAS THAT IS COLORLESS AND ODORLESS. IT IS A DANGEROUS GAS THAT WILL CAUSE DEATH IN CERTAIN LEVELS. ONLY OPERATE THE GENERATOR IN WELL VENTILATED AREAS AND NEVER OPERATE THE GENERATOR WHILE YOU ARE SLEEPING.

Electrical System

6.12 Bonding System & Galvanic Isolator

Your boat is equipped with a bonding system that interconnects all underwater hardware and thru-hull fittings to ensure that they are of the same electrical potential. Sacrificial anodes are attached to the bonding system at the transom, the engines and could be installed on the trim tab planes if your boat is kept in the water. There is also an anode in the seawater cooling system for the generator. The anodes deteriorate before the other metals, thereby protecting the underwater metals from galvanic corrosion or stray electrical current. Since the anodes are sacrificial, it is important to monitor them and replace them when they have deteriorated to 50 - 75% of their original size. The bonding system is connected to the DC ground and the earth ground wire for the AC electrical system. It provides a path for dangerous short circuits in the AC electrical system to the safety earth ground in the event of a fault in the shore earth ground connection and when the boat is away from the dock.

When the boat is connected to shore power at a marina or city dock, all boats connected to shore power are connected to a common shore safety earth ground connection. This circuit provides essential protection against electrical shock from faults or short circuits in AC electrical equipment and, unfortunately, provides a path for low voltage galvanic current to flow between the bonding system of other boats in the circuit. If one or more of the boats in the circuit has a stray current electrical problem or is not equipped with proper galvanic protection, it will seek protection from your boat's bonding system through the safety ground circuit. This could cause accelerated deterioration of the anodes and/or severe damage to the underwater hardware. To prevent damage from other boats in the circuit, a galvanic isolator is installed in the shore ground circuit that isolates your boat's bonding system from the other boats. It prevents the flow of low voltage galvanic current while still providing a path for dangerous short circuit currents in the AC system to the shore safety ground.



Typical Transom Sacrificial Anode



Typical Seacock Bonding Wire & Connection

6.13 Electrical System Maintenance DC Electrical System Maintenance

At least once a year, spray all exposed electrical components behind the helm, in the transom area and in the plugs with a protector. Removable light fixture lenses should be removed and wiped clean

with a damp cloth and reinstalled. Some LED light fixtures are sealed and not serviceable.

Inspect all wiring for proper support and tight terminals, paying particular attention to portable cords and plugs.

Check all below deck wiring to be sure it is properly supported, that the insulation is sound and that there are no loose or corroded terminals. Corroded terminals should be thoroughly cleaned with sandpaper or replaced, tightened securely and sprayed with a metal and electrical protector. Inspect all engine wiring.

Your boat is equipped with batteries that are installed by your dealer at the time of delivery. Check the electrolyte level in the batteries regularly and add distilled water as necessary. If the batteries are frequently charged by the automatic battery charger, the electrolyte level will have to be checked more often. The correct fluid level in the cells is usually approximately 1/4 to 1/2 inch above the plates. If fluid is needed, fill to the proper level with distilled water. **Do not over fill!**

Notice:

Some batteries are sealed and do not require or allow the inspection of the electrolyte.

Keep the battery tops clean and dry. Dirt and water can conduct electricity from one post to the other causing the battery to discharge.

The battery posts should be kept free of corrosion. Remove the cables and clean the posts and cable clamps with a battery post cleaner or sandpaper as required. Coating the battery posts and cable clamps with Teflon or Silicone grease will protect them and reduce corrosion. Battery cables, both hot and ground, must be replaced when they show signs of corrosion or fraying. Deteriorated cables cause a considerable voltage loss when high currents are drawn, as for starting the engines.

AC Electrical System Maintenance

Periodically inspect all wiring for nicks, chafing, brittleness, improper support, etc. Examine the shore power cords closely for cracks in the insulation and corrosion in electrical connectors. Spraying receptacles and electrical connections with an electrical contact cleaner or a metal and electrical protector will reduce corrosion and improve electrical continuity.

Inspect all wiring for proper support, sound insulation and tight terminals, paying particular



attention to portable appliance cords and plugs. The entire AC circuitry, especially the shore power cords, should be seasonally tested for proper continuity by an experienced electrician. This will detect any shorts, open wires or ground faults.

Ground fault interrupt outlets and ELCI circuits should be tested monthly to ensure proper operation by pressing the test/reset buttons. The polarity indicator system should also be inspected for proper operation.



Generator Maintenance

The engine maintenance required on the generator is similar in many ways to the main engines. The most important factors to the generator's longevity are proper ventilation and maintenance of the fuel system, ignition system, cooling system, lubrication system and the AC alternator.

Maintenance schedules and procedures are outlined in your generator owner's manual. They should be followed exactly.

 **WARNING** 

CORROSION ALLOWED TO BUILD ON THE ELECTRICAL CONNECTORS CAN CAUSE A POOR CONNECTION RESULTING IN SHORTS, GROUND FAULTS OR POOR GROUND CONNECTIONS. ELECTRICAL CONNECTORS SHOULD BE CHECKED AT LEAST ANNUALLY AND CLEANED AS REQUIRED. DO NOT ALLOW CORROSION TO BUILD ON CONNECTIONS.

 **WARNING** 

ELECTRIC SHOCK CAN CAUSE SEVERE INJURY OR EVEN DEATH. THE AC AND DC ELECTRICAL SYSTEMS ALWAYS SHOULD BE DISCONNECTED FROM THE POWER SOURCE BEFORE INSPECTING OR SERVICING THE SYSTEM. NEVER SERVICE ANY COMPONENT OF AN ELECTRICAL SYSTEM WHILE IT IS ENERGIZED.

THE AC AND DC ELECTRICAL SYSTEMS ALWAYS SHOULD BE DISCONNECTED FROM THE POWER SOURCE BEFORE INSPECTING OR SERVICING THE SYSTEM. NEVER SERVICE ANY COMPONENT OF AN ELECTRICAL SYSTEM WHILE IT IS ENERGIZED.

Electrical System

6.14 AC Line Load Estimator

Depending on the AC power load your boat requires and the power available from the shore supply or the generator, you may not be able to operate all 120 volt AC accessories at one time. POWER MANAGEMENT PRACTICES may need to be observed particularly when supplying power from the optional generator. You should be aware of the load each accessory draws and make sure you don't overload the circuit.

The table in this section will assist you in documenting the load AC accessories on your boat

require and managing the electrical load on each circuit. An owner's manual for each AC accessory installed on your boat at the factory has been included with your boat. Additionally, you should make sure you have the manuals for accessories installed by your dealer or that you bring aboard. The specification section of the owner's manual will provide the wattage or amperage the accessory requires. Enter the load requirements in the table provided and use the information as a quick reference tool to calculate the electrical load. If only watts are given in the specifications, divide the watts by the voltage to determine amperage.

Appliances	Start-up Watts/Amps	Running Watts/Amps	Line 1 Amps	Line 2 Amps
Air Conditioner – 1				
Air Conditioner – 2				
Battery Charger				
Blender				
Cockpit Grill				
Coffee Maker				
Computer				
Crock Pot				
Curling Iron				
Electric Blanket				
Fan				
Freezer Plate				
Fry Pan				
Hair Dryer				
Ice Maker				
Iron				
Microwave				
Refrigerator				
Refrigerator				
Space Heater				
Stove – Per Element				
Television - 1				
Television - 2				
Television - 3				
Toaster				
VCR/CD				
Water Heater				
		Line Totals		

FRESH WATER SYSTEM

7.1 General

The fresh water system consists of a potable water tank, distribution lines and a distribution pump. The pump is equipped with an automatic pressure switch and is located near the water tank in the center storage compartment.

⚠	CAUTION	⚠
DO NOT FILL SYSTEM WITH ANYTHING OTHER THAN WATER. SHOULD THE SYSTEM BECOME CONTAMINATED WITH FUEL OR OTHER TOXIC FLUIDS, COMPONENT REPLACEMENT MAY BE NECESSARY.		

⚠	WARNING	⚠
DO NOT CONFUSE FUEL FILL DECK PLATES WITH THE WATER OR WASTE FILL DECK PLATE. THESE PLATES ALSO ARE LABELED ACCORDINGLY. IF GASOLINE IS ACCIDENTALLY PUMPED INTO THE WATER OR WASTE TANK, DO NOT ATTEMPT TO PUMP IT OUT YOURSELF. WATER AND WASTE PUMPS ARE NOT DESIGNED TO PUMP FUEL AND A FIRE OR EXPLOSION COULD RESULT. CONTACT YOUR DEALER OR THE EVERGLADES CUSTOMER SERVICE DEPARTMENT FOR ASSISTANCE IN HAVING THE FUEL PROFESSIONALLY REMOVED AND COMPONENTS OF THE FRESH WATER SYSTEM REPLACED AS NECESSARY.		


7.2 Fresh Water System Operation

Fill the water supply tank slowly through the labeled deck plate located on the port gunnel. After filling the water tank, partially open all faucets. The Fresh Water Pump switch on the helm switch panel should be on. Allow the pump to run until all of the air is purged from the system and a steady stream of water is flowing from each outlet. Next, turn off the faucets one by one. As the pressure builds, the pump will automatically shut off.

When properly primed and activated, the water system will operate much like the water system in a home. An automatic pressure sensor keeps the system pressurized. If the system has been recently filled or has not been used for an extended period, air bubbles may accumulate at the pump and the system may have to be reprimed.



Typical Fresh Water Fill



Fresh Water Pump, Drain Sump & Water Heater

Whenever the boat is left unattended, the Fresh Water Pump switch should be placed in the OFF position.



CAUTION



DO NOT ALLOW THE FRESH WATER PUMP TO RUN DRY. THE FRESH WATER PUMP WORKS ON DEMAND AND WILL NOT SHUT OFF AUTOMATICALLY WHEN THE TANK IS EMPTY. THIS CAN RESULT IN DAMAGE TO THE PUMP. ALWAYS TURN THE FRESH WATER PUMP SWITCH OFF WHEN THE FRESH WATER SYSTEM IS NOT IN USE.

Head Compartment & Cockpit Galley Sinks

The faucets in the galley sink and head compartment are supplied by the fresh water system. They are equipped with hot and cold water (the water heater is optional). To use either sink, make sure the fresh water system is activated, then turn the water on. Adjust the hot and cold water until the desired temperature is obtained. Some minor variations in the water temperature may occur as the pressure pump cycles. If your boat is not equipped with the optional water heater, the sinks will be plumbed with cold water only.

Head and Cockpit Shower

There is a shower located in the head compartment and in the cockpit, near the transom door. Each shower has hot and cold water and a retractable shower head with an on/off valve.

To use the shower, make sure the Fresh Water pump switch in the helm switch panel is on. Then pull the shower head out of the faucet and adjust the hot and cold water faucet until the desired temperature is obtained. Some minor variations in the water temperature may occur as the pressure pump cycles. To conserve water, use the valve on the shower head to turn the water on and off as you shower. If your boat is not equipped with the optional water heater, the showers will be plumbed with cold water only.

Head compartment shower and sink water are drained overboard by the shower sump pump. The pump is automatically controlled by an automatic switch in the sump. The Shower Pump switch in the helm switch panel overrides the automatic switch and provides a means to activate the sump pump manually. After showering, let the cold water flow for a period of time to flush the drainage system of soap residue. It is essential that the shower drain strainer is cleaned regularly and the sump is inspected periodically for accumulated debris that needs to be removed.



Cockpit Galley Sink & Faucet



Head Compartment Sink



Cockpit Shower

The Fresh Water Washdown

A quick-release washdown hose connector is located on the side of the cockpit galley. The connector has an automatic valve that is always closed until the washdown hose is connected. The hose requires a special fitting that snaps into the connector and activates the automatic valve. The cover on the connector should always be in the closed position to keep the connector clean when the washdown hose is not attached. Contact your dealer for information on replacement fittings and hoses.



Make sure the Fresh Water Pump switch in the helm switch panel is on before using the washdown hose and that the hose spray nozzle is off when the fresh water system is activated.



Fresh Water Washdown


7.3 Water Heater (Optional)

The water heater is located in center storage compartment. The 120 volt AC element that heats the water is thermostatically controlled at the heater and activated by a circuit breaker located in the AC panel. A high pressure relief valve protects the system from excessive pressure. To avoid damage to the water heater, always make sure all air is purged from the water heater and lines before activating the water heater breaker. Refer to the water heater owner's manual for additional information.

	CAUTION	
DO NOT SUPPLY CURRENT TO AN EMPTY WATER HEATER. DAMAGE TO THE HEATER WILL RESULT. THE SYSTEM MUST BE FILLED AND PRIMED BEFORE USING THE WATER HEATER.		



Fresh Water Quick Connection



Water Heater

Fresh Water System

7.4 Fresh Water System Maintenance

Information supplied with water system components by the equipment manufacturers is included with this manual. Refer to this information for additional operation and service data.


Routine Maintenance

The following items should be done routinely to maintain your fresh water system:


- Remove the filter screens from the faucet spouts and eliminate any accumulation of debris. A build up of debris can cause the pump to cycle excessively.
- Periodically remove and clean the water strainer located at the intake side of the pressure pump. To clean the strainer, make sure the Fresh Water switch is off. Rotate the strainer bowl counterclockwise to release it. Remove and clean the screen with fresh water. Lubricate the O-ring lightly with Teflon or silicon grease and reinstall the screen and strainer bowl.
- Periodically remove the lid on the cabin drain and shower sump and clean the water strainer.
- Periodically spray the fresh water pump and metal components with a metal protectant.
- The batteries must be properly maintained and charged. Operating the pressure pump from a battery with a low charge could lead to pump failure.
- Add a commercially available potable water conditioner to the water tank to keep it fresh.

Notice:



The fresh water system must be properly winterized prior to winter lay-up. Refer to the section on winterizing for more information.



Fresh Water Pump & Strainer



Typical Fresh Water Pump Strainer Removed for Cleaning

	CAUTION	
THE FRESH WATER PUMP SWITCH SHOULD BE PLACED IN THE "OFF" POSITION WHENEVER LEAVING THE BOAT UNATTENDED OR WHEN THE FRESH WATER SYSTEM IS NOT IN USE.		

Sanitizing the Fresh Water Tank

The fresh water system should be sanitized if it has not been used for a long period or you are unsure of the quality of the water in the system.

The following steps can be used to sanitize the system:

- Activate the system, open all faucets and pump out as much water as you can.
- Make a chlorine solution by mixing two ounces of household chlorine bleach in a gallon of water. This mixture will treat approximately fifteen gallons. If the water tank on your boat is larger or smaller than 15 gallons, then adjust the mixture accordingly. Always mix the chlorine with water in a separate container first and never add straight chlorine to the fresh water tank.
- Fill the water tank half full with fresh water and pour the mixture into the water tank. Top off the tank.

- Activate the system and allow the water to run for about one minute at each faucet. Let the treated water stand for 4-6 hours.
- Drain the system by pumping it dry and flush with several tank fills of fresh water.
- The system should now be sanitized and can be filled with fresh water. If the chlorine smell is still strong, it should be flushed several more times with fresh water.

Notice:

The quality of the water in marine fresh water systems can be questionable and is considered non-potable water. We recommend that you avoid using the water from the fresh water system for drinking and cooking. You should only use bottled water for these purposes.

NOTES

RAW WATER SYSTEM

8.1 General

A raw water manifold located in the mechanical systems compartment bilge supplies seawater to the raw water pumps. The intake for the manifold is equipped with a valve that turns the raw water supply to the manifold on or off. Other valves on the manifold enable the operator to turn the water supply on or off for each individual pump in the system. Always make sure all valves are open before attempting to operate any component of the raw water system.

Priming the System

Make sure the valves are open and the Raw Water Pump switch is on. Run the pressure pump by turning on the raw water washdown hose until all of the air is purged from the system and then turn the hose off. Turn the Baitwell Pump switch on and run the pump until all of the air is purged from the system and turn the pump off.

Make sure the air conditioner seawater pump valve is on, then turn on the forward or cockpit air conditioner. Monitor the discharge fitting for the air conditioning system in the hull side. Water should begin to flow from the discharge fitting within 30 seconds. If water does not flow, the system may have an air lock or debris in the strainer restricting the water flow. Investigate and correct the problem, then restart the air conditioner.

The intake for the raw water manifold is equipped with a scoop and ball valve. If a pump runs but will not prime make sure the valve is open. If the pump still won't prime, it may be air locked. Make sure the valve is open and run the boat at or above 15 M.P.H. Water pressure from the scoop will force the trapped air through the pump and allow it to prime. If this procedure doesn't work, contact your Everglades dealer.

Closing the thru-hull valves before the boat is hauled from the water will help to eliminate air locks in raw water systems. The valves should also be closed whenever you leave the boat unattended.



Raw Water Pressure Pump & Sea Strainer



Raw Water System Manifold & Valves

Notice:

It may be necessary to reprime the raw water system if it is not used for an extended period and at the time of launching.

Raw Water System

8.2 Raw Water System Operation

A high pressure pump, controlled by a pressure sensor, is activated by the Raw Water Pump switch in the helm switch panel. When activated, the pressure switch will automatically control the pump that supplies the raw water hose connector.

As the pressure builds in the system, the pump will shut off. When the system is in use and the pressure drops, the pump will turn on. The water pump is equipped with a strainer between the valve and the pump. The strainer should be checked frequently and cleaned as necessary. Whenever the boat is left unattended, the Raw Water switch should be off.

Washdown Hose Connectors

There are two quick-release raw water washdown hose connections. One is located on the port side of the cockpit and the other is in the windlass compartment at the bow. Each connector has an automatic valve that is always closed until the washdown hose is connected. The hose requires a special fitting that snaps into the connector and activates the automatic valve. The cover on the connector should always be closed to keep the connector clean when the washdown hose is not attached. Contact your dealer for information on replacement fittings and hoses.

Make sure the Raw Water Pump switch in the helm switch panel is on before using the washdown hose and that the hose spray nozzle is off when the Raw Water system is activated.



Raw Water Washdown Connection



Baitwell

8.3 Baitwell

Seawater is provided to the baitwell by a 12 volt circulation pump. The pump is designed to carry a constant flow of water to the well. The pump does not have a pressure sensor and is activated by the Baitwell Pump switch in the helm switch panel. There is also a light that is activated by the Baitwell Light switch.

An overflow built into the drain system automatically controls the water level. Always turn the pump off at the switch panel when the baitwell is not in use.

To fill the baitwell, insert the plug into the drain fitting at the bottom of the well. Make sure the valves on the manifold for the pump and the supply valve in the well are open. Then activate the pump. When the water level reaches the overflow, it will begin to circulate.



Typical Livewell Recirculation Pump

When the recirculating feature is activated by the Recirc Pump switch, a separate pump will recirculate and aerate the water without drawing additional seawater into the system. A valve in the side of the well is used to regulate the flow of oxygen in the water when the recirculating feature is activated.

The raw water manifold intake is equipped with a high speed pickup that will supply water to the baitwell if the supply pump should fail and helps prime the system during normal operation. To supply water to the well using the high speed pickup, make sure the ball valves on the manifold are open and run the boat at a speed above 15 miles per hour. Water will circulate through the well and out the overflow.

To drain the well, turn off the pump and remove the plug in the drain fitting. When the well has completely drained, use the washdown hose to flush it and drain of debris. There is a hook on the side of the well for the drain plug when it is not in use.

The valve at the pump should be closed whenever the baitwell is not in use. This will prevent water from entering the well while the boat is cruising.

Notice:

Do not use the baitwell as a dry storage area it is not in use. Seawater could accidentally be delivered to the well from the thru-hull fitting and damage equipment stored there.

8.4 Air Conditioning Pump (Optional)

The forward and cockpit air conditioning units are self-contained and seawater cooled. A 120 volt AC centrifugal pump supplies seawater that cools the condensing units for both air conditions as it circulates through the system and is discharged overboard.

The seawater pump is located in the aft systems compartment and runs whenever the one or both air conditioners are activated. It must be activated by the HVAC Pump circuit breaker in the cabin AC electrical panel whenever the air conditioner is running.



Air Conditioner Sea Strainer

Seawater is supplied to the pump by a valve and hose connected to the raw water manifold. A sea strainer between the pump and valve on the manifold protects the system from contaminants that could damage the pump or the air conditioning system. Make sure the pump receives adequate seawater by periodically cleaning the sea strainer basket. Refer to Raw Water System Maintenance in this chapter for information on cleaning the sea strainer.

You should refer to the air conditioner owner's manual for more information on the operation and maintenance of the seawater pump.

Raw Water System

8.5 Generator Raw Water Supply

The optional generator engine uses a closed cooling system with a seawater-cooled heat exchanger. Seawater circulates through the heat exchanger and is expelled through the generator exhaust system, cooling it as well. It includes a strainer that prevents debris in the seawater from entering the cooling pump. The strainer is located in the stern bilge and supplied seawater by a dedicated thru-hull fitting and seacock valve near the strainer. It is important to check and clean the strainer regularly to ensure the seawater system can circulate enough water to cool the heat exchanger and exhaust system on the generator. Refer to Raw Water System Maintenance in this chapter for information on cleaning the sea strainer.

You should also read the generator owner's manual for detailed information on the safe operation and maintenance of the generator.

8.6 SeaKeeper Cooling Pump

The optional SeaKeeper boat stabilizer is self-contained and seawater cooled. A centrifugal pump supplies seawater that cools specific components in the gyroscope system. The seawater pump is located in the aft systems compartment near the SeaKeeper. It is protected and supplied current by a circuit breaker in the SeaKeeper battery switch panel. The pump is activated automatically whenever the SeaKeeper system is running.

Seawater is supplied to the pump by a valve and hose connected to the sea chest. Make sure the valve is open before activating the pump.

You should refer to the SeaKeeper owner's manual for more information on the operation and maintenance of the SeaKeeper cooling system and seawater cooling pump.

8.7 Raw Water System Maintenance

The following items should be done routinely to help maintain your raw water system:

Routine Maintenance

- Check hoses, particularly the seawater supply lines, for signs of deterioration. Tighten fittings and clamps or replace deteriorated hoses and components as necessary.




Generator Seacock Valve & Strainer

- Periodically remove and clean the water strainer located near the intake side of the washdown pump.
- Periodically remove and clean the water strainers for the air conditioner, generator and SeaKeeper pumps.
- Spray pumps and thru-hull valves with a protective oil periodically.
- The fishbox and baitwell should be drained and cleaned after each use.
- Operate all valves at least once a month to keep them operating properly.

Cleaning the Raw Water Washdown Pump Strainer

- Make sure the Raw Water Pump switch is off.
- Close the intake valve at the raw water manifold.
- Rotate the strainer bowl counterclockwise to release it.



Typical Raw Water Pump Strainer Removed for Cleaning




Raw Water Pump Strainer

- Remove the bowl and pull the screen out. Thoroughly flush the screen and the inside of the strainer to remove foreign matter.
- Lubricate the seal with silicon or Teflon grease and reassemble the strainer, making sure that the strainer bowl is tightened hand tight.
- Open the seawater supply valve and check for leaks.

Cleaning the Generator Sea Strainer

- Turn off the generator.
- Close the generator intake water seacock valve.
- Rotate the strainer cap counterclockwise to release it.
- Remove the cap and pull the screen out. Thoroughly flush the screen and the inside of the strainer to remove foreign matter.
- Lubricate the seal with silicon or Teflon grease and reassemble the strainer, making sure that the strainer cap is tightened hand tight.
- Open the seacock valve and check for leaks.
- Start the generator and inspect the strainer for leaks and proper water flow at the exhaust port. If there is no discharge within thirty seconds, shutdown the generator and find and correct the problem.



Typical Generator Sea Strainer Cap

Raw Water System

Cleaning the Air Conditioner Pump Strainer


- Turn off the air conditioners and deactivate the air conditioner and seawater pump circuit breakers on the cabin AC panel.
- Close the intake valve at the raw water manifold.
- Rotate the strainer bowl counterclockwise to release it.
- Remove the bowl and pull the screen out. Thoroughly flush the screen and the inside of the strainer to remove foreign matter.
- Lubricate the seal with silicon or Teflon grease and reassemble the strainer, making sure that the strainer bowl is tightened hand tight.
- Open the seawater supply valve and check for leaks.
- Activate the air conditioners and monitor the flow of water out of the air conditioner thru-hull fitting in the hull side. If no water is flowing after 30 seconds, shutdown the air conditioners and find and correct the problem.



Typical Air Conditioner & SeaKeeper Pump Strainer

Cleaning the SeaKeeper Pump Strainer

- Turn off the SeaKeeper and turn the Seakeeper battery switch off.
- Close the intake water seacock valve.
- Rotate the strainer bowl counterclockwise to release it.
- Remove the bowl and pull the screen out. Thoroughly flush the screen and the inside of the strainer to remove foreign matter.
- Lubricate the seal with silicon or Teflon grease and reassemble the strainer, making sure that the strainer bowl is tightened hand tight.
- Open the seacock and check for leaks.
- Activate the Seakeeper and monitor the flow of water out of the thru-hull fitting in the hull side. If no water is flowing after 30 seconds, shutdown the Seakeeper and find and correct the problem.



Typical Seawater Speed Scope & Strainer

Intake Scoop Strainer

A thru-hull water intake scoop and strainer provides seawater to the air conditioner seawater pump. This strainer is located on the hull bottom and must be kept free of mud, weeds and other debris.

The strainer should be visually inspected each time the boat is hauled for accumulation of marine growth, weeds and other foreign objects. If clogged or dirty, the strainer should be cleaned.

DRAINAGE SYSTEMS

9.1 General

All water is drained by gravity to overboard thru-hull fittings located in the hull. It is important to check the drain system frequently to ensure it is free flowing and that the hoses on the thru-hull fittings are secure and not leaking.

9.2 Cockpit & Deck Drainage

Cockpit Drains

Your boat has two scupper drains located in the rear of the cockpit. Check valves in each scupper drain thru-hull fitting reduce the surge of seawater through the scuppers and into the cockpit while maneuvering or in rough water.

Water is channeled away from all hatches by a gutter or drain rail system. The water then drains overboard through the overboard drain system.

Cup Holder Drains

All cup holders in the helm and cockpit areas drain by gravity to the cockpit sole or to the bilge.

Rope Locker Drain

The rope locker drains overboard thru a drain hole in the bottom of the locker. It is important to inspect the drain frequently to remove any accumulated debris.

Cockpit and Forward Air Conditioners

The air conditioning condensation pans are drained by a hose attached to the pan that drains the water to the drain sump system.

Bow Storage Compartments

The storage compartments/coolers below the bow seats are drained overboard by gravity to thru-hull fittings in the hull. Drain plugs for each compartment drain fitting are used to control drainage when the compartments are used as coolers.

Cockpit Galley Drains

The sink and refrigerator or ice maker are drained by gravity to a thru-hull drain sump system.



Typical Scupper Drains



Rope Locker Drain Fitting in Hull Side

Drainage Systems

Forward Below Deck Compartment

The forward storage compartment below the cockpit sole is drained by gravity to the bilge.

The hatch drain rail drains by gravity to a thru-hull fitting in the hull.

Lounge Seat Compartment Storage

The storage compartments below the port cockpit lounge area are drained to the cockpit.

Aft Fishbox/Cooler

The aft fishbox/cooler drains by gravity to a thru-hull fitting in the hull.

Baitwell

The baitwell is drained by gravity to a thru-hull fitting in the hull. The overflow drains to the baitwell drain system.

9.3 Hardtop Drains

There is a hole drilled in the leg bases on the frame to prevent water from being trapped within the legs. Additional drain holes are drilled in the tubing to drain other areas as required.

Always make sure the leg drain holes are clear when the boat is laid up for the winter. Water trapped inside the legs could freeze and cause the legs to split.

9.4 Bilge Drainage

There are three bilge pumps, forward, aft bilge 1 and aft bilge 2/emergency. The bilge pumps are activated both manually by switches in the helm station and automatically by water activated switches located next to or near the pump. The automatic switches are connected to the house battery bank. They are protected by fuses in the continuous power fuse panel and remain activated when the battery switches are in the OFF position. The manual switches are supplied current when the HOUSE battery switch is activated.

All bilge pumps pump water out of thru-hull fittings located above the waterline in the hull sides. Aft bilge 1 pump and automatic switch are located near the transom. Aft bilge 2/emergency pump and automatic switch are located just aft of aft bilge 1. The forward bilge pump and automatic switch are located in the forward below deck storage compartment bilge.



Cockpit Galley



Aft Fishbox & Baitwell



Aft Bilge Pumps & Automatic Switches

The manual bilge pump switches should be activated briefly each time the boat is used. This will ensure that the pumps are operating properly and increase the service life of the pumps. The automatic switches should be manually activated periodically to verify operation. This is particularly important before operating the boat offshore.



Aft bilge 2/emergency pump and automatic switch is mounted higher in the bilge than aft pump 1. Aft bilge 2/emergency pump is activated if the bilge water level rises above the normal operating range of the other bilge pumps and automatic switches.

Bilge High Water Alarm

An additional automatic switch will sound an alarm at about the same time the emergency bilge pump is activated if the bilge water level rises above the normal operating range of the other bilge pump automatic switches. The alarm switch is connected to the batteries. It remains activated when the battery switches are in the OFF position and the batteries are connected.

Transom Drain Plug

When the boat is out of the water, the bilge can be drained by a thru-hull drain located in the hull at the transom. The plug should be removed whenever the boat is hauled out of the water and installed just prior to launching. It is important to check the drain plug regularly to make sure it is tight.



	CAUTION	
<p>A LOOSE DRAIN PLUG WILL ALLOW SEAWATER TO ENTER THE BILGE AND COULD CAUSE THE BOAT TO TAKE ON ENOUGH WATER TO DAMAGE EQUIPMENT OR ENDANGER THE CREW. IT IS VERY IMPORTANT TO CHECK THE DRAIN PLUG FREQUENTLY TO ENSURE IT IS PROPERLY TIGHTENED.</p>		

Important:

Any oil spilled in the bilge must be thoroughly removed and properly disposed of before operating the bilge pump. The discharge of oil from the bilge is illegal and subject to a fine.



Bilge High Water Alarm Automatic Switch

	CAUTION	
<p>THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES OR THE WATERS OF THE CONTIGUOUS ZONE IF SUCH DISCHARGE CAUSES A FILM OR SHEEN UPON OR A DISCOLORATION OF THE SURFACE OF THE WATER OR CAUSES A SLUDGE OR EMULSION BENEATH THE SURFACE OF THE WATER. VIOLATORS ARE SUBJECT TO A PENALTY OF \$10,000.</p>		

9.5 Cabin Drainage

Head Sink and Shower

The head compartment sole, sink and shower are drained to the drain sump system located in the below deck storage compartment bilge. The sump system is equipped with a strainer, centrifugal pump and automatic switch. It is activated whenever the House batteries are connected. The Sump Pump switch in the helm switch panel overrides the automatic switch and provides a means to manually activate the sump pump.

Drainage Systems

After showering, it is important to let the cold water flow for a period of time to flush the drainage system of soap residue. Make sure to inspect the sump system regularly and keep the sump components and strainer screen clean.

Console Cabin Sole

The port console cabin sole drains by gravity to the bilge through a drain fitting below the cabin step.

9.6 Drainage System Maintenance

It is essential that the following items be done periodically to maintain proper drainage of your boat:

- Clean cockpit drain rails with a hose to remove debris that can block water drainage.
- Clean the hardtop leg drain holes. This is especially important just before winter lay-up.
- Clean bilge pump strainers of debris and check the bilge for foreign material that can cause the automatic switch to malfunction.
- Frequently test the automatic bilge pump switches for proper operation. This is accomplished by using a garden hose to flood the bilge until the water level is high enough to activate the pumps.
- Frequently test the high water alarm automatic switch for proper operation. This is accomplished by simultaneously holding your fingers on the two recesses on the side of the switch until the alarm is activated.
- Flush each air conditioner condensation pan drain with fresh water at least once each season to remove mold and debris. This is particularly important because mold tends to accumulate in condensation pan drain and, if it is not cleaned regularly, the drain can clog and flood the cabin sole when the air conditioners are operating.
- Flush all gravity drains with fresh water to keep them clean and free flowing.
- Clean and flush coolers and storage boxes with soap or a bilge cleaner and fresh water after each use to keep them clean and fresh.



Drain Sump System



Typical High Water Alarm Automatic Switch & Test Recesses

- Operate all seacock valves at least once a month to keep them operating properly.

Notice:

All drains and pumps must be properly winterized before winter lay-up.

CAUTION

NEVER USE HARSH CHEMICAL DRAIN CLEANERS IN MARINE DRAIN SYSTEMS. PERMANENT DAMAGE TO THE HOSES AND FITTINGS MAY RESULT.

VENTILATION SYSTEM



Windshield Panel Open



Windshield Panel Closed

10.1 Cabin Ventilation

Ventilation to the port console cabin and head compartment is provided by the cabin doors and the optional forward air conditioner. A 12 volt exhaust blower in the head compartment that provides forced ventilation to that area whenever the blower is activated by the switch on the head compartment wall.

10.2 Windshield & Helm Ventilation Windshield & Cockpit Ventilation

Ventilation to the helm area and access to the bow seating is provided by an opening center windshield panel and a walk-thru door below the windshield.

Windshield Center Panel

The center panel is opened and closed by an electric actuator controlled by the Windshield Open/Close momentary switches in the helm switch panel. Each switch automatically returns to the OFF position when it is released.

To open the center section, press and hold the Open switch to slide the panel to the full open position, then release the switch. To close the panel,



Windshield Panel Control Switches

press the Close switch until the panel is completely closed. A limit switch will stop the actuator when the panel reaches the full open or closed position to prevent damage to the panel or the actuator system. Release the switch immediately when panel reaches the full open or closed position and never open the panel part way.



CAUTION




NEVER CLOSE THE WINDSHIELD CENTER PANEL WHEN SOMEONE OR SOMETHING WILL PREVENT FULL CLOSURE. NEVER OPERATE THE OPENING OR CLOSING OF THE PANEL WHILE UNDERWAY.

Ventilation System



Hard Top Access Panels Above Windshield



Vent Panel Quick Release Pin

The actuator mechanism that opens and closes the panel is equipped with a quick release pin on the linkage that allows the operator to release the panel from the actuator if the mechanism malfunctions.

To remove the pin and slide the door manually, remove the access panel in the hardtop liner above the windshield. Locate the pin and pull firmly to remove it.

⚠ WARNING ⚠

THE WINDSHIELD VENT PANEL COULD SLIDE UNEXPECTEDLY WHEN THE QUICK RELEASE PIN IS REMOVED FOR MANUAL OPERATION. THIS CAN RESULT IN SEVERE INJURY TO PASSENGERS AND DAMAGE TO THE PANEL AND TRACK.

MAKE SURE THE SLIDING PANEL IS SECURED IN THE OPEN OR CLOSED POSITION BEFORE OPERATING THE BOAT WITH THE PIN REMOVED.



Walk-Thru Door Open & Nested In Recess

Bow Walk-Thru Door

An acrylic door secured with a flush, push to close latch provides the ability to close off the walk-thru area below the opening windshield panel when desired. The door is designed to "nest" in a recess on the side of the walk-thru when it is open. The latch secures the door in the open or closed position. To secure the door in either position, push the door until the latch catches.

Always make sure the walk-thru door is securely latched in the open or closed position before operating the boat. Periodically clean and lubricate the latches to protect them from corrosion and help keep them operating properly.



Vent Panel & Walk-Thru Door Closed

10.3 Carbon Monoxide & Proper Ventilation

⚠
DANGER
⚠







FAILURE TO PROPERLY VENTILATE THE BOAT WHILE THE ENGINES OR GENERATOR ARE RUNNING MAY PERMIT CARBON MONOXIDE TO ACCUMULATE WITHIN THE CABIN AND OPEN AREAS OF YOUR BOAT. CARBON MONOXIDE IS A COLORLESS AND ODORLESS GAS THAT IS LETHAL WHEN INHALED. CARE MUST BE TAKEN TO PROPERLY VENTILATE THE BOAT AND TO AVOID CARBON MONOXIDE FROM ACCUMULATING IN THE BOAT WHENEVER AN ENGINE IS RUNNING.

A by-product of combustion, carbon monoxide (CO) is invisible, tasteless, odorless and is produced by all engines and gas heating and cooking appliances. The most common sources of CO on boats are gasoline engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping. The hazard also may be created by a boat nearby whose exhaust fumes are entering your boat. Boats also have a problem due to the "station wagon effect" where engine exhaust fumes are captured in the vacuum or low pressure area, usually the cockpit, bridge deck and cabin, that can be created by the forward speed of the boat.

Boats underway should close all aft facing hatches and doors. The forward facing deck hatch should be open whenever possible to help pressurize the living spaces of the boat. No sleeping in the cabin should be permitted while underway. Proper ventilation should be maintained on the bridge deck by opening windshield or forward clear connector panel as far as possible to help pressurize the cockpit area. The canvas drop or aft curtain must be removed and the side curtains should be opened or removed to increase air flow and maintain proper ventilation whenever the engines are running. ***Under no circumstances should the engines be operating with side curtains closed and the aft or drop curtain installed.*** Extreme caution must be taken while at anchor or in a slip when an auxiliary power generator is operating. Wind still nights can easily allow exhaust fumes, containing high concentrations of CO, from the generator on your boat or from an adjacent boat's generator to enter the boat. The exhaust fumes may enter your boat through open hatches or windows.



Typical Carbon Monoxide Detector & Alarm

 <p>Onboard Generator Exhaust - exhaust accumulates because of bulkhead.</p>	 <p>Nearby Generator Exhaust - wind carries exhaust to the other boat</p>
 <p>Back Drafting / Station Wagon Effect - at cruising speed with no forward ventilation</p>	 <p>Back Drafting / Station Wagon Effect - at cruising speed with canvas closed</p>
 <p>Slow Speed or Boat Stopped w/ engines running - CO can accumulate in cabin, cockpit & bridge</p>	 <p>Desired Air Flow Through the Boat</p>

Ventilation System

A carbon monoxide detector has been installed in your cabin as standard equipment. While a CO detector enhances your protection from CO poisoning, it does not guarantee it will not occur. Do not use the carbon monoxide detector as a replacement for ordinary precautions or periodic inspections of equipment. Never rely on alarm systems to save your life, common sense is still prudent and necessary. Remember, the operator of the boat carries the ultimate responsibility to make sure the boat is properly ventilated and the passengers are not exposed to dangerous levels of carbon monoxide. You should always be alert to the symptoms and early warning signs of carbon monoxide poisoning. You should also read the "Carbon Monoxide Monitoring System" in the Safety Equipment chapter of this manual and the owner's manual supplied by the CO detector manufacturer for operation instructions and additional information regarding the hazards and symptoms of carbon monoxide poisoning.



Bilge Free Air & Forced Air Vent



DANGER



ACTIVATION OF THE CARBON MONOXIDE DETECTOR INDICATES THE PRESENCE OF CARBON MONOXIDE (CO) WHICH CAN BE FATAL. EVACUATE THE CABIN IMMEDIATELY. DO A HEAD COUNT TO CHECK THAT ALL PERSONS ARE ACCOUNTED FOR. DO NOT REENTER THE CABIN UNTIL IT HAS BEEN AIRED OUT AND THE PROBLEM FOUND AND CORRECTED.

Periodically test the carbon monoxide alarm per the manufacturer's instructions. Please refer to the carbon monoxide alarm manual or contact the manufacturer for more information on maintaining and calibrating the alarm.

10.4 Bilge & System

Compartment Ventilation

Ventilation to the bilge and systems compartment is provided by air intakes on each side of the cockpit and the port side deck liner, aft of the cockpit near the engines. The ventilation system consists of intake, exhaust ducts and an exhaust blower. The system is designed to meet or exceed the requirements of the United States Coast Guard in effect at the time of manufacture to remove excess heat from the systems compartment while the diesel generator is operating. Additionally, the vents provide air circulation to reduce odors and mildew. Make sure to keep these vents clear and unobstructed.

Free Air System

A flow of air that circulates in and out of the bilge and systems compartment is provided by the vent just aft of the cockpit near the engines and the intake vents. The pressure differential created at the vent as the wind passes over the cockpit provides adequate air movement while operating at or near cruise speeds.

Forced Ventilation



If your boat is equipped with a generator, it will have an electric blower connected to the rear vent that provides forced ventilation to the systems compartment while the generator operating. The in-line blower is activated by a switch in the cabin near the generator control panel and is located in the vent hose just below the vent. Refer to the Electrical Systems chapter for more information on generator and blower operation.

10.5 Maintenance

- Periodically lubricate all hinges and latch assemblies with a light oil.
- Periodically clean and coat gasket materials with silicone to help keep them pliable.
- Periodic inspection and cleaning of the bilge and systems compartment ventilation ducts is necessary to ensure adequate air circulation. A buildup of leaves, twigs or other debris can severely reduce ventilation.
- The bilge blower is permanently lubricated and requires no maintenance. Blower operation can and should be tested by placing a hand over the exhaust vent. Do not rely on the sound of the blower. A substantial amount of air should be exhausted by the blower. Frequently check the vents for obstructions and proper blower operation, preferably before each cruise.

Notice:

Should blower noise become excessive, the source of the noise should be found and corrected before operating the generator.

 WARNING 
OBSTRUCTING THE VENTILATION SYSTEM WILL RESTRICT AIR IN AND OUT OF THE SYSTEMS COMPARTMENT. THE AIR FLOW THROUGH THE AFT FORCED AIR VENT IS IMPORTANT FOR PROPER AIR FLOW VOLUME FOR COOLING WHILE THE GENERATOR IS RUNNING. MAKE SURE THE AIRFLOW OUT OF THIS VENT IS NOT OBSTRUCTED.

NOTES

EXTERIOR EQUIPMENT

11.1 Deck

Rails and Deck Hardware

The rail system and hardware fittings have been selected and installed to perform specific functions. Hand rails are installed to provide a handhold in certain areas of the boat. You should make sure you keep at least one hand on the handholds as you move about the boat.

Fenders or mooring lines should be secured to the cleats and not to rails or stanchions. The cleats on your boat are retractable and flush with the deck when not in use. To use the cleats, pull up on the center of the cleat until it locks in the mooring position.

Be sure a clear lead exists when running dock lines or anchor lines. A line inadvertently run around a stanchion or over the rail could cause damage.

Important:

All fittings must be periodically inspected for loose fit or wear and damage. Any problems should be corrected immediately.



WARNING



EVERGLADES BOATS ARE NOT EQUIPPED WITH HARDWARE DESIGNED FOR TOWING PURPOSES. THE MOORING CLEATS ARE NOT TO BE USED FOR TOWING ANOTHER VESSEL OR HAVING THIS BOAT TOWED.



Retractable Cleat Down



Retractable Cleat Up


11.2 Rope Locker & Windlass

Bow Roller

The bow roller is built into the hull and equipped with hardware that allows the anchor to be operated and stored at the roller. The roller assembly, anchor line and chain binder are concealed below a hatch in the deck. The anchor line is stored in the rope locker and routed out the windlass, through the roller and connected to the anchor chain. A chain binder is provided between the windlass and the roller to secure the anchor. Always make sure the anchor is properly secured by the chain binder when it is in the stored position on the roller.



Bow Roller & Anchor



Windlass, Chain Binder & Cleat

A. Chain Binder

B. Windlass

C. Anchor Line Cleat

D. Bow Roller Assembly

E. Rope Locker

F. Windlass Remote Switch

The chain binder is accessed by opening the hatch and is designed to connect to a link in the anchor chain when the anchor is hauled in. To release the binder, pull the anchor chain in slightly to relieve the tension on the binder, then release the binder from the chain. To secure the anchor in the up and stored position, raise the anchor until it seats firmly in the roller with the chain snug. Attach the chain binder to a link in the chain. Before getting underway after hauling the anchor, always make sure the binder is properly attached to the anchor chain link and the hatch is closed and latched.

Anchor and Rope Locker

The anchor rope locker, windlass and windlass switch are concealed in a recess below a hatch in the deck. A gas spring supports the hatch in the open position. A flush, twist lock latch secures the hatch in the closed position. Always make sure the hatch is closed with the latch in the secured posi-

tion before operating the boat above idle speed. The rope locker and anchor line is accessed through an opening next to the windlass. The anchor line is always stored in the rope locker and there is an eye fitting to secure the bitter end of the anchor line.

The rope locker is designed for the anchor line and not for storing anchors or additional anchor lines. Do not store anchors or any heavy objects in the locker. Anchors and weights for floating markers will bounce and damage the hull or rope locker if they are stored there. They will also interfere with the operation of the windlass. Always store and secure additional anchors and weights in a storage compartment in the cockpit as far aft as possible. The rope locker is drained by a fitting in the hull side near the bottom of the locker. It is very important to check the drain frequently to make sure it is clean and free flowing.

Periodically remove the anchor line from the rope locker, rinse it with fresh water and allow it to dry in the sun. Cleaning the anchor line regularly will reduce odors in the rope locker and increase the life of the line.

The line should also be inspected for abrasions or signs of deterioration. Replace the line if it shows any sign of damage or deterioration. It is important to replace the anchor line with a new line of the type recommended or supplied by the windlass manufacturer.

Windlass

The windlass is mounted in the compartment below the hatch in the deck. The anchor is stored on the roller and is raised and lowered by the windlass. The anchor line is stored in the rope locker and routed out through the windlass to the anchor chain.

The anchor is lowered by releasing it from the chain binder near the roller and operating the WINDLASS DOWN switch at the helm or pressing the down button in the remote windlass switch. The windlass control switches are protected by the circuit breakers built into the helm switches and fuses in the accessory fuse panel in the battery switch panel. The main circuit for the windlass is protected by a heavy duty circuit breaker.

After the anchor is set, the windlass must not be left to take the entire force from the anchor line. Boats lying to their anchor in a high swell or heavy weather conditions will snub on the line. This can cause slippage or apply excessive loads to the windlass. The line should be made fast to the anchor line cleat mounted in the compartment next to the windlass to relieve the load on the windlass.

The anchor is hauled in by releasing the line from the cleat and operating the WINDLASS UP switch at the helm or pressing the up button in the remote windlass switch. Always start the engines before hauling the anchor and motor up to the anchor as the line is retrieved to relieve the load on the windlass.

Once the anchor is retrieved, independently secure the anchor to the chain binder to prevent it from being accidentally released. This is especially important while the boat is under way.



Remote Windlass Switch

The windlass manufacturer provides an owner's manual with its product. It is extremely important that you read the manual and become familiar with the proper care and operation of the windlass. Refer to the Operation chapter for tips on anchoring your boat.



WARNING



THE WINDLASS MUST BE USED WITH CARE. IT IS EXTREMELY IMPORTANT THAT YOU READ THE OWNER'S MANUAL AND BECOME FAMILIAR WITH THE SAFETY INSTRUCTIONS AND PROPER OPERATION OF THE WINDLASS BEFORE USING IT WITH YOUR BOAT. ALWAYS ENSURE THAT LIMBS, FINGERS, HAIR AND CLOTHING ARE KEPT CLEAR OF THE WINDLASS AND ANCHOR LINE DURING OPERATION.

A PARTIALLY LOWERED AND LOOSE ANCHOR CAN CAUSE CONSIDERABLE DAMAGE TO THE HULL. DO NOT USE THE WINDLASS AS A SOLE MEANS OF SECURING AN ANCHOR IN THE BOW ROLLER. ALWAYS SECURE THE ANCHOR TO THE CHAIN BINDER BEFORE OPERATING YOUR BOAT.

Exterior Equipment

Windshield

Your boat is equipped with heavy duty aluminum windshield with tinted glass and a windshield wiper. The center windshield panel opens to provide ventilation and access to the bow seating area.

The windshield wiper should only be used when the windshield is wet. The windshield glass can be scratched by activating the wiper when there is dried salt or dirt on the windshield.

Ventilation to the helm area and access to bow seating is provided by an opening center windshield panel and a walk-thru door below the windshield.

The center panel is opened and closed by an electric actuator controlled by the WINDSHIELD OPEN/CLOSE momentary switches in the helm switch panel. Each switch automatically returns to the OFF position when it is released. Always fully open or close the center windshield section to prevent the possibility of breakage.

To open the center panel, press and hold the OPEN switch to slide the panel to the full open position, then release the switch. To close the panel, press the CLOSE switch until the panel is completely closed. A limit switch will stop the actuator when the panel reaches the full open or closed position to prevent damage to the panel or the actuator system. Release the switch when panel reaches the full open or closed position. Refer to Windshield and Helm Ventilation for additional information on the sliding windshield panel.



Windshield

If the boat is operated in saltwater, the windshield should be washed after each use with soap and water to keep it clean. Saltwater allowed to remain on the windshield frame will eventually begin to attack the aluminum and cause corrosion, usually around fasteners and hardware mounted to the windshield. Snaps or any hardware mounted to the windshield must be properly sealed and isolated with caulk or a Teflon sealer to prevent salty moisture and galvanic corrosion from damaging the frame. Poor maintenance or improperly mounted hardware and snaps can void the warranty on the windshield.

Refer to the Routine Maintenance chapter for more information on the care and maintenance of anodized aluminum.



CAUTION



NEVER CLOSE THE WINDSHIELD CENTER PANEL WHEN SOMEONE OR SOMETHING WILL PREVENT FULL CLOSURE. NEVER OPERATE THE OPENING OR CLOSING OF THE PANEL WHILE UNDERWAY.

11.3 Hull

Engine Mounting System and Swim Platform

Your Everglades is equipped with an engine mounting system that is integrated into the hull and stringer system that is designed to distribute the stresses of engine weight and thrust throughout the entire hull.

The engine hoses and cables or the transom gel coat can be damaged by tilting the engines to the full up position with the engines turned to the wrong position. You should monitor the engines as they tilt to determine best full tilt engine position for your boat.



A swim platform with an anchor locker built into the engine mounting system is standard on your boat.



Ladder Retracted & Secured with Retaining Pin

Stern Boarding Ladder

A telescopic boarding ladder is recessed into the transom below the swim platform. To use the ladder, release the spring loaded retaining pin, pull the ladder out of the recess and rotate it to the down position. Unfold the steps. The ladder must be retracted and secured in the recess before starting the engines.

	WARNING	
<p>MOVING PROPELLERS ARE DANGEROUS. THEY CAN CAUSE DEATH, LOSS OF LIMBS OR OTHER SEVERE INJURY. DO NOT USE THE SWIM PLATFORM OR BOARDING LADDER WHILE AN ENGINE IS RUNNING. STOP THE ENGINES IF DIVERS OR SWIMMERS ARE ATTEMPTING TO BOARD. ALWAYS RETRACT AND PROPERLY SECURE THE LADDER BEFORE STARTING THE ENGINES.</p>		



Typical Stern Ladder Deployed

Unassisted Boarding Situations

When using the stern ladder in an unassisted boarding situation in deep water, release the spring loaded retaining pin. Brace yourself by placing both feet against the transom and pull the ladder out of the recess. Rotate it to the down position and unfold the steps. Use the grab rail, transom eye and ladder to steady yourself while unfolding the steps and boarding. Remember to retract the ladder and secure it in the recess before starting the engines.

Trim Tabs

The trim tabs are recessed into the hull below the transom. The trim tabs are an important part of the control systems. Refer to the Helm Control

Systems chapter for detailed information on the operation of the trim tabs.

Underwater Lights (Optional)

The LED underwater lights are mounted in the transom, below the water line. The lights are activated by the UNDERWATER LIGHTS switch at the helm and should only be used when the boat is in the water with the lights submerged.

Exterior Equipment

Docking Lights (Optional)

Located on each side of the bow. These lights provide lighting forward of the bow while docking or maneuvering in tight quarters at night. They are activated by the DOCKING LIGHTS switch in the helm switch panel and should only be used during docking, mooring or anchoring situations. Never use docking lights while cruising. They are not legal for night navigation and may obstruct the visibility of the bow navigation lights to on-coming vessels.

Heavy Duty Bow Eye (Optional)

The heavy duty towing package includes a heavy duty bow eye. The eye includes a welded stainless steel plate with internal bow reinforcement and backing plates that distribute the force on the bow eye to a larger area of the hull than with the standard bow eye. This option should always be selected if you intend to tow the boat behind a larger vessel.



Docking Lights

⚠ DANGER ⚠

TOWING A BOAT BEHIND A LARGER VESSEL REQUIRES SPECIAL KNOWLEDGE AND SKILL. THE USE OF TOW LINES OR HARDWARE NOT INTENDED FOR TOWING OR RATED FOR THE FORCES EXERTED ON EQUIPMENT DURING THE TOW IS EXTREMELY DANGEROUS AND CAN CAUSE SEVERE INJURY OR DEATH TO PASSENGERS IF THAT EQUIPMENT FAILS. NEVER TOW THE BOAT BEHIND A LARGER VESSEL USING THE STANDARD BOW EYE OR A TOW LINE, HARNESS OR OTHER EQUIPMENT NOT RATED FOR THE EXPECTED LOADS EXPERIENCED DURING THE TOW. IF YOU ARE NOT EXPERIENCED IN TOWING A VESSEL, CONSULT WITH AN OPERATOR AND A MARINE FACILITY EXPERIENCED IN TOWING VESSELS FOR HELP SELECTING PROPER EQUIPMENT AND FOR TRAINING.



Typical Heavy Duty Bow Tow Eye

⚠ CAUTION ⚠

BOATS THAT ARE TOWED BEHIND LARGER VESSELS REQUIRE SPECIAL MAINTENANCE. ATTENTION TO THE ALUMINUM AND STAINLESS STEEL HARDWARE IS ESSENTIAL. SALT SPRAY, SALTY STEAM AND CHEMICALS IN EXHAUST GASES ARE PARTICULARLY CORROSIVE AND WILL DAMAGE THE SURFACE OF STAINLESS HARDWARE OR ANODIZED AND POWDER COATED ALUMINUM. IT IS IMPERATIVE THAT THE BOAT AND HARDWARE ARE CLEANED THOROUGHLY AT THE COMPLETION OF EACH TRIP OR AT THE END OF EACH DAY ON LONG CRUISES TO REDUCE ACCELERATED DETERIORATION AND PREMATURE CORROSION TO ALUMINUM, STAINLESS STEEL AND OTHER COMPONENTS ON THE BOAT.


11.4 Cockpit Features

General



Most hatches and doors in the cockpit are secured with cam action, magnetic or automatic "push to close" latches. Gas charged springs are used on most hatches in the deck and cockpit that help raise the hatches and hold them in the open position.

Some large hatches in the cockpit sole and deck are secured with flush mounted, twist lock latches with handles that store flush to the hatch when they are in the latched position. Always make sure that all hatches are closed with the latches in the secured position before operating the boat above idle speed.

Round access plates located in the sides of the cockpit liner provide access to the fill hoses and fittings. Other access plates in the cockpit sole provide accesses to fuel supply lines, fuel gauge sender and the fuel fill and vent hose connections on the fuel tank.



Typical Twist Lock Latch

	WARNING	
<p>IN CERTAIN CONDITIONS, OPEN EXTERIOR DOORS AND HATCHES THAT ARE NOT SECURED PROPERLY CAN SLAM CLOSED UNEXPECTEDLY AND CAUSE INJURY TO PASSENGERS OR DAMAGE TO THE BOAT. SOME DOORS AND HATCHES ARE EQUIPPED WITH SPECIAL FASTENERS, HATCH LIFTERS, MAGNETIC LATCHES OR SNAPS AND STRAPS TO SECURE THEM IN THE OPEN POSITION. ALWAYS MAKE SURE THAT THESE HATCHES AND DOORS ARE PROPERLY SECURED WHENEVER THEY ARE IN THE OPEN POSITION.</p>		



Transom Door

Transom Door

A door is incorporated into the starboard side of the transom. It is secured by a special latch mounted on the inboard side of the door. The door latch has a push button safety pin. When the transom door is closed, make sure the latch and safety pin are completely engaged to prevent the latch from opening accidentally.

The transom door should only be opened when the boat is not underway. The door must be closed and latched whenever the boat is underway. Never leave the transom door unlatched.

Notice:

Periodically inspect the transom door fittings for wear, damage or loose fit. Any problems should be inspected and corrected immediately.



Transom Door Latch & Safety Lock



WARNING



THE TRANSOM DOOR SHOULD BE CLOSED AND PROPERLY LATCHED WHENEVER THE ENGINES ARE RUNNING. NEVER OPEN THE TRANSOM DOOR WHILE UNDERWAY OR IN ROUGH SEA CONDITIONS. IN CERTAIN SITUATIONS, AN OPEN TRANSOM DOOR COULD ALLOW A SUBSTANTIAL AMOUNT OF WATER TO ENTER THE COCKPIT CREATING A POTENTIALLY DANGEROUS CONDITION.

OPERATING THE BOAT UNDER POWER WITH THE TRANSOM DOOR OPEN MAY ALLOW PERSONS TO FALL OVERBOARD AND INTO BOAT PROPELLERS OR TO BE LOST IN OPEN WATER. ALWAYS CHECK TO MAKE SURE THE TRANSOM DOOR IS PROPERLY CLOSED AND SECURED BEFORE STARTING THE ENGINES AND NEVER OPERATE THE BOAT UNDER POWER WITH THE TRANSOM DOOR OPEN.



Side Utility Door

Side Utility Door

A utility door is located in the starboard hull side. The door makes boarding and exiting the boat much easier in many docking situations.

A magnetic latch in the cockpit holds the door when it is open and a special latch mounted on the inboard side of the door secures it when it is closed. The door latch has a spring loaded safety pin. When the door is closed, make sure the latch is completely engaged and that the safety pin is snapped into place to prevent the latch from opening accidentally.

The door should only be opened when the boat is not in motion with the engines shutdown. The door must be secured in either the open position to the side of the cockpit or in the closed position with the main latch and safety pin. Never leave the side door unlatched.



Utility Door Latch & Safety Pin

Notice:

Periodically inspect the door hinges and hardware for wear, damage or loose fit. Any problems found should be corrected immediately.



WARNING



THE UTILITY DOOR SHOULD BE CLOSED AND PROPERLY LATCHED WHENEVER THE ENGINES ARE RUNNING. NEVER OPEN THE DOOR WHILE UNDERWAY OR IN ROUGH SEA CONDITIONS. IN CERTAIN SITUATIONS, AN OPEN UTILITY DOOR COULD ALLOW A SUBSTANTIAL AMOUNT OF WATER TO ENTER THE COCKPIT CREATING A POTENTIALLY DANGEROUS CONDITION.

OPERATING THE BOAT UNDER POWER WITH THE UTILITY DOOR OPEN MAY ALLOW PERSONS TO FALL OVERBOARD AND INTO BOAT PROPELLERS OR TO BE LOST IN OPEN WATER. ALWAYS CHECK TO MAKE SURE THE UTILITY DOOR IS PROPERLY CLOSED AND LATCHED BEFORE STARTING THE ENGINES. NEVER OPERATE THE BOAT UNDER POWER WITH THE DOOR OPEN.

Aft Bench Seat

Your boat is equipped with a forward facing bench seat in the rear of the cockpit. The seat is designed to fold flush against the cockpit when it is not in use and be flush with the lounge seat when deployed.

To use the seat, pull the top of the seat out of the recess toward the cockpit. The bottom of the seat slides in a track and two side supports move out with the seat as it folds out. The seat automatically locks into the seating position when the cushion reaches the full down position.

To store the seat, pull the seat out slightly as you raise the front. The rear supports will release and slide down in the track as the seat and side supports fold into the recess. Fold the seat in until it is flush with the recess, then push the seat firmly to secure it in the recess.

Cooler/Baitwell

A cooler that can be converted to an optional baitwell is located on the starboard side of the fishbox/cooler at the rear of the cockpit. The hatch is held open by a gas spring and secured with a rotating compression latch with a handle that stores flush with the hatch when it is closed.

When the baitwell option is selected, it is equipped with a light, built in overflow, and recirculation pump. The well drains by gravity to a thru-hull fitting in the hull.

The baitwell is supplied seawater by a dedicated centrifugal raw water pump located in the systems compartment. Another pump mounted to the side of the well can be activated by a switch in the helm panel to recirculate and aerate the water in the baitwell. The overflow built into the side of the baitwell automatically controls the water level.

The baitwell should be drained and rinsed clean after each use. Refer to the Raw Water System and Drainage Systems chapters for more information on the operation of the baitwell.

Stern cooler/Fishbox

An insulated cooler/fishbox is located in the rear of the cockpit. The hatch is held open by gas springs and secured with two rotating compression latches with handles that store flush with the hatch when it is closed. The box drains by gravity to a thru-hull fitting in the hull.



Aft Bench Seat Open



Aft Bench Seat Closed



Cooler/Baitwell & Cooler/Fishbox

Exterior Equipment

Systems Compartment Access

A hatch in the rear of the cockpit provides access to the pumps, strainers and other equipment in the systems compartment. The hatch is held open by gas springs and secured with two rotating compression latches with handles that store flush with the hatch when it is closed.

The latches are designed to pull the pawl against cockpit sole slightly when closed, securing the hatch and compressing the gasket for a more watertight seal. Always make sure the hatch is closed with the latches in the secured position and the handles folded flush before operating the boat above idle speed.

To open the hatch, release the latches by pulling the handles out and rotating them until the latch releases. Then lift the hatch to the full open position. Close the hatch by pushing it to the closed position. Then rotate the latch handles until they are latched in the closed position, securing the hatch firmly to the cockpit sole.

The system compartment is illuminated by an overhead light with a touch activated switch. A dim LED light near the center of the light indicates the location of the switch. Touch the switch once to turn the light on. Touch the switch again to turn it off.

Aft Facing Seat

There is an aft facing seat on the port side of the cockpit on the rear of the passenger seat base. A large storage compartment is located below the seat cushion.

Aft Cockpit Lounge Seat and Table

A lounge seat and table in the cockpit, aft of the passenger lounge seat is an available option. There is a storage compartment below the aft facing lounge seat cushion.

The retractable table converts the lounge area into either a sitting area with a table or a sun lounge. The table is mounted on an adjustable pedestal with cam levers that secure the pedestal in the desired position. A gas charged spring that helps raise the table when the cam levers are released. A folding leaf that provides more room in the cockpit when folded.

To convert the seating area to a sun lounge, fold the leaf out, loosen the cam levers and push down firmly to lower the table to down position. Make



Systems Compartment Hatch



Cockpit Lounge & Table



Table Leaf Folded

sure it is sitting firmly on the support rails in the recess. Install the filler cushion to complete the conversion.

Remove the filler cushion, release the cam levers and raise the table to convert the lounge to a sitting or eating area. Always store the filler cushion in the cabin and out of the weather when it is not being used.

To avoid damage to the table and pedestal, always make sure the table is in the full down position and sitting firmly on the support rails whenever the boat is operating above slow speed. This is particularly important when the boat is being run offshore.



Table Down in Sun Lounge Position

Cockpit Carpet (Optional)

Cockpit carpet is an available option. The carpet is custom fit and includes snaps in the carpet and cockpit sole. For the safety of your passengers, always make sure the carpet is secured with the snaps. Carpet that is not secured can slide unexpectedly.

Helm Seat

The double wide helm seat is equipped with a flip up bolster to provide more room between the seat and the helm. The bolster converts the seat to a leaning post style seat with a backrest and allows the operator to sit or stand at the helm. To convert the seat to a leaning post, lift the front of the seat cushion to raise the bolster and push it back above the seat cushion.



Helm Seat with Bolster in Seat Position

Arm rests on each side of the seats provide a more comfortable position and swing up into the backrest cushion to make it easier to enter and exit the helm area. A molded in footrest on the rear of the helm provides a more comfortable position when the bolsters are set to the seat position.



Helm Seat with Bolster in leaning Post Position

Exterior Equipment

Companion Seat

A forward facing, double wide seat is located on the port side of the cockpit. It is equipped with storage below the seat cushion and a filler cushion that converts the forward facing seat to a lounge.

The filler cushion stores in a recess along side the companion seat. To convert the forward facing seat to a lounge, slide the filler cushion up and out of the recess, then place it on the support rails. Secure it in position with the slide bolt latches with spring loaded safety pins on the front and rear of the cushion. Make sure both slide bolts and safety pins are fully engaged.



Forward Facing Companion Seat & Filler Cushion

CAUTION

THE FILLER CUSHION CAN SLIDE OUT OF THE SUPPORT RAILS IF IT IS NOT SECURED WITH THE SLIDE BOLT LATCHES. THIS COULD RESULT IN INJURY TO PASSENGERS AND DAMAGE TO THE BOAT. ALWAYS MAKE SURE THE FILLER CUSHION IS PROPERLY SECURED WITH THE SLIDE BOLT LATCHES WITH THE SAFETY PINS ENGAGED BEFORE OPERATION THE BOAT.

Helm

The steering, engine controls, engine instruments and switches for exterior equipment and navigation lights are located on the helm station. An area for flush mounted electronics is located forward of the steering and engine controls. The helm is equipped with molded in cup holders and a storage compartment. There are also MP3 and 12 volt accessory plugs on the starboard side. Air conditioning ducts on each side of the helm and on the galley provide cooling to helm and passenger seat area whenever the optional cockpit air conditioning system is operating.

Access hatches in the rear head compartment bulkhead provides access to the back of the helm for servicing equipment and installing electronics or other accessories. There are also fuse panels that provide protection for equipment installed by Everglades or other equipment added by you or dealer.

Overhead Accessory Panel

An overhead accessory panel is built into the hardtop liner above the helm. It is designed to accommodate control panels and small flush mounted electronics like a stereo or VHF radio. Removable hatches in the liner provides access to the inside of the hardtop.



Companion Seat with Filler Cushion Installed



Filler Cushion Slide Bolt Latches

11.5 Cockpit Galley

A galley equipped with a cooler, Faux Granite counter top, sink, slide out basket, refrigerator and storage is located on the rear of the helm seat base. A grab rail is mounted on the starboard side and an electric grill is an available option.

The drawers, slide out basket and compartment doors are secured with lockable, "push to close" latches. To open the drawers, basket or compartment door, pull the handle to release the latch. To close, push the drawers, basket or door in and press against the island until the latch catches.

Fresh Water Sink

The sink is located on the top of the galley. The sink faucet is plumbed to the fresh water system and is drained by gravity to a thru-hull fitting in the hull side above the waterline.

To use the sink, make sure the fresh water system is activated, then rotate the faucet to the operating position. The faucet works like faucets in your home when the fresh water system is activated. Always lower the faucet to the stored position before operating the boat.

Refrigerator

The dual voltage refrigerator operates on 12 volt DC or 120 volt AC power. It will switch to 12 volt DC automatically when AC power is disconnected and the refrigerator is activated. When 120 volt AC current is provided by shore power, the refrigerator automatically switches from DC to AC power.

Care should be exercised while operating the refrigerator on 12 volt power without the engines running. It draws a substantial amount of current and can severely drain the house batteries through extended use. The refrigerator slide out drawers have a special latch to secure the drawers while under way. Make sure the drawers are properly secured whenever the boat is moving.

Refer to the refrigerator owner's manual for additional operating and maintenance instructions.

Electric Grill (Optional)

An electric, stainless steel grill is recessed into the rear counter top. The grill operates on 120 volt AC power only.

To use the grill, make sure the Cockpit Grill circuit breaker in the AC panel is activated. Open the sliding hatch, then use the touch control near



Galley



Galley Fresh Water Sink



Typical Grill Touch Control Panel

Exterior Equipment

the grill to activate the burner and control the temperature. After cooking, be sure the burner is turned off and allowed to cool before closing the hatch. Never close the hatch while the grill is hot. Deactivate the Cockpit Grill circuit breaker whenever the grill is not being used to ensure it is not activated accidentally.

Refer to the grill operating manual for additional information on the proper operation and maintenance of the grill.

Cockpit Air Conditioners (Optional)

The cockpit air conditioning unit is mounted below the helm seat and cockpit galley. It is accessed through a removable vent grill on the forward side of the helm seat base. It is powered by the AC electrical system and equipped with reverse cycle heat so it can be operated as a cooling or heating unit.

To operate, make sure the thru-hull valve for the air conditioning raw water supply pump, located in the systems compartment, is on. Turn the HVAC Unit Cockpit and HVAC Pump breakers in the AC breaker on. The air conditioning or heat then will be controlled by the electronic control panel in the hardtop liner above the helm. When activated, water should continuously flow from the overboard thru-hull fitting in the hull side.

The air conditioning system produces heat when it is operated in the reverse cycle mode. The ability of the unit to produce heat is affected by the temperature of the seawater. As the seawater temperature lowers, the air conditioner's ability to produce warm air decreases. When the seawater temperature drops below 40-45 degrees, the air conditioner will not be able to produce heat. You should not operate the air conditioner to produce heat when the water temperature is below 40 degrees.

The air conditioning unit creates condensation that drips into the pan at the base of the unit. A hose attached to the pan drains the water by gravity to the drain sump system. It is normal for some water to be in the pan whenever the air conditioner has been used. The condensation pan should be checked periodically to make sure it is draining properly.

The drain hose and condensation pan should be flushed clean if it becomes restricted by mold or debris. If the drain becomes plugged, the condensation pan will overflow onto the cockpit sole.



Cockpit Air Conditioner Vent Grill



Typical Air Conditioner Control Panel

The intake line for the pump that supplies sea water to cool the unit is equipped with a sea strainer that must be checked for debris frequently and cleaned as necessary. Refer to the Raw Water System chapter for information on the air conditioning pump and cleaning the sea strainer.

You also should refer to the air conditioner owner's manual for additional operating and maintenance instructions.

Notice:

Air conditioners use surface water as a cooling medium. The boat must be in the water and the raw water supply system properly activated prior to use. After a certain amount of time without water flow, air conditioning units will automatically power down. Always check for proper water flow out of the air conditioning pump discharge thru-hull fitting when the cockpit air conditioner is operating.

11.6 Cabin Doors & Bow Seating Area Opening Windshield Panel

The bow seat area is accessed by opening the center windshield walk-thru panel. The center panel is opened and closed by an electric actuator controlled by the WINDSHIELD OPEN/CLOSE momentary switches in the helm switch panel. Each switch automatically returns to the off position when it is released.

To open the vent, press and hold the OPEN switch to slide the panel to the open position, then release the switch. To close the panel, press the CLOSE switch until the panel is completely closed. A limit switch will stop the actuator when the panel reaches the full open or closed position to prevent damage to the panel or actuator system. Always release the switch immediately when vent panel reaches the full open or closed position.

Refer to the Windshield section of this chapter and the Ventilation chapter for more information on the windshield.

Walk-thru Door

An acrylic door on the side of the walk-thru is used to close off the walk-thru area below the opening windshield panel when desired. It is designed to “nest” into a recess on the port side of the walk-thru when it is open. To secure the door in either position, push the door until the latch catches.

The door could be damaged or hurt a passenger by the motion of the boat if it is allowed to swing free. Always make sure it is latched in either the open or closed position in rough water or when the boat is underway.

Periodically clean and lubricate the latches to protect them from corrosion and help keep them operating properly.



Opening Windshield Vent Panel



Walk-Thru Door

Exterior Equipment

Head and Cabin Compartment Doors

The head compartment and port console cabin doors are made of fiberglass. The doors are hinged and swing open to provide access. It is very important that the doors are closed and latched when not using the cabin or head and whenever the boat is underway. The doors are heavy and could be damaged or hurt a passenger by the motion of the boat if allowed to swing free.

Refer to the Interior Equipment chapter for information on cabin and head compartment equipment and operation.



WARNING



NEVER LEAVE THE HEAD OR CABIN DOOR UNLATCHED. THE DOORS ARE HEAVY AND SWING EASILY. IF A DOOR IS LEFT UNLATCHED, IT COULD SWING UNEXPECTEDLY AS THE BOAT ROCKS, DAMAGING THE DOOR OR CAUSING AN INJURY TO A PASSENGER. TO AVOID INJURY TO PASSENGERS OR DAMAGE TO THE BOAT, ALWAYS CLOSE AND SECURE COMPARTMENT DOORS WHENEVER THE COMPARTMENTS ARE NOT BEING USED, THE BOAT IS IN MOTION OR IN ROUGH WATER CONDITIONS.



Port Console Cabin Door

In-Floor Storage Compartment

There is a large storage compartment located below the cockpit floor between the cabin doors. The fresh water tank and pump, water heater, forward bilge pump, sump pump and macerator discharge pump are among the equipment installed in this compartment.

Access is provided by two hatches in the cockpit sole. A drain rail around the hatches channels water away from the compartment and overboard through a fitting in the hull.

Gas charged springs hold the hatches open and flush twist latches hold them closed. Always make sure the hatches are closed with the latches secured and the handle folded flush to the deck before operating the boat above idle speed.



Head Compartment Door

Bow Seats and Storage Compartments

The bow area is equipped with seats, grab rails and drink holders. The anchor and windlass locker is located just forward of the bow seating area. The area is illuminated by LED lights activated by the courtesy light switches in the helm switch panel.

The bow seat area is equipped with a molded in, rear facing bench seat with a cooler/storage compartment below the seat cushion. There are also forward facing lounge seats with backrests on each side. The bow seat cushions are secured to the hatches with snaps and should be removed and stored when the boat is not being used.



Bow Seating Area & Table



WARNING



PASSENGERS RIDING IN THE BOW SEATING AREA WHILE CRUISING COULD RESTRICT THE OPERATOR'S VISIBILITY. THIS IS A FREQUENT CAUSE OF ACCIDENTS. POSITION PASSENGERS SO THEY DON'T BLOCK THE OPERATOR'S VISIBILITY OR MOVE THEM TO SEATS IN THE MAIN COCKPIT WHILE THE BOAT IS CRUISING.

Cockpit Table

A removable cockpit table mounts to a bracket on the rear side of the bow aft facing bench seat base. A spring loaded pin in the side of the mounting bracket secures the table pedestal in the bracket and prevents it from working loose while the boat is underway. The table is stored in a storage compartment when it is not being used.



Forward Bow Seat Storage/Cooler Compartment

To use the table, remove the table and pedestal from the storage compartment. Pull the safety pin in the side of the mounting bracket and insert the pedestal base firmly in the bracket, then release the pin and make sure it extends into the pedestal base to secure the pedestal to the base. Then install the table on the pedestal. Reverse the process to remove the table.

The table should only be used while running at slow speeds, at the dock or at anchor. Always remove and properly stow the table and pedestal before cruising.



Table Pedestal, Bracket & Spring Loaded Pin



Hardtop

11.7 Hardtop

The standard hardtop consists of a laminated fiberglass top mounted to a powder coated aluminum frame that is bolted to the deck. It is equipped with stereo speakers, LED overhead lighting for the cockpit, and speakers. Two hatches provide additional light for the cockpit and additional ventilation. Removable hatches in the hardtop liner provide access to wiring and rigging for hardtop mounted accessories and antennas.

The outside of the top is equipped with flood lights, navigation lights and an optional spotlight or LED light bar.

The hardtop is not designed to support the additional weight of heavy items like a life raft. GPS, VHF and other electronics antennas must be mounted to the top in the designed locations for antennas. A special mounting location is provided for a radar antenna. The port and starboard legs mounted to the deck aft of the windshield are the wire chase for lights and antennas mounted to the top.

The warranty for the hardtop will be void if the top is modified in any way or heavy accessories

like life rafts are mounted to the top. Additionally, if items like radar antennas, spotlights and other accessories are mounted in the wrong location, the warranty could be void. If you intend to add equipment or make modifications to the hardtop, you should contact Everglades Customer Service or your dealer to make sure the equipment you would like to add or the intended modification will not void the warranty on the top.

Retractable Aft Awning (Optional)

The awning extends to provide shade for the rear cockpit. Electric actuators on each side of the hardtop extend or retract the awning. The actuators are controlled by a switch in the helm switch panel.

The awning switch is a three-position rocker switch. The center position is off. Move the switch in one direction to extend the sunshade. Move the switch in the opposite direction to retract the shade. The switch automatically returns to the off position when it is released. Limit switches built into the actuators automatically stop the sunshade when it is fully extended or retracted.

11.8 Weather Enclosure

Because the aluminum frames vary slightly, the side curtains and drop curtain are custom made to each boat at the factory. To install the curtains, lay them on a soft surface that won't scratch the clear vinyl, mark the top and bottom rope filled hems and unzip the hems from the curtains. Slide the top and bottom hem into the slide tracks on the hardtop and top of the windshield frame. Zip the curtains to the top hems on each side of the top. Then zip the curtains to the bottom hems. Finally, zip the rear of the side curtains to the zippers on the rear frame legs for the hardtop. The side curtains will have to be stretched slightly to pull out the wrinkles and reach the zipper on the windshield.

If you have a drop curtain, slide it into the slide track on the back of the hardtop and attach it to the rear legs.

Notice:

Cold weather can make the clear vinyl material on the curtains stiff and difficult to stretch to the bottom zipper or snaps. This can be particularly difficult with new canvas that has been stored off the boat. Laying the curtains in the sun for 30 minutes during the heat of the day will make installing them much easier in cold weather.

11.9 Aftermarket Hardtop or Tower

Everglades does not recommend installing an aftermarket hardtop, tower or upper control station. An improperly designed or installed fabrication can cause structural damage to the deck structure or hardtop and void the Limited Warranty. Additionally, Everglades will not be responsible for any damage resulting from the installation of a fabrication not installed at the Everglades factory. If you intend to install an aftermarket hardtop, Upper control station or tower on your boat, contact your dealer or Everglades Customer Service.

NOTES

INTERIOR EQUIPMENT

12.1 Head Compartment & Marine Toilet

Overview

The head compartment is located in the starboard console, forward of the helm. It is equipped with a fresh water sink and faucet in the vanity counter top. A retractable shower head is located in a compartment near the vanity. The sink and shower are equipped with hot and cold water. The shower head is equipped with a valve that allows the shower water to be turned on and off without affecting the temperature to conserve water while showering.

A hinged teak seat swings down above the toilet to provide a comfortable place to sit while showering. The seat is flush to the starboard wall when folded up to use the toilet and is secured by a sliding bolt latch with a spring loaded safety pin. Make sure the latch and safety pin are completely engaged when the seat is folded up.

Shower water drains to the sump system where it is pumped overboard. An automatic switch near the sump pump automatically activates and controls the pump while showering.

Ventilation is provided by an exhaust blower and the optional forward air conditioner. There is also a 12 volt overhead light and 120 volt GFI duplex outlet. The light and exhaust blower are activated by switches on the forward bulkhead. The 120 volt outlet is in the storage compartment behind



Head Compartment



Vanity Sink & Storage Compartment



Shower Seat



Vanity Storage Drawer

Interior Equipment

the mirror. The switches that control the toilet and the overboard macerator pump are in a panel on the rear bulkhead.

Vanity Storage Compartments

There are storage cabinets above and below the vanity. There is also a slide out basket in the forward side. The mirror, cabinet doors and drawers are secured with push to release latches that are flush with doors when latched. To open, press and release the knob. The knob will pop out one inch, releasing the locking mechanism and provide a means to pull the door or drawer open. To close, make sure the door or drawer is completely closed and push the knob in. The knob will stay in and the locking mechanism will be activated.



Access Hatches in Rear Bulkhead

Access Doors and Hatches

Hatches with push to close latches in the rear bulkhead provide access to the mounting area for electronics control modules and the back of the helm station to service components. The fuses that protect some 12 volt helm accessories and electronics are located in fuse panels mounted in the compartment behind the lower hatch.

A door with a push to release latch in the forward bulkhead provides access to a storage compartment and the shore main inlet breakers and ELCI panels.



Access Door in Forward Bulkhead

Marine Head System

Your boat is equipped with an electric marine toilet (head) and holding tank as standard equipment. A momentary switch in the head system panel controls the filling and flushing of the toilet. Flush water is supplied by the fresh water system. Before using, make sure the fresh water system is activated and press the flush button briefly to wet the inside of the bowl. After use, press the flush button to activate the toilet macerator pump to discharge the waste to the holding tank and empty the bowl.

Refer to the toilet manufacturer owner's manual for additional information on the operation and maintenance of the marine head.



Marine Toilet

Holding Tank and Overboard Discharge Pump

The holding tank is located in the forward bilge. When the tank is full it must either be pumped out by an approved waste dumping station through the waste deck fitting or be pumped overboard with the macerator discharge pump, when legal to do so. A momentary switch with a key activated lockout is located in the head system switch panel on the

forward bulkhead. The overboard macerator discharge pump and discharge valve are in the forward bilge compartment. The pump discharges holding tank waste to a thru-hull fitting in the hull below the waterline in the same compartment.



To operate the overboard discharge pump, make sure the thru-hull valve is open. Then turn the key switch in the panel on. Press and hold the momentary button next to the key switch to activate the pump. Monitor the fluid level in the holding tank as it is pumped out. When pumping is complete, release the button, close the pump out thru-hull valve and turn the key switch off. Remove the key from the switch and store in a safe location.

Notice:

Monitor the waste level in the holding tank closely as the overboard discharge pump drains the tank and turn the pump off immediately when draining is complete. The macerator discharge pump will be damaged if it runs dry for more than a couple of seconds.

Notice:


In order to comply with current State, Federal and Coast Guard regulations, the pump out thru-hull valve must be closed and the lockout key switch must be off and the key removed whenever the boat is operating in areas in which the discharge of sewage is prohibited.

	CAUTION	
IN MANY AREAS IT IS ILLEGAL TO FLUSH HEAD WASTE DIRECTLY OVERBOARD. VIOLATION OF THESE POLLUTION LAWS CAN RESULT IN FINES OR IMPRISONMENT. ALWAYS KNOW THE LAW FOR THE AREAS IN WHICH YOU BOAT. NEVER DUMP HEAD OR HOLDING TANK WASTE OVERBOARD ILLEGALLY.		


Maintenance

The head should be cleaned and inspected for leaks regularly.

The holding tank should be pumped out and flushed as needed. Always add chemical to the holding tank to help control odor and to chemically break down the waste. See the head manufacturer owner's manual for additional operating and maintenance information.



Waste Discharge Switch & Marine Toilet Control Switch in Head System Control Panel



Overboard Discharge Pump & Thru-Hull Valve in Forward Below Deck Compartment

To reduce odor in the cabin, never allow waste to remain in the holding tank for more than one week. Make sure to add fresh water to the holding tank and pump the tank several times to flush it out during pump out operations.

Important:

The head system must be properly winterized before winter lay-up. Refer to the Seasonal Maintenance chapter and the manufacturer owner's manual for winterizing instructions.



Port Console Cabin



120 Volt AC Panel, Generator Control Panel & Stereo

12.2 Port Console Cabin

The console cabin is located on the port side, forward of the companion seat. It is equipped with lounge seat, entertainment center and air conditioner.

Cabin Light Switches

All lights in the cabin are powered by the DC electrical system. The overhead lights for the cabin are controlled by ON/OFF switches in a panel on the cabin wall near the companionway.

120 Volt AC Breaker Panel

The cabin AC breaker panel, stereo and optional generator control panel are built into the cabinet on the forward bulkhead. Refer to the Electrical Systems chapter for more information on the operation of the components in the AC panel.

TV and entertainment Center

The CD/DVD/player and stereo are built into a cabinet on the forward bulkhead. The TV is in the side bulkhead across from lounge seat. They are activated by circuit breakers in the AC electrical panel.



Cabin Light Switches



Cabin TV

Carbon Monoxide Detector

A carbon monoxide (CO) detector/alarm is installed on the starboard wall. The detector is always activated when the house batteries are connected and is protected by a fuse in the cabin fuse panel. If excess carbon monoxide fumes are detected, an audible beeping will sound indicating the presence of the toxic gas. A green light on the detector indicates that it is activated. Always make sure the green light is on whenever the cabin is occupied.

A by-product of combustion, carbon monoxide is invisible, tasteless, odorless and is produced by all engines and some heating and cooking appliances. The most common sources of CO on boats are the engines, auxiliary generators and propane or butane stoves. These produce large amounts of CO and should never be operated while sleeping.

You should read the owner's manual supplied by the detector manufacturer for operation instructions and additional information regarding the hazards of carbon monoxide gas. Also read more about carbon monoxide, carbon monoxide detectors and proper ventilation in the Ventilation System and Safety Equipment chapters in this manual. This is especially essential since your boat is equipped with a generator as standard equipment. If you did not receive a manual for your carbon monoxide detector, please contact the Everglades Customer Service Department.

⚠
WARNING
⚠

ACTIVATION OF THE CARBON MONOXIDE DETECTOR INDICATES THE PRESENCE OF CARBON MONOXIDE (CO) WHICH CAN BE FATAL. EVACUATE THE CABIN IMMEDIATELY. DO A HEAD COUNT TO CHECK THAT ALL PERSONS ARE ACCOUNTED FOR. DO NOT REENTER THE CABIN UNTIL IT HAS BEEN AIRED OUT AND THE PROBLEM FOUND AND CORRECTED.

12.3 Forward Air Conditioner

The Cabin (forward) conditioning unit is the reverse cycle type and operates on AC power. The unit is equipped with reverse cycle heat and can be operated as a cooling or heating unit. It is protected by a circuit breaker in the AC breaker panel.

To operate the cabin air conditioner, make sure the thru-hull valve for the air conditioner seawater supply pump is on. The valve and sea strainer are located in the systems compartment bilge. Turn



Typical Carbon Monoxide Detector & Alarm



Typical Air Conditioner & Drain

Interior Equipment

the HVAC Unit Forward and HVAC Pump breakers in the AC breaker panel on. The air conditioning or heat then will be controlled by the electronic control panel in the cabin. When activated, water should continuously flow from the overboard discharge thru-hull.

The air conditioning system produces heat when it is operated in the reverse cycle mode. The ability of the unit to produce heat is affected by the temperature of the seawater. As the seawater temperature lowers, the air conditioner's ability to produce warm air decreases. When the seawater temperature drops below 40 - 45 degrees, the unit will not be able to produce heat. You should not operate the air conditioner to produce heat when the water temperature is below 40 degrees.

The cabin air conditioner is located behind the intake vent in the forward cabin storage compartment. The unit creates condensation that drips into the pan at the base of the unit. A hose attached to the pan drains the water to the drain sump system where it is pumped overboard. You should monitor the operation of the sump pump and make sure it is operating properly whenever the air conditioning unit is activated. Air conditioners can produce enough condensation to flood the forward bilge if it is allowed to run for extended periods without the sump pump and forward bilge pump operating properly.

It is normal for some water to be in the condensation pan whenever the air conditioner has been used. The pan should be checked periodically to make sure it is draining properly. The drain hoses and condensation pans should be flushed clean if they become restricted by mold or debris.

The intake line for the seawater pump is equipped with a sea strainer that must be checked for debris frequently and cleaned as necessary. Refer to the Raw Water System chapter for information on the air conditioning pump and cleaning the sea strainer.

You should also refer to the air conditioner owner's manual for additional operating and maintenance instructions.



Forward Air Conditioner Control Panel



Air Condition Intake Vent

Notice:

Air conditioners use surface water as a cooling medium. The boat must be in the water and the raw water supply system must be properly activated prior to use. Operation without proper cooling could cause the air conditioning unit to shut down and could cause system damage. Always check for proper water flow out of the air conditioning pump discharge thru-hull when the air conditioner is operating.

12.4 Cabin Woodwork

Floors and Shower Seat

The wood cabin floors and head compartment shower seat are made of teak. The floors and seat are finished with a high quality urethane finish that will provide years of protection with proper care and treatment.

It is important to avoid tracking sand and dirt on the cabin floors. Sand and dirt acts like sand paper and will eventually sand off the finish in the traffic areas. The wood can be sanded and refinished as necessary.

Carpeted or wood floors be cleaned with a vacuum. Wood floors can be vacuumed then washed with a mixture of water and Murphy's Oil Soap. Wipe the wood dry with a clean towel.

Walls, Cabinets and Trim

The hardwood used for the trim moldings is finished with a high quality urethane varnish. The walls, cabinets and cabinet doors are made of a laminated, simulated wood that requires no maintenance. The walls and molding can be routinely cleaned with a damp cloth. For heavy duty cleaning, use a mixture of water and Murphy's Oil Soap or white vinegar and water to clean the wood or laminate and wipe it dry with a clean towel. Apply a furniture polish to add luster and help to preserve the finish.



Port Console Cabin Sole

NOTES

ROUTINE MAINTENANCE

13.1 Exterior Hull & Deck

Hull Cleaning-Below The Water Line

When the boat is removed from the water, clean the outer bottom surface immediately. Algae, grass, dirt and other marine growth is easier to remove while the hull is still wet. Use a pressure cleaner or a hard bristle brush to clean the surface.

Bottom Painting

If the boat is to be left in saltwater for extended periods, the hull must be protected from marine growth by antifouling paint. Because of variations in water temperature, marine growth and pollution in different regions, a qualified boat yard in your area should be consulted when deciding what bottom paint system to apply to your hull. This is extremely important as pollution and marine growth can damage fiberglass hulls.

Use only standard antifouling paints and fiberglass wax removers and primers recommended by the antifouling paint manufacturer when preparing the hull for bottom paint. Light sanding, just enough to scuff the gel coat or a skip sand primer system can be used to prepare the hull for bottom paint. The use of a coating other than standard antifouling paint or epoxy barrier coatings are not recommended and will void the hull blister warranty.

Do not allow the hull antifouling paint to contact the outboard motors. Most antifouling paints designed for hull bottoms contain copper and can cause severe galvanic corrosion damage to the motors. Always leave at least a 1" barrier between the hull bottom paint and outboard motors.

CAUTION

SANDBLASTING THE HULL BOTTOM WILL DAMAGE THE FIBERGLASS. USE A FIBERGLASS WAX REMOVER AND SAND TO SCUFF THE GELCOAT SURFACE. THE INSTRUCTIONS AND RECOMMENDATIONS OF THE BARRIER COATING AND ANTIFOULING PAINT MANUFACTURERS SHOULD BE FOLLOWED EXACTLY.

CAUTION

BARRIER COATINGS AND BOTTOM PAINT SHOULD BE APPLIED ONLY BY QUALIFIED MARINE PROFESSIONALS IN A BOAT YARD OR DEALERSHIP THAT SPECIALIZES IN THEIR APPLICATION. USE ONLY STANDARD, HIGH QUALITY ANTIFOULING PAINTS AND BARRIER COATINGS FROM NAME BRAND MANUFACTURERS SUCH AS INTERLUX AND PETTIT.

DO NOT ALLOW THE HULL ANTIFOULING PAINT TO CONTACT THE OUTBOARD MOTORS. MOST ANTIFOULING PAINTS DESIGNED FOR HULL BOTTOMS CONTAIN COPPER AND CAN CAUSE SEVERE GALVANIC CORROSION DAMAGE TO THE OUTBOARD DRIVE UNIT. USE ONLY ANTIFOULING PAINT DESIGNED FOR OUTBOARD MOTORS IF APPLYING ANTIFOULING PAINT TO THE ENGINES. ALWAYS LEAVE A ONE INCH BARRIER BETWEEN THE HULL BOTTOM PAINT AND OUTBOARD MOTOR.

Most bottom paints require some maintenance. Proper maintenance is especially important when the boat is in saltwater and not used for extended periods or after dry storage. If the hull bottom has been painted with antifouling paint, contact your dealer or local boat yard for the recommended maintenance procedures.

Anodes

Sacrificial anodes are installed on the outboard motors, engine clamp brackets and could be installed on the trim tabs. Your boat is equipped with a large anode on the transom that is connected to the bonding system. The transom anode provides additional protection against galvanic corrosion for the engines, thru-hull fittings and other underwater hardware that is bonded.



Typical Transom Anode

Routine Maintenance

The anodes are less noble than copper based alloys, stainless steel and aluminum. They will deteriorate first, protecting the more noble underwater hardware against galvanic corrosion. They must be monitored if the boat is to be left in the water. Anodes should be checked monthly and changed when they are 75% of their original size. When replacing the anodes, make sure the contact surfaces are clean, shiny metal and free of paint and corrosion. Never paint over the anode.

Boats stored in saltwater will normally need to have the anodes replaced every 6 months to one year. Anodes requiring replacement more frequently may indicate a stray current problem within the boat or at the slip or marina. Anodes that do not need to be replaced after one year may not be providing the proper protection. Loose or low quality anodes could be the problem. Contact your dealer or Everglades Customer Service for the proper size and type of anodes to be used and the specific installation procedure.

There are 2 anodes on Yamaha engines. There is a large anode on the bottom of the clamp bracket and another anode on the anti-cavitation plate, above the propeller. There are also anodes in the fresh water cooling system for the generator. Refer to the engine and generator owner's manuals for additional information on the location and type of anodes on your outboard engines and generator.

Fiberglass Gel coat

Normal maintenance requires only washing with mild soap and water. A stiff brush can be used on the nonskid areas. Kerosene or commercially prepared products will remove oil and tar which could be a problem on trailered boats. Harsh abrasive and chemical cleaners are not recommended because they can damage or dull the gel coat, reducing its life and making it more susceptible to stains. When the boat is used in saltwater, it should be washed thoroughly with soap and water after each use.

At least once a season, wash and wax all exposed fiberglass surfaces. Use a high quality automotive or boat wax. Follow the procedure recommended by the wax manufacturer. The washing and waxing of your boat will have the same beneficial effects as they have on an automobile finish. The wax will fill minute scratches and pores thus helping to prevent soiling and will extend the life of the gel coat or paint.



After the boat is exposed to the direct sunlight for a period of time, the gel coat or painted surfaces tend to fade, dull or chalk. A heavier buffing is required to bring the finish back to its original luster. For power cleaning use a light cleaner. To clean the boat by hand, use a heavier automotive cleaner. Before cleaning the surfaces, read the instructions given with the cleaner. After cleaning the surfaces, apply wax and polish all fiberglass surfaces except the nonskid areas.

Avoid the following on gelcoat surfaces:

- Do not use plastic or other nonporous (non-breathable) materials to cover gelcoat surfaces. Trapped moisture from condensation can cause gelcoat damage. Shrink wrap storage covers must be properly ventilated, including hull sides.
- Do not use abrasives, bleaches, ammonia, acids or harsh detergents. See your dealer for special marine formulations. Harsh abrasive and chemical cleaners are not recommended because they can damage or dull the gelcoat, reducing its life and making it more susceptible to stains.
- NEVER apply wax or buffing compound to a gelcoat surface in direct sunlight.

Chalking, stains and minor scratches can be removed in most cases with careful rubbing and polishing with appropriate compounds or chemicals and is best done by a professional - see your dealer.

If the fiberglass should become damaged and need repair, contact your dealer or Everglades Customer Service for assistance in finding an authorized repair person to make the repairs.

 **CAUTION** 

DO NOT WAX NONSKID AREAS AS THIS COULD MAKE THEM SLIPPERY AND CONSEQUENTLY INCREASE THE POSSIBILITY OF INJURY.

Stainless Steel Hardware

When using the boat in saltwater, the hardware should be washed with soap and water after each use. When your boat is used in a corrosive environment such as saltwater, water with a high sulfur content or polluted water, the stainless steel will



periodically develop surface rust stains. This is perfectly normal under these conditions.

The following guidelines will help keep stainless steel looking good for many years.

- Clean stainless steel frequently (daily in salt or polluted environments) with mild soap and plenty of water. Any cleaner safe for use on glass is usually safe for stainless.
- Remove rust spots (especially around welds) immediately with a brass, silver or chrome cleaner. Irreversible pitting will develop under rust allowed to remain on stainless for any period of time.
- Remove rust stains on gelcoat. See dealer for recommended product.
- Stainless Steel can normally be cleaned and protected by using a high quality boat or automotive wax or a commercial metal cleaner and protectant.

Never do the following on Stainless Steel.

- Do not use coarse abrasives like sandpaper or steel wool which may actually cause rusting.
- Do not use acids or bleaches which may etch the naturally occurring protective coating.
- Do not leave stainless steel in contact with iron, steel or other metals which cause contamination leading to rust or corrosion.

 **CAUTION** 



UNDER NO CIRCUMSTANCES SHOULD ANY ABRASIVE MATERIALS SUCH AS SANDPAPER, BRONZE WOOL OR STEEL WOOL BE USED ON STAINLESS STEEL. DAMAGE TO THE HARDWARE WILL RESULT.

Anodized Aluminum Surfaces

Anodized aluminum should be washed periodically with soap and water to keep it clean. If the boat is used in saltwater or polluted water, the aluminum should be washed with soap and water after each use. Saltwater allowed to remain on anodized aluminum will penetrate the anodized coating and attack the aluminum.

Hardtops, bimini tops or T-tops with canvas and/or fiberglass tops require special attention to the anodized aluminum just below the top. This area is subject to salt build up from salty condensation and sea spray. It is also frequently overlooked

when the boat is washed and will not be rinsed by the rain. Consequently, the aluminum just below the top is more likely to become pitted than the exposed aluminum on the structure. Make sure the aluminum in this area is washed frequently with soap and water and rinsed thoroughly. Pay particular attention to places where the top material or lacing contact the frame. Once a month coat the entire frame with a metal protector made for anodized aluminum to protect against pitting and corrosion caused by the harsh effects of saltwater. Do not use automotive or boat wax designed for paint or gel coat on anodized aluminum. The wax can contaminate the aluminum and damage the anodized surface.

 **CAUTION** 

ONE DRAWBACK TO METAL PROTECTORS IS THAT THEY CAN MAKE THE METAL SLIPPERY. THEREFORE, THEY SHOULD BE NOT BE USED ON TOWER LADDERS, STEERING WHEELS AND OTHER AREAS WHERE A GOOD GRIP AND SURE FOOTING IS IMPORTANT.

Stains can be removed with a metal polish or fine polishing compound. To minimize corrosion, use only high quality stainless steel fasteners on aluminum fabrications. Isolate the fasteners from the aluminum by using fiber washers and caulking compound or Tef-Gel to bed hardware and fasteners mounted to aluminum fabrications. If the anodized coating is badly scratched, it will require special attention and more frequent cleaning to the damaged area. With proper care, anodized aluminum will provide many years of service.

Powder Coated Aluminum

Powder coated aluminum should be washed periodically with soap and water to keep it clean. If the boat is used in saltwater or polluted water, the aluminum should be washed with soap and water after each use. Saltwater allowed to remain on powder coated aluminum will penetrate the coating and attack the aluminum, usually around fasteners and hardware mounted to the aluminum.

Pay special attention to the area just below the top. This area is subject to salt buildup from salty condensation and sea spray. It is also frequently overlooked when the boat is washed and will not be rinsed by the rain. Consequently, the powder coating near fasteners and hardware mounted just below the top is more likely to be attacked by the salt and become corroded than the exposed

Routine Maintenance

areas on the structure. Make sure the aluminum in this area is washed frequently with soap and water and rinsed thoroughly. Pay particular attention to places where the top material or lacing contact the frame.

Once a month check the entire frame for damaged powder coating and corrosion around fasteners and hardware. Nicked or badly scratched powder coating can be sanded and touched up with enamel paint. Corrosion will have to be sanded, then touched up with paint. Periodically applying automotive or boat wax to the powder coating will provide additional protection from the harsh effects of saltwater.

We recommend that you do not drill into or install any hardware to the aluminum frame. Poor maintenance or hardware and snaps mounted to the fabrication can void the warranty on the powder coated frame. If you do install hardware to the frame, the fasteners will require fiber washers and sealing with caulk or Tef-Gel to isolate the fastener from the aluminum and reduce damage to the powder coating when the fastener is installed.

Always repair scratches, nicks and corroded areas in powder coating as soon as possible. Corrosion left unaddressed will lift the powder coating allowing moisture to travel between the powder coating and the aluminum causing the corrosion to spread below the coating and damage the aluminum.

If excessive chipping and peeling occurs, it could be an indication of an electrical fault in the boat or aluminum fabrication. You should contact a qualified marine electrician to inspect your boat immediately and correct the problem if you suspect that your boat may have a fault in the aluminum frame. You should also contact your dealer or Everglades Customer Service.

Notice:

Boats that are towed behind larger vessels require special attention to the aluminum hardware. The salt spray, salty steam and chemicals in exhaust gases are particularly corrosive and will damage the surface of anodized or powder coated aluminum. It is imperative that the boat and the aluminum are cleaned thoroughly at the completion of each trip or at the end of each day on long cruises to reduce accelerated deterioration of the anodizing or powder coating and premature corrosion to the aluminum.

Notice:

You should contact Everglades Customer Service before making any modifications to aluminum fabrications. Unauthorized modifications can void the warranty.

Chrome Hardware

Use a good chrome cleaner and polish on all chrome hardware.

Acrylic Plastic Glass

Acrylic glass scratches easily. Never use a dry cloth or glass cleaning solutions on acrylic. Use a soft cloth and mild soap and water for routine cleaning. Solvents and products containing ammonia can permanently damage acrylic plastic glass.

Fine scratches can be removed with a fine automotive clear coat polishing compound. A coat of automotive or boat wax is beneficial to protect the surface.

Do not use the following on acrylic glass:

Abrasive cleaners	Acetone
Solvents	Alcohol
Cleaners containing ammonia	Glass cleaners

13.2 Upholstery, Canvas & Enclosures

Vinyl Upholstery

The vinyl upholstery used on the seats, cushions, bolsters and for the headliner in some cabins, should be cleaned periodically with mild soap and water. Any stain, spill or soiling should be cleaned up promptly to prevent the possibility of permanent staining. When cleaning, always rub gently. Avoid using products containing ammonia, powdered abrasive cleaners, steel wool, ink, strong solvents, acetone and lacquer solvents or other harsh chemicals as they can cause permanent damage or shorten the life of vinyl. Never use steam heat, heat guns or hair dryers on vinyl.

Stronger cleaners, detergents and solvents may be effective in stain removal, but can cause either immediate damage or slow deterioration. Lotions, sun tan oil, waxes and polishes, etc., contain oils and dyes that can cause stiffening and staining of vinyls.

- Dry soil, dust and dirt - Remove with a soft cloth.
- Dried on dirt - Wash with a soft cloth dampened with water.

- Variations in surface gloss - Wipe with a water dampened soft cloth and allow to air dry.
- Stubborn dirt - Wash with a soft cloth dampened with Ivory Flakes® and water. Rinse with clean water.
- Stubborn spots and stains - Spray with either Fantastik Cleaner® or Tannery Car Care Cleaner® and rub with a soft cloth. Rinse with clean water.
- Liquid spills - Wipe immediately with a clean absorbent cloth. Rinse with clean water.
- Food grease and oily stains - Spray immediately using either Fantastik Cleaner® or Tannery Car Care Cleaner®, wiping with a soft cloth. Take care not to extend the area of contamination beyond its original boundary. Rinse with clean water.

Acrylic Canvas (Sunbrella)

Modern, bright colored canvas tops are usually fabricated from acrylic fabrics with the trade names like Sunbrella®, Argonaut®, etc. Acrylic fabrics look similar to cotton canvas but are much more durable and color fast.

Acrylic canvas can be cleaned by using Ivory Flakes, Ivory Liquid or another mild soap and water. Scrub lightly and rinse thoroughly to remove the soap. Do not use detergents, as they will deteriorate the waterproofing in the fabric. The underside can be brushed with a soft brush and sprayed with a disinfectant to prevent the accumulation of dirt and mildew. The top or accessories should never be folded or stored wet.

In fresh water areas, the top and curtains should be washed weekly. This is particularly important if the boat is stored near a highway, airport or in a large city. Residue from jet fuel, exhaust fumes and industrial pollution can shorten the life of tops and enclosures.

In saltwater areas, the top and curtains should be rinsed with fresh water after each use and at least weekly if it is stored outside. Saltwater attracts moisture and dirt can shorten the life of fabric tops and enclosures. The salt is also abrasive and can cause premature wear in the fabric and stitching.

After several years, the acrylic canvas may lose some of its ability to shed water. If this occurs,

wash the fabric and let it dry thoroughly. Then treat the outside surface with a commercially available waterproofing designed for this purpose. Waterproofing is available in bulk at most canvas shops. One-gallon garden sprayers are excellent for applying waterproofing.

Notice:

Some leakage at the seams is normal and unavoidable with acrylic enclosures.

Laminated Vinyl Tops

Laminated vinyl top material is a lamination of two plies of specially formulated vinyl with an inner reinforcing core fabric. The most common trade names for this fabric is Weblon® or Stamoid®. It is not unusual for the interior ply to be a different color than the exterior. There is a greater tendency for this type of fabric to leak at the seams than with acrylic or vinyl coated polyester. Paraffin wax that matches the top can be used to seal the seams if necessary.

Laminated vinyl fabrics should be cleaned periodically by using Ivory Flakes, Ivory Liquid or another mild soap and water. Scrub lightly and rinse thoroughly to remove the soap. Do not use detergents or harsh cleaners like bleach and ammonia. They will attack the vinyl in the fabric and shorten its life. The top or accessories should never be folded or stored wet.

In fresh water areas, the top and curtains should be washed weekly. This is particularly important if the boat is stored near a highway, airport or in a large city. Residue from jet fuel, exhaust fumes and industrial pollution can shorten the life of tops and enclosures.

In saltwater areas, the top and curtains should be rinsed with fresh water after each use and at least weekly if it is stored outside. Saltwater attracts moisture and dirt can shorten the life of fabric tops and enclosures. The salt is also abrasive and can cause premature wear in the stitching.

Clear Curtains and Connectors

Side curtains and clear connectors can be cleaned with mild soap and water. They should not be allowed to become badly soiled. Dirt, oil, mildew and cleaning agents containing ammonia, will shorten the life of the vinyl that is used for clear curtains. After cleaning the curtains and allowing them to dry, apply a non-lemon furniture polish

Routine Maintenance

or an acrylic glass and clear plastic protector to extend the life of the curtains.

Vinyl curtains should be stored either rolled or flat, without folds or creases. Folding the curtains will make permanent creases that could cause the vinyl to crack.

Notice:

Do not use any polish containing lemon scents or lemon. The lemon juice will attack the vinyl and shorten its life.

Snaps should be lubricated periodically with Teflon or silicone grease or a lubricant designed for snaps. Zippers should be lubricated with silicone spray, paraffin or silicone stick.

Strataglass

Strataglass® is a special coated vinyl that could be used in the curtains for the hardtop enclosure. The coating protects the vinyl glass and resists scratching. Waxes and Plexiglas polishing compounds should not be used on strataglass as the protective coating prevents them from penetrating into the vinyl and they will build up on the surface. These products will create a hazy, greasy appearance that will affect the clarity of the strataglass. Products that repel water, like Rainex®, should not be used as they will not take well to the surface and could appear spotty and may also yellow or dull the Strataglass over time.

Strataglass can be cleaned by rinsing off dirt or salt deposits with fresh water, then washing with a clean cloth and mild soap. Chamois dry to remove water spots and improve clarity. If a polish is accidentally used, use Windex® or its equivalent to remove it. While window cleaners will destroy the standard vinyl normally used in side curtains and clear connectors, it will not harm strataglass. Always roll down the curtains and snap in place at the end of each day so the curtains will maintain their shape and to minimize fold distortions.

Depending upon usage, it is recommended that an occasional application of Aquatech Strataglass Cleaner be done. Treat this like a polish, as opposed to a cleaner - wash and dry curtains first, then apply Aquatech Strataglass Cleaner, actually buffing the surface to a beautiful sheen. This is not just a wipe on/ wipe off product...it needs to be buffed to perform.

Remember, the coating on strataglass is scratch resistant and not scratch proof. Always handle the

curtains with care and never roll up curtains that are salty or dirty. If you have any questions about the clear curtains used on your boat, please contact your dealer or Everglades Customer Service.

Notice:

Hardtop enclosures must be removed when trailering. Canvas enclosures are not designed to withstand the extreme wind pressure encountered while trailering and will be damaged. Always remove and properly store the enclosure before trailering your boat.

13.3 Interior

The cabin or head interior can be cleaned just like you would clean a home interior. To preserve woodwork, use teak oil. To maintain carpeting, use a vacuum cleaner. Because air and sunlight are very good cleansers, periodically put cushions, sleeping bags, etc. on deck, in the sun and fresh air, to dry and air out. If cushions or equipment get wet with saltwater, remove and use clean, fresh water to rinse off the salt crystals. Salt retains moisture and will cause damage. Dry thoroughly and reinstall.

Vinyl headliner material should be cleaned periodically as explained in the previous section. Avoid using products containing ammonia, bleach or harsh chemicals as they can shorten the life of vinyl. Fiberglass headliners should be wiped down with a damp towel as necessary to remove dust and dirt.

If you leave the boat for a long period of time, put all cushions on their sides, open all interior cabin and locker doors and hang a commercially available mildew protector in the cabin.

Notice:

Always read the label carefully on mildew protectors. Remove the protector and allow the cabin to ventilate completely before using the cabin.

Counter Tops - Faux Granite

A mild liquid detergent and water or disinfectant cleaners will remove most dirt and stains from Faux Granite. Rinse with a clean cloth moistened with fresh water. Wipe dry with a clean cloth.

Never use granite cleaners, bleaches, ammonia, household cleaners, polishes or scouring pads.

Harsh cleaners and scouring pads will damage the polymer surface of Faux Granite.

In most cases, Faux Granite can be repaired if accidentally damaged. Small scratches that do not penetrate the coating can be repaired using an automotive buffing compound. Deep scratches and heavy damage require a professional repair. Contact your dealer or a counter top repair professional for assistance in repairing deep scratches or other damage on your counter tops.

Interior Woodwork

Oiled and varnished woodwork or laminated, simulated wood can be cleaned with a damp cloth. For heavy duty cleaning, use a mixture of water and Murphy's Oil Soap or a solution of 10% white vinegar and water to clean the wood and wipe it dry with a clean towel. Apply a furniture polish to add luster and help to preserve the finish.

13.4 Engines and Fuel

Proper engine maintenance is essential to the proper performance and reliability of your outboard engines. Maintenance schedules and procedures are outlined in your engine owner's manual. They should be followed exactly.

If the boat is used in saltwater, flush the cooling system after each daily use. To flush the systems when the boat is out of the water, follow the procedure outlined in your engine owner's manual.

Proper engine operation requires a good supply of clean, dry fuel. Improper marina fuel storage techniques, limited boat usage, etc. can cause the fuel to become contaminated.

The age of fuel can affect engine performance. Chemical changes occur as the fuel ages that can cause deposits and reduce the octane rating of the fuel. Severely degraded fuel can damage the engine and boat fuel tank and lines. Therefore, if your boat is not being run enough to require at least one full tank of fresh fuel a month, a fuel additive should be added to protect it from degradation. Your dealer or the engine manufacturer can provide additional information on fuel degradation and fuel stabilizers recommended for your engine.

In many states, most gasoline is blended with ethanol alcohol. Ethanol is a strong solvent and can absorb water during periods of storage. You should refer to the engine operating manual for

information regarding alcohol blended fuels and how it affects the operation of your marine engine.

13.5 Generator

The engine maintenance required on the generator is similar in many ways to the main engines. The engine incorporates a pressure-type lubrication system and a fresh water cooled engine block which is thermostatically controlled.

The seawater cooling system on the generator is equipped with a sacrificial anode to protect cooling system components from galvanic corrosion. The anode should be inspected when the generator is serviced and replaced when it is 75% of its original size or at least once each year.

The most important factors to the generator's longevity are proper ventilation and maintenance of the fuel system, ignition system, cooling system, lubrication system and the AC alternator.

Maintenance schedules and procedures are outlined in your generator owner's manual. They should be followed exactly.

Notice:

The generator charges the house batteries just enough to compensate for the DC electrical current the engine requires to operate. Therefore, it is important to activate the battery charger to maintain the house and engine batteries whenever the generator is running.

13.6 Bilge, Pumps & Components

To keep the bilge clean and fresh, it is recommended that you use a commercial bilge cleaner on a regular basis. Follow the directions carefully. All exposed pumps and metal components in the bilge should be sprayed periodically with a protector to reduce the corrosive effects of the high humidity always present in these areas.

Periodically check the bilge pumps and alarms for proper operation and clean debris from the strainers and automatic switches. Inspect all hoses, clamps and thru-hulls for leaks and tightness on a regular basis. Operate all thru-hull valves at least once a month to keep them operating properly.

Frequently test the automatic bilge pump switches for proper operation. This is accomplished by using the test knob or buttons on the side of external

Routine Maintenance

switches. You can also use a garden hose to flood the bilge until the water level is high enough to activate the pump.

13.7 Drainage System

It is essential that the following items be done periodically to maintain proper drainage of your boat:

- Clean the cockpit drains with a hose to remove debris that can block water drainage.
- Clean the hardtop leg drain holes. This is especially important just before winter lay-up.
- Flush all gravity drains with fresh water to keep them clean and free flowing.
- Clean and inspect the shower and cabin drain sump system. Remove accumulated debris and flush with fresh water. Frequently test the automatic pump switch for proper operation.
- Flush air conditioner condensation pans and drain hoses with fresh water at least once each season to remove mold and debris. This is particularly important because mold tends to accumulate in condensation pan drain and, if it is not cleaned regularly, the drain can clog and flood the cabin sole when the air conditioner is operating.
- Clean and flush coolers and storage boxes with soap or a bilge cleaner and fresh water after each use to keep them clean and fresh.
- Operate the thru-hull valves once a month and service as required.
- Run all overboard pumps briefly at least once a month to keep them operating properly.

Notice:

All drains and pumps must be properly winterized before winter lay-up.

SEASONAL MAINTENANCE

14.1 Storage & Lay-up

Before Hauling:

- Pump out the head holding tank. Flush the holding tank using clean water, soap and a deodorizer. Pump out the cleaning solution.
- The fuel tank should be left nearly full to reduce condensation that can accumulate in the tank. Allow enough room in each tank for the fuel to expand without leaking out the vents. Moisture from condensation in the fuel tank can reach such concentrations that it becomes heavy enough to settle out of the fuel to the bottom of the tank. Since fuel pickup tubes are located near the bottom of the tank, this accumulated moisture can cause the engines to run poorly or not at all after extended storage.

Chemical changes also occur as the gasoline ages that can cause deposits and varnish in the fuel system as well as reduce the octane rating of the fuel. Severely degraded fuel can damage the engines and boat fuel tank and lines. Therefore, if your boat is not being run enough to require at least one full tank of fresh fuel a month or during winter storage, a fuel stabilizer should be added to the gasoline to help protect the fuel system from these problems. Operate the boat for at least 15

minutes after adding the stabilizer to allow the treated fuel to reach the engines. Yamaha recommends using Yamaha Fuel Conditioner and Stabilizer for their engines.

Your dealer or the engine manufacturer can provide additional information on fuel degradation and fuel stabilizers recommended for your engines. For more recommendations for your specific area, check with your local Everglades dealer.

- Drain water from the fresh water system.
- Consult the engine owner's manual for detailed information on preparing the engines for storage.

Lifting

It is essential that care be used when lifting your boat. Make sure the spreader bar at each sling is at least as long as the distance across the widest point of the boat that the sling will surround. Put the slings in position. Sling labels on the gunnels just above the rubrail identify the correct position for the lifting slings. The fore and aft slings should be tied together to prevent the slings from sliding on the hull.



Sling Locations



CAUTION



BOATS CAN BE DAMAGED FROM IMPROPER LIFTING AND TRANSPORTING WITH FORK LIFTS. CARE AND CAUTION MUST BE EXERCISED WHEN TRANSPORTING A BOAT WITH A FORK LIFT. NEVER HOIST THE BOAT WITH A SUBSTANTIAL AMOUNT OF WATER IN THE BILGE.

SEVERE GEL COAT CRACKING OR MORE SERIOUS HULL DAMAGE CAN OCCUR DURING HAULING AND LAUNCHING IF PRESSURE IS CREATED ON THE GUNWALES (SHEER) BY THE SLINGS. FLAT, WIDE BELTING SLINGS AND SPREADERS LONG ENOUGH TO KEEP PRESSURE FROM THE GUNWALES ARE ESSENTIAL. DO NOT ALLOW ANYONE TO HAUL YOUR BOAT WHEN THE SPREADERS ON THE LIFT ARE NOT WIDE ENOUGH TO TAKE THE PRESSURE OFF THE GUNWALES.

Supporting The Boat For Storage

A trailer, elevating lift, well-made cradle or proper blocking is the best support for your boat during storage.

When storing the boat on a trailer for a long period:

- Make sure the trailer is large enough to properly support your boat and that it is rated to support the weight.
- Make sure the trailer is on a level surface and the bow is high enough so that water will drain from the bilge and cockpit.
- Make sure the engines are in the down position.
- The trailer must properly support the hull. The bunks and rollers should match the bottom of the hull and should not be putting pressure on the lifting strakes.
- Make sure the hitch is properly supported.
- Check the tires once each season. Add enough air for the correct amount of inflation for the tires as necessary.

Notice:

Read the owner's manual for the trailer for the correct amount of inflation for the tires.

When storing the boat on a lift or cradle:

- The cradle must be specifically for boat storage.
- Make sure the cradle or lift is well supported with the bow high enough to provide proper drainage of the bilge and cockpit.

- Make sure the engines are in the down position.
- The cradle or lift must be in the proper fore and aft position to properly support the hull. When the cradle or lift is in the correct location, the bunks should match the bottom of hull and should not be putting pressure on the lifting strakes.



CAUTION



BOATS HAVE BEEN DAMAGED BY TRAILERS, LIFTS AND CRADLES THAT DON'T PROPERLY SUPPORT THE HULL. ALWAYS MAKE SURE THE BUNKS AND ROLLERS ARE ADJUSTED SO THEY ARE NOT PUTTING PRESSURE ON THE LIFTING STRAKES AND ARE PROVIDING ENOUGH SUPPORT FOR THE HULL. HULL DAMAGE RESULTING FROM IMPROPER CRADLE OR TRAILER SUPPORT IS NOT COVERED BY THE EVERGLADES WARRANTY.

When supporting the boat with blocking:

- Make sure the boat is blocked on a level surface and the bow is high enough so that water will drain from the bilge and cockpit.
- Make sure the keel is supported with large, solid wood blocks in at least three points.
- Use at least three heavy duty jacks on each side of the hull and make sure the boat is level from side to side. The jacks must be on a solid surface like packed gravel, concrete or pavement. All of the supports must be set up properly to prevent the boat from shifting while it is in storage.

Preparing The Boat For Storage:

- Remove the bilge drain plug, if installed.
- Thoroughly wash the fiberglass exterior, especially the antifouling portion of the bottom. Remove as much marine growth as possible. Lightly wax the exterior fiberglass components.
- Remove all oxidation from the exterior hardware and apply a light film of moisture displacing lubricant, wax or a metal protector.
- Remove propellers and grease the propeller shafts using light waterproof grease.

- Remove the batteries and store in a cool place. Clean using clear, clean water. Be sure the batteries have sufficient water and clean terminals. Keep the batteries charged and safe from freezing throughout the storage period.

Notice:

Refer to the Electrical System chapter, for information on the maintenance of the AC and DC electrical systems.

- Coat all faucets and exposed electrical components in the cabin and cockpit with a protecting oil.
- Clean out, totally drain and completely dry the fish boxes, coolers, sinks and livewells.
- Thoroughly clean the interior of the boat. Vacuum all carpets and dry clean drapes and upholstery.
- Remove cushions and open as many locker doors as possible. Leaving as many of these areas open as possible will improve the boat's ventilation during the storage period.

Notice:

It is recommended that a mildew preventer be hung in the cabin before it is closed for storage.

- Clean the exterior upholstery with a good vinyl cleaner and dry thoroughly. Spray the weather covers and boat upholstery with a spray disinfectant. Enclosed areas such as the shower basin, storage locker areas, etc. should also be sprayed with this disinfectant.

14.2 Winterizing Fresh Water System

The entire fresh water system must be completely drained. Disconnect all hoses, check valves, etc. and blow all the water from the system. Make sure the water heater, filters and fresh water tank are completely drained. Use only very low air pressure when doing this to prevent possible system damage. Because of the check valve mechanism built in the pump, blowing the lines will not remove the water from the fresh water pump. Remove the inlet and outlet hoses on the pump. Turn the pump on and allow it to pump out any remaining water...about a cupful. A recommended alternative to the above-mentioned procedure is the use of commercially available non toxic, fresh water

system antifreeze. After draining the fresh water tank, lines, filters and water heater, pour the antifreeze mixture into the fresh water tank, prime and operate the pump until the mixture flows from all fresh water faucets. Be sure to open all hot and cold water faucets, including the fresh water shower in the head compartment, washdown hose and the faucet in the work station. Make sure antifreeze has flowed through all of the fresh water drains.

The shower/cabin drain system must be properly winterized. Clean debris from the drain and sump and flush for several minutes with fresh clean water. After the system is clean, pump the drain sump as dry as possible. Then pour a potable water antifreeze mixture into the shower drain until antifreeze has been pumped through the entire system and out of the thru-hull.

For additional information refer to the Fresh Water System and Drainage System chapters.

Raw Water System

Completely drain the raw water systems including the sea strainers in the systems compartment bilge. Disconnect all hoses and blow the water from the system. Use only very low air pressure when doing this to prevent possible system damage. Because of the check valve mechanism built in the raw water washdown pump, blowing the lines will not remove the water from the raw water pump. Remove the inlet and outlet hoses on the pump. Turn the pump on and allow it to pump out any remaining water...about a cupful.

A recommended alternative to the above-mentioned procedure is the use of commercially available nontoxic, potable water system antifreeze. If potable water antifreeze is used, pour the mixture into a pail and put the raw water intake lines into the solution. Run the pumps one at a time until the antifreeze solution is visible at all raw water faucets and discharge fittings and drains. Be sure antifreeze has flowed through all of the raw water drains.

Make sure all the water is removed from the fish-box and livewell. Also make sure the drains are clear and free flowing.

Refer to the Raw Water System chapter for additional information on the raw water system.

Marine Toilet

The marine toilet must be properly winterized by following the manufacturer's winterizing instructions in the marine toilet owner's manual. Drain the intake and discharge hoses completely using low air pressure if necessary. The head holding tank and overboard discharge pump must be pumped dry and one gallon of potable water antifreeze poured into the tank through the deck waste pump out fitting. After the antifreeze has been added to the holding tank, open the overboard discharge valve and activate the overboard macerator pump until the antifreeze solution is visible at the discharge thru-hull.

Notice:

Make sure you follow the marine toilet manufacturer's winterizing instructions exactly.

Bilge

Coat all metal components, wire busses and connector plugs in the bilge with a protecting oil. It is also important to protect all strainers, seacocks and steering components. The bilge pumps and bilge pump lines must be completely free of water and dried out when the boat is laid-up for the winter in climates where freezing occurs. Compartments in the bilge that will not drain completely should be pumped out and then sponged until completely free of water. Dry the hull bilge and self-bailing cockpit troughs. Water freezing in these areas could cause damage.

Air Conditioners

Disconnect and drain the seawater pump intake and discharge hoses. Remove all water from the sea strainer and thru-hull fitting. Blow the water from the system. Use only very low air pressure when doing this to prevent possible system damage.

The air conditioner components must be properly winterized by following winterizing procedure in the manufacturer's owner's manual.

Notice:

The air conditioning, marine head and steering systems have specific lay up requirements. Please refer to their owner's manuals for recommended winterizing procedures.

Outboard Engines

The engines should be flushed with fresh water for at least 15 minutes prior to winter storage. This will remove salt, sand and other contaminants that can damage the engine. It is also important to "Fog" the cylinders, change the gear oil and change the oil. Coat each engine with a protector, wax the exterior and properly store and charge the batteries. You should refer to the engine owner's manual or contact your dealer for specific instructions on winterizing your engines.

Generator Raw Water System

Drain the sea strainer, heat exchanger and raw water supply and discharge lines for the generator seawater supply pump. Make sure all seawater has drained from the exhaust system. The generator muffler has a drain plug that must be removed to properly drain the muffler. Once this is accomplished, pour a non toxic marine engine antifreeze mixture into a large pail and put the seawater intake line into the solution. Run the generator until the antifreeze solution is visible at the exhaust port, then shut the engine off. You should refer to the generator owner's manual or contact your dealer for specific instructions on winterizing your generator.



Notice:

Properly winterize the engines, generator and fuel system by following the engine manufacturer's winterizing procedures located in your engine owner's manuals or contact an Everglades dealer.

Hardtop

It is imperative that all drain holes in the legs are open and that the legs are completely free of water. Remove the canvas and thoroughly clean and store in a safe, dry place. Remove all electronics. Coat all wire connectors and bus bars in the helm compartment with a protecting oil.

Clean the aluminum frame with soap and water and dry thoroughly. Apply an aluminum metal protector to the entire frame on anodized aluminum to reduce corrosion and pitting. Apply an automotive or boat wax to powder coated aluminum to protect it during storage periods.



 **CAUTION** 

ALWAYS MAKE SURE THE LEG DRAIN HOLES ARE CLEAR WHEN THE BOAT IS LAID UP FOR THE WINTER. WATER TRAPPED INSIDE THE HARDTOP OR TOWER LEGS COULD FREEZE AND CAUSE THE LEGS TO SPLIT.

Special Notes Prior To Winter Storage

If the boat will be in outside storage, properly support a storage cover and secure it over the boat. It is best to have a frame built over the boat to support the canvas. It should be a few inches wider than the boat so the canvas will clear the rails and allow passage of air. If this cover is fastened too tightly there will be inadequate ventilation and this can lead to mildew, moisture accumulation, etc. It is essential to fasten the canvas down securely so that the wind cannot remove it or cause chafing of the hull superstructure. Do not store the boat in a damp storage enclosure. Excessive dampness can cause electrical problems, corrosion and excessive mildew.

Whenever possible, do not use the Weather Enclosure or sunshade in place of the winter storage cover. The life of these canvases may be significantly shortened if exposed to harsh weather elements for long periods.

 **CAUTION** 

PLACING AN ELECTRIC OR FUEL BURNING HEATING UNIT IN THE BILGE AREA CAN BE POTENTIALLY HAZARDOUS AND IS NOT RECOMMENDED.

Proper storage is very important to prevent serious damage to the boat. If the boat is to be stored indoors, make sure the building has enough ventilation. It is very important that there is enough ventilation both inside the boat and around the boat.

Notice:

If the boat is to be stored indoors or outdoors, open all interior drawers, clothes lockers, cabinets and doors a little. If possible, remove the upholstery, mattresses, clothing and rugs. Then hang a commercially available mildew protector in the interior compartments.



14.3 Recommissioning

 **WARNING** 



DO NOT OPERATE THE BOAT UNLESS IT IS COMPLETELY ASSEMBLED. KEEP ALL FASTENERS TIGHT. KEEP ADJUSTMENTS ACCORDING TO SPECIFICATIONS.

Notice:

It is important and recommended that the fitting out procedure for the marine gear be done by a qualified service person. Read the engine owner's manual for the recommended procedure.

 **CAUTION** 

BEFORE LAUNCHING THE BOAT, MAKE SURE THE HULL DRAIN PLUG IS INSTALLED.

 **WARNING** 

MAKE SURE THE GENERATOR MUFFLER HAS NOT BEEN DAMAGED DURING WINTER STORAGE AND THAT THE DRAIN PLUG IS INSTALLED AND PROPERLY TIGHTENED. LOOSE OR MISSING DRAIN PLUGS AND DAMAGED OR LEAKING MUFFLERS OR EXHAUST HOSES WILL ALLOW CARBON MONOXIDE, ENGINE GASES AND WATER INTO THE BILGE CREATING A POTENTIALLY HAZARDOUS CONDITION.

Reactivating The Boat After Storage:

- Charge and install the batteries.
- Install the drain plug in the hull.
- Check the engines for damage and follow the manufacturer's instructions for recommissioning.
- Check the mounting bolts for the engines to make sure they are tight.
- Perform all routine maintenance.
- Check all hose clamps for tightness.
- Pump the antifreeze from the fresh and raw water systems and flush several times with fresh water. Make sure all antifreeze is flushed from the water heater and it is filled with fresh water before it is activated.

Seasonal Maintenance

- Check and lubricate the steering system.
- Clean and wash the boat.
- Install all upholstery, cushions and canvas.

After Launching:

- Carefully check all water systems and the engine bolts for leaks. Operate each system one at a time checking for leaks and proper operation.
- Check the bilge pump manual and automatic switches.
- When each engine starts, check the cooling system port below the engine cowling for a strong stream of water. This ensures that the cooling pump is operating.
- Carefully monitor the gauges and check for leakage and abnormal noises.
- Operate the boat at slow speeds until the engine temperature stabilizes and all systems are operating normally.
- Start the generator and monitor the exhaust port for a steady stream of water. It may take 20 or 30 seconds for the muffler to fill and for water to appear at the port. This ensures that the cooling pump is operating. Carefully inspect the generator and all hoses for leaks, paying particular attention to the muffler and exhaust hoses. Any leak, no matter how minor must be corrected immediately.
- Once the generator is started and operating normally, activate the air conditioners and monitor the outlet port for a steady stream of water. It may take 20 or 30 seconds for the sea strainer and system to fill and for water to appear at the port. This ensures that the cooling pump is properly primed and operating. Carefully inspect the all hoses for leaks, paying particular attention to the hoses below the waterline and those connected to the air conditioning system.
- If the pump runs but no water is visible at the outlet port after 45 seconds the air conditioning cooling pump may be air locked. The intake for the raw water manifold is equipped with a scoop and ball valve. Make sure the valve is open and run the boat at or above 15 M.P.H. for several minutes. The water pressure from the scoop will force the trapped air through the pump and allow it to prime. If this procedure doesn't work, contact your Everglades dealer.

GLOSSARY OF TERMS

Aft: In, near or toward the stern of a boat.

Aground: A boat stuck on the bottom.

Amidships: In or toward the part of a boat midway between the bow and stern.

Anchor: A specially shaped heavy metal device designed to dig efficiently into the bottom under a body of water and hold a boat in place.

Anchorage: An area specifically designated by governmental authorities in which boats may anchor.

Ashore: On shore.

Astern: Behind the boat, to move backwards.

Athwartship: At right angles to the center line of the boat.

Barnacles: Small, hard-shelled marine animals which are found in salt water attached to pilings, docks and bottoms of boats.

Beam: The breadth of a boat usually measured at its widest part.

Bearing: The direction of an object from the boat, either relative to the boat's direction or to compass degrees.

Berth: A bunk or a bed on a boat.

Bilge: The bottom of the boat below the flooring.

Bilge Pump: A pump that removes water that collects in the bilge.

Boarding: Entering or climbing into a boat.

Boarding Ladder: Set of steps temporarily fitted over the side of a boat to assist persons coming aboard.

Boat Hook: Short shaft of wood or metal with a hook fitting at one end shaped to aid in extending one's reach from the side of the boat.

Bow: The front end of a boat's hull

Bow Line: A line that leads forward from the bow of the boat.

Bow Rail: Knee high rails of solid tubing to aid in preventing people from falling overboard.

Bridge: The area from which a boat is steered and controlled.

Bridge Deck: A deck forward and usually above the cockpit deck.

Broach: When the boat is sideways to the seas and in danger of capsizing; a very dangerous situation that should be avoided.

Bulkhead: Vertical partition or wall separating compartments of a boat.

Cabin: Enclosed superstructure above the main deck level.

Capsize: When a boat lays on its side or turns over.

Chock: A deck fitting, usually of metal, with inward curving arms through which mooring or anchor lines are passed so as to lead them in the proper direction both on board and off the boat.

Cleat: A deck fitting, usually of metal with projecting arms used for securing anchor and mooring lines.

Closed Cooling System: A separate supply of fresh water that is used to cool the engine and circulates only within the engine.

Coaming: A vertical piece around the edges of cockpit, hatches, etc. to stop water on deck from running below.

Cockpit: An open space, usually in the aft deck, outside of the cabin.

Companionway: Opening in the deck of a boat to provide access below.

Compartment: The interior of a boat divided off by bulkheads.

Cradle: A framework designed to support a boat as she is hauled out or stored.

Cutlass Bearing: A rubber bearing in the strut that supports the propeller shaft.

Glossary of Terms

Deck: The floor-like platform of a boat that covers the hull.

Displacement: The volume of water displaced by the hull. The displacement weight is the weight of this volume of water.

Draft: The depth of water a boat needs to float.

Dry Rot: A fungus attack on wood areas.

Dry-dock: A dock that can be pumped dry during boat construction or repair.

Electrical Ground: A connection between an electrical connector and the earth.

Engine Beds: Sturdy structural members running fore and aft on which the inboard engines are mounted.

EPIRB: Emergency Position Indicating Radio Beacon. Operates as a part of a worldwide satellite distress system.

Even Keel: When a boat floats properly as designed.

Fathom: A measure of depth. One Fathom = 6 feet.

Fender: A soft object of rubber or plastic used to protect the topsides from scarring and rubbing against a dock or another vessel.

Fend off: To push or hold the boat off from the dock or another boat.

Flying Bridge: A control station above the level of the deck or cabin.

Flukes: The broad portions of an anchor which dig into the ground.

Fore: Applies to the forward portions of a boat near the bow.

Foundering: When a boat fills with water and sinks.

Freeboard: The height from the waterline to the lowest part of the deck.

Galley: The kitchen of a boat.

Grab Rail: Hand-hold fittings mounted on cabin tops or sides for personal safety when moving around the boat, both on deck and below.

Ground Tackle: A general term including anchors, lines and other gear used in anchoring.

Grounds: A boat touches the bottom.

Gunwale: The upper edge of a boat's side.

Hand Rail: Rail mounted on the boat, for grabbing with your hand, to steady you while walking about the boat.

Harbor: An anchorage which provides reasonably good protection for a boat, with shelter from wind and sea.

Hatch: An opening in the deck with a door or lid to allow for access down into a compartment of a boat.

Head: A toilet on a boat.

Heat Exchanger: Used to transfer the heat that is picked up by the closed cooling system to the raw cooling water.

Helm: The steering and control area of a boat.

Hull: The part of the boat from the deck down.

Inboard: A boat with the engine mounted within the hull of the boat. Also refers to the center of the boat away from the sides.

Inboard/outboard: Also stern drive or I/O. A boat with an inboard engine attached to an outboard drive unit.

Keel: A plate or timber plate running lengthwise along the center of the bottom of a boat.

Knot: Unit of speed indicating nautical miles per hour. 1 knot = 1 nautical mile per hour (1.15 miles per hour). A nautical mile is equal to one minute of latitude: 6076 feet. Knots times 1.15 equals miles per hour. Miles per hour times .87 equals knots.

Lay-up: To decommission a boat for the winter (usually in northern climates).

Leeward: The direction toward which the wind is blowing.

Length On The Waterline (l.w.l.): A length measurement of a boat at the waterline from the stern to where the hull breaks the water near the bow.

Limber Hole: A passage cut into the lower edges of floors and frames next to the keel to allow bilge water to flow to the lowest point of the hull where it can be pumped overboard.

Line: The term used to describe a rope when it is on a boat.

Lists: A boat that inclines to port or starboard while afloat.

L.O.A.: Boat length overall.

Locker: A closet, chest or box aboard a boat.

Loran: An electronic navigational instrument which monitors the boat's position using signals emitted from pairs of transmitting stations.

Lunch hook: A small light weight anchor typically used instead of the working anchor. Normally used in calm waters with the boat attended.

Midships: The center of the boat.

Marina: A protected facility primarily for recreational small craft.

Marine Ways or Railways: Inclined planes at the water's edge onto which boats are hauled.

Moored: A boat secured with cables, lines or anchors.

Mooring: An anchor permanently embedded in the bottom of a harbor that is used to secure a boat.

Nautical Mile: A unit of measure equal to one minute of latitude. (6076 feet)

Nun Buoy: A red or red-striped buoy of conical shape.

Outboard: A boat designed for an engine to be mounted on the transom. Also a term that refers to objects away from the center line or beyond the hull sides of a boat.

Pad Eye: A deck fitting consisting of a metal eye permanently secured to the boat.

Pier: A structure which projects out from the shoreline.

Pile or Piling: A long column driven into the bottom to which a boat can be tied.

Pitching: The fore and aft rocking motion of a boat as the bow rises and falls.

Pitch: The measure of the angle of a propeller blade. Refers to the theoretical distance the boat travels with each revolution of the propeller.

P.F.D: Personal Flotation Device.

Port: The left side of the boat when facing the bow.

Porthole (port): The opening in the side of a boat to allow the admittance of light and air.

Propeller: A device having two or more blades that is attached to the engine and used for propelling a boat.

Propeller Shaft: Shaft which runs from the back of the engine gear box, aft, through the stuffing box, shaft log, struts and onto which the propeller is attached.

Pyrotechnic Distress Signals: Distress signals that resemble the brilliant display of flares or fireworks.

Raw Water Cooled: Refers to an engine cooling system that draws seawater in through a hull fitting or engine drive unit, circulates the water in the engine and then discharges it overboard.

Reduction Gear: Often combined with the reverse gear so that the propeller turns at a slower rate than the engine.

Reverse Gear: Changes the direction of rotation of the propeller to provide thrust in the opposite direction for stopping the boat or giving it sternway.

Roll: A boat's sideways rotational motion in rough water.

Rope Locker: A locker, usually located in the bow of a boat, used for stowing the anchor line or chain.

Rubrail: Railing (often rubber or hard plastic) that runs along the boat's sheer to protect the hull when coming alongside docks, piers or other boats.

Rudder: A moveable flat surface that is attached vertically at or near the stern for steering.

Sea anchor: An anchor that does not touch the bottom. Provides drag to hold the bow in the most favorable position in heavy seas.

Glossary of Terms

Scupper: An opening in the hull side or transom of the boat through which water on deck or in the cockpit is drained overboard.

Seacock: Safety valves installed just inside the thru-hull fittings and ahead of the piping or hose running from the fittings.

Shaft Log: Pipe through which the propeller shaft passes.

Sheer: The uppermost edge of the hull.

Sling: A strap which will hold the boat securely while being lifted, lowered or carried.

Slip: A boat's berth between two pilings or piers.

Sole: The deck of a cockpit or interior cabin.

Spring Line: A line that leads from the bow aft or from the stern forward to prevent the boat from moving ahead or astern.

Starboard: The right side of a boat when facing the bow.

Steerageway: Sufficient speed to keep the boat responding to the rudder or drive unit.

Stem: The vertical portion of the hull at the bow.

Stern: The rear end of a boat.

Stow: To pack away neatly.

Stringer: Longitudinal members fastened inside the hull for additional structural strength.

Strut: Mounted to the hull which supports the propeller shaft in place.

Strut Bearing: See "cutlass bearing."

Stuffing Box: Prevents water from entering at the point where the propeller shaft passes through the shaft log.

Superstructure: Something built above the main deck level.

Swamps: When a boat fills with water from over the side.

Swimming Ladder: Much the same as the boarding ladder except that it extends down into the water.

Taffrail: Rail around the rear of the cockpit.

Thru-hull: A fitting used to pass fluids (usually water) through the hull surface, either above or below the waterline.

Topsides: The side skin of a boat between the waterline or chine and deck.

Transom: A flat stern at right angles to the keel.

Travel Lift: A machine used at boat yards to hoist boats out of and back into the water.

Trim: Refers to the boat's angle or the way it is balanced.

Trough: The area of water between the crests of waves and parallel to them.

Twin-Screw Craft: A boat with two propellers on two separate shafts.

Underway: When a boat moves through the water.

Wake: Disrupted water that a boat leaves astern as a result of its motion.

Wash: The flow of water that results from the action of the propeller or propellers.

Waterline: The plane of a boat where the surface of the water touches the hull when it is afloat on even keel.

Watertight Bulkhead: Bulkheads secured so tightly so as not to let water pass.

Wharf: A structure generally parallel to the shore.

Working Anchor: An anchor carried on a boat for most normal uses. Refers to the anchor used in typical anchoring situations.

Windlass: A winch used to raise and lower the anchor.

Windward: Toward the direction from which the wind is coming.

Yacht Basin: A protected facility primarily for recreational small craft.

Yaw: When a boat runs off her course to either side.

Maintenance Log

Date	Hours	Dealer	Service/Repairs

Date	Hours	Dealer	Service/Repairs

Maintenance Log

Date	Hours	Dealer	Service/Repairs

Date	Hours	Dealer	Service/Repairs

Maintenance Log

Date	Hours	Dealer	Service/Repairs

Appendix C:

DEPARTMENT OF TRANSPORTATION U.S. COAST GUARD CG-3865 (Rev. 9/95)		BOATING ACCIDENT REPORT		FORM APPROVED OMB NO. 2115-0010	
				STATE ASSIGNED CASE NO. _____	
THE OPERATOR/OWNER OF A VESSEL USED FOR RECREATIONAL PURPOSES IS REQUIRED TO FILE A REPORT IN WRITING WHENEVER AN ACCIDENT RESULTS IN: LOSS OF LIFE OR DISAPPEARANCE FROM A VESSEL; AN INJURY WHICH REQUIRES MEDICAL TREATMENT BEYOND FIRST AID; OR PROPERTY DAMAGE IN EXCESS OF \$2000 OR COMPLETE LOSS OF THE VESSEL. REPORTS IN DEATH AND INJURY CASES MUST BE SUBMITTED WITHIN 48 HOURS. REPORTS IN OTHER CASES MUST BE SUBMITTED WITHIN 10 DAYS. REPORTS MUST BE SUBMITTED TO THE REPORTING AUTHORITY IN THE STATE WHERE THE ACCIDENT OCCURRED. THIS FORM IS PROVIDED TO ASSIST THE OPERATOR IN FILING THE REQUIRED WRITTEN REPORT.					
COMPLETE ALL BLOCKS (INDICATE THOSE NOT APPLICABLE BY "NA")					
ACCIDENT DATA					
DATE OF ACCIDENT	TIME	AM PM	NAME OF BODY OF WATER	LOCATION (GIVE LOCATION PRECISELY)	
NUMBER OF VESSELS INVOLVED	NEAREST CITY OR TOWN		COUNTY	STATE	ZIP CODE
WEATHER (CHECK ALL APPLICABLE) [] CLEAR [] RAIN [] CLOUDY [] SNOW [] FOG [] HAZY	WATER CONDITIONS [] CALM (WAVES LESS THAN 6") [] CHOPPY (WAVES 6" TO 2') [] ROUGH (WAVES 2' TO 6') [] VERY ROUGH (GREATER THAN 6') [] STRONG CURRENT		TEMPERATURE (ESTIMATE) AIR _____ °F WATER _____ °F	WIND [] NONE [] LIGHT (0-6 MPH) [] MODERATE (7-14 MPH) [] STRONG (15-25 MPH) [] STORM (OVER 25 MPH)	VISIBILITY DAY NIGHT [] GOOD [] [] FAIR [] [] POOR []
NAME OF OPERATOR			OPERATOR ADDRESS		
OPERATOR TELEPHONE NUMBER ()	DATE OF BIRTH MO DAY YR	OPERATOR'S EXPERIENCE [] NONE [] UNDER 100 HOURS [] > 100 HOURS		INSTRUCTION IN BOATING SAFETY [] STATE COURSE [] U.S. POWER SQUADRON [] USCG AUXILIARY [] AMERICAN RED CROSS [] NONE	
[] MALE [] FEMALE					
NAME OF OWNER			OWNER ADDRESS		
OWNER TELEPHONE NUMBER ()	NUMBER OF PEOPLE ON BOARD	NUMBER OF PEOPLE BEING TOWED		RENTED BOAT? [] YES [] NO	
BOAT NO. 1 (THIS VESSEL)					
BOAT REGISTRATION OR DOCUMENTATION NUMBER		STATE	HULL IDENTIFICATION NUMBER		BOAT NAME
BOAT MANUFACTURER		LENGTH	MODEL		YEAR BUILT
TYPE OF BOAT [] OPEN MOTORBOAT [] CABIN MOTORBOAT [] AUXILIARY SAIL [] SAIL (ONLY) [] ROWBOAT [] CANOE/KAYAK [] PERSONAL WATERCRAFT [] PONTOON BOAT [] HOUSEBOAT [] OTHER (SPECIFY)	HULL MATERIAL [] WOOD [] ALUMINUM [] STEEL [] FIBERGLASS [] RUBBER/VINYL/CANVAS [] RIGID HULL INFLATABLE [] OTHER (SPECIFY)		ENGINE [] OUTBOARD [] INBOARD [] INBOARD- STERNDRIVE (I/O) [] AIRBOAT	PROPULSION [] PROPELLER [] WATER JET [] AIR THRUST [] MANUAL [] SAIL	PERSONAL FLOTATION DEVICES (PFDS): WAS BOAT ADEQUATELY EQUIPPED WITH COAST GUARD APPROVED PFDS? [] YES [] NO WERE PFDS ACCESSIBLE? [] YES [] NO
		FUEL [] GASOLINE [] DIESEL [] ELECTRIC	NUMBER OF ENGINES TOTAL HORSEPOWER		FIRE EXTINGUISHERS ON BOARD? [] YES [] NO USED? [] YES [] NO
OPERATION AT TIME OF ACCIDENT (CHECK ALL APPLICABLE) [] CRUISING [] CHANGING DIRECTION [] CHANGING SPEED [] DRIFTING [] TOWING [] BEING TOWED [] ROWING/PADDLING [] SAILING [] LAUNCHING [] DOCKING/UNDOCKING [] AT ANCHOR [] TIED TO DOCK/MOORED [] OTHER (SPECIFY)		ACTIVITY AT TIME OF ACCIDENT (CHECK ANY IF APPLICABLE) [] FISHING [] TOURNAMENT [] HUNTING [] SWIMMING/DIVING [] MAKING REPAIRS [] WATERSKIING/TUBING/ETC. [] RACING [] WHITEWATER SPORTS [] FUELING [] STARTING ENGINE [] NON-RECREATIONAL [] OTHER (SPECIFY)	TYPE OF ACCIDENT [] GROUNDING [] CAPSIZING [] FLOODING/SWAMPING [] SINKING [] FIRE OR EXPLOSION (FUEL) [] FIRE OR EXPLOSION (OTHER) [] SKIER MISHAP [] COLLISION WITH VESSEL [] COLLISION WITH FIXED OBJECT [] COLLISION WITH FLOATING OBJ. [] FALLS OVERBOARD [] FALLS IN BOAT [] STRUCK BY BOAT [] STRUCK BY MOTOR/PROPELLER [] STRUCK SUBMERGED OBJECT [] OTHER (SPECIFY)		WHAT CONTRIBUTED TO ACCIDENT? (CHECK ALL APPLICABLE) [] WEATHER [] EXCESSIVE SPEED [] IMPROPER LOOKOUT [] RESTRICTED VISION [] OVERLOADING [] IMPROPER LOADING [] HAZARDOUS WATERS [] ALCOHOL USE [] DRUG USE [] HULL FAILURE [] MACHINERY FAILURE [] EQUIPMENT FAILURE [] OPERATOR INEXPERIENCE [] OPERATOR INATTENTION [] CONGESTED WATERS [] PASSENGER/SKIER BEHAVIOR [] DAM/LOCK [] OTHER (SPECIFY)
ESTIMATED SPEED [] NONE [] UNDER 10 MPH [] 10 - 20 MPH [] 21 - 40 MPH [] OVER 40 MPH			[] HIT AND RUN		

Boating Accident Report

DECEASED (IF MORE THAN 2 FATALITIES, ATTACH ADDITIONAL FORMS)			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	[] MALE [] FEMALE	DEATH CAUSED BY	[] DROWNING [] OTHER [] DISAPPEARANCE
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	[] MALE [] FEMALE	DEATH CAUSED BY	[] DROWNING [] OTHER [] DISAPPEARANCE
INJURED (IF MORE THAN 2 INJURIES, ATTACH ADDITIONAL FORMS)			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	MEDICAL TREATMENT BEYOND FIRST AID? [] YES [] NO ADMITTED TO HOSPITAL? [] YES [] NO	DESCRIBE INJURY	
WAS PFD WORN? [] YES [] NO	PRIOR TO ACCIDENT? [] YES [] NO	AS A RESULT OF ACCIDENT? [] YES [] NO	
WAS IT INFLATABLE? [] YES [] NO			
NAME OF VICTIM		ADDRESS OF VICTIM	
DATE OF BIRTH	MEDICAL TREATMENT BEYOND FIRST AID? [] YES [] NO ADMITTED TO HOSPITAL? [] YES [] NO	DESCRIBE INJURY	
WAS PFD WORN? [] YES [] NO	PRIOR TO ACCIDENT? [] YES [] NO	AS A RESULT OF ACCIDENT? [] YES [] NO	
WAS IT INFLATABLE? [] YES [] NO			
OTHER PEOPLE ABOARD THIS BOAT (IF MORE THAN 2 PEOPLE, ATTACH ADDITIONAL FORMS)			
NAME		ADDRESS	
DATE OF BIRTH	WAS PFD WORN? [] YES [] NO AS A RESULT OF ACCIDENT [] YES [] NO	PRIOR TO ACCIDENT? [] YES [] NO	WAS IT INFLATABLE? [] YES [] NO
NAME		ADDRESS	
DATE OF BIRTH	WAS PFD WORN? [] YES [] NO AS A RESULT OF ACCIDENT [] YES [] NO	PRIOR TO ACCIDENT? [] YES [] NO	WAS IT INFLATABLE? [] YES [] NO
BOAT NO. 2 (IF MORE THAN 2 VESSELS, ATTACH ADDITIONAL IDENTIFYING INFORMATION)			
NAME OF OPERATOR		OPERATOR ADDRESS	
OPERATOR TELEPHONE NUMBER ()		BOAT REGISTRATION OR DOCUMENTATION NUMBER	STATE
NAME OF OWNER		OWNER ADDRESS	
OWNER TELEPHONE NUMBER ()			
PROPERTY DAMAGE			
ESTIMATED AMOUNT: THIS BOAT AND CONTENTS:	OTHER BOAT(S) AND CONTENTS:	OTHER PROPERTY:	
\$	\$	\$	
DESCRIBE PROPERTY DAMAGED			
WITNESSES NOT ON THIS VESSEL			
NAME	ADDRESS	TELEPHONE NUMBER ()	
NAME	ADDRESS	TELEPHONE NUMBER ()	
PERSON COMPLETING REPORT			
NAME	ADDRESS	TELEPHONE NUMBER ()	
SIGNATURE	QUALIFICATION [] OPERATOR [] OWNER [] INVESTIGATOR [] OTHER	DATE SUBMITTED	
FOR AGENCY USE ONLY			
CAUSES BASED ON (CHECK ONE): [] THIS REPORT [] INVESTIGATION [] INVESTIGATION AND THIS REPORT [] OTHER			
NAME OF REVIEWING OFFICE	DATE RECEIVED	RECREATIONAL []	NON-REPORTABLE []
PRIMARY CAUSE	COMMERCIAL [] SECONDARY CAUSE		

Call the Coast Guard Infoline 1-800-368-5647 for information on **Federal Requirements for Recreational Boats**

ACCIDENT DESCRIPTION

DESCRIBE WHAT HAPPENED (SEQUENCE OF EVENTS. INCLUDE FAILURE OF EQUIPMENT. INCLUDE A DIAGRAM IF NEEDED. CONTINUE ON ADDITIONAL SHEETS IF NECESSARY. INCLUDE ANY INFORMATION REGARDING THE INVOLVEMENT OF ALCOHOL AN/OR DRUGS IN CAUSING OR CONTRIBUTING TO THE ACCIDENT. INCLUDE ANY DESCRIPTIVE INFORMATION ABOUT THE USE OF PFD'S.)

An agency may not conduct or sponsor and a person is not required to respond to an information collection, unless it displays a currently valid OMB Control Number. The Coast Guard estimates that the average burden for this report form is 30 minutes. You may submit any comments concerning the accuracy of this burden estimate or any suggestions for reducing the burden to: Commandant (G-OPB-1), U.S. Coast Guard, Washington, DC 20593-0001 or Office of Management and Budget, Paperwork Reduction Project (2115-0010), Washington, DC 20503.

NOTES

FLOAT PLAN

Everglades recommends filling out a float plan each time you use your boat for an off-shore day trip or a long cruise. Leave this information with a responsible person ashore, like a close friend or relative that you know well.

1. Name of person reporting and telephone number.

2. Description of boat.

Type _____ Color _____ Trim _____

Registration No. _____ Length _____

Name _____ Make _____ Other Info _____

3. Engine type _____ H.P. _____

No. of Engines _____ Fuel Capacity _____

4. Survival equipment: (Check as appropriate)

PFDS Flares Mirror

Smoke Signals Flashlight Food

Paddles Water Others

Anchor Raft or Dinghy EPIRB

5. Radio Yes No Type _____

6. Automobile license _____

Type _____ Trailer License _____

Color _____ and make of auto _____

7. Persons aboard _____

Name _____ Age _____ Address & telephone No. _____

8. Do any of the persons aboard have a medical problem?

Yes No If yes, what? _____

9. Trip Expectations: Leave at _____

From _____ Going to _____

Expect to return by _____ (time)

and no later than _____

10. Any other pertinent info. _____

11. If not returned by _____ (time)
call the COAST GUARD or (Local authority) _____

12. Telephone Numbers.

NOTES

TROUBLESHOOTING GUIDE

PROBLEM	CAUSE AND SOLUTION
CONTROL SYSTEMS	
<p>Hydraulic Steering is slow to respond & erratic and/or the steering wheel feels bumpy.</p>	<ul style="list-style-type: none"> • Steering system is low on fluid. Fill and bleed system. • Steering system has air in it. Fill and bleed system. • A component in the steering system is binding. Check and adjust or repair binding component. • Engine steering spindle is binding. Grease spindle.
<p>The boat wanders and will not hold a course at cruise speeds.</p>	<ul style="list-style-type: none"> • There could be air in the steering system. Fill & bleed the system. • The engines are not aligned properly. Align engines. • Engine steering spindle is binding. Grease spindle.
<p>Steering is unusually hard.</p>	<ul style="list-style-type: none"> • The fuse for the power steering circuit has blown. Replace the fuse. • An internal fuse in the power steering pump system has blown. Refer to the steering owners manual for fuse location and replace the fuse or contact your dealer for assistance. • A steering line is kinked or collapsed. Replace kinked or collapsed line.
<p>An engine will not start with the shift control lever in neutral.</p>	<ul style="list-style-type: none"> • The shift control lever is not in the neutral detent. Try moving the shift lever slightly. • There is a loose wire on the neutral safety switch in the control. Inspect wires and repair loose connections. • The starter or ignition switch is bad. • There is a problem with the electronic control system at the helm control, module or at the engine. Have the system serviced by a qualified marine technician.
PERFORMANCE PROBLEMS	
<p>Boat is sluggish and has lost speed & RPM.</p>	<ul style="list-style-type: none"> • The boat may be need to have marine growth cleaned from hull and running gear. • Propellers may be damaged & need repair. • Weeds or line around the propellers. Clean propellers. • Boat is overloaded. Reduce load. • Check for excessive water in the bilge. Pump out bilge & find & correct the problem. • One of the throttles is not responding properly and the engine is not getting full throttle. Have the throttle control system checked by a qualified marine technician.
<p>The boat vibrates at cruising speeds.</p>	<ul style="list-style-type: none"> • Propellers may be damaged & need repair. • A propeller or propeller shaft is bent. Repair or replace damaged components. • The running gear is fouled by marine growth or rope. Clean running gear. • The engines are not trimmed properly. Trim engines.

PROBLEM	CAUSE AND SOLUTION
ENGINE PROBLEMS	
<p>An engine is running too hot.</p>	<ul style="list-style-type: none"> • The engine raw water pick up strainer is clogged with marine growth. Clean pick up. • The engine raw water pump impeller is worn or damaged. Repair the pump. • The engine thermostat is faulty and needs to be replaced.
<p>An engine alternator is not charging properly.</p>	<ul style="list-style-type: none"> • The battery cable is loose or corroded. Clean and tighten battery cables. • The alternator is not charging and must be replaced. • The battery is defective. Replace the battery. • A Voltage Sensitive Relay in the charging system is not working properly. Replace defective VSR.
<p>An engine suddenly will not operate over 2000 RPM.</p>	<ul style="list-style-type: none"> • The engine emergency system has been activated. The on board computer has sensed a problem and has limited the RPM to protect the engine. Find & correct the problem. • The tachometer is bad and needs to be replaced. • A throttle control is not responding properly. Have the throttle setting checked by a qualified technician.
<p>An engine is losing RPM. The boat is not overloaded and the hull bottom and running gear are clean and in good condition.</p>	<ul style="list-style-type: none"> • The engine may be having a problem with a sticky anti-siphon valve, located in the fuel line near the fuel tank, that is restricting the fuel flow. Remove & clean or replace the anti-siphon valve. • The remote gasoline fuel filter could be dirty. Inspect and replace the fuel filter. • The primary fuel filter on the engine may be dirty. Inspect and replace the fuel filter. • The electronic engine control system on the engine is malfunctioning. Repair the engine control system. • The fuel injection system on the engine is malfunctioning. Repair the fuel injection system.


PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
The fresh water pump runs, but will not pump water.	<ul style="list-style-type: none"> • The water tank is empty. Fill the tank. • The intake hose is damaged and sucking air. Replace or repair the hose. • The pump is defective. Repair or replace the pump.
The fresh water pump fails to turn off after all outlets are closed.	<ul style="list-style-type: none"> • There is a leak in a pressure line or outlet. Repair the leak. • There is an air leak in the intake line. Repair the air leak. • The pressure switch is defective. Replace the pressure switch. • The voltage to the pump is low. Check for corroded or loose wiring connections or low battery. • The strainer is clogged. Clean strainer. • The pump is defective. Repair or replace the pump.
The washdown pump runs, but the pump will not pump water.	<ul style="list-style-type: none"> • The thru-hull valve is not open. Open valve. • There is an air leak in the intake line. Repair the air leak. • The intake scoop strainer for the raw water system is clogged with weeds or debris. Back down the boat to clear debris or clean the scoop strainer. • The in-line sea strainer for the pump is clogged. Clean the sea strainer.
The washdown or fresh water pump fails to turn off after all outlets are closed.	<ul style="list-style-type: none"> • The intake hose is damaged and sucking air. Replace hose. • The pump is defective. Repair or replace the pump. • There is a leak in a pressure line or outlet. Repair the leak. • There is an air leak in the intake line. Repair the air leak. • The pressure switch is defective. Replace the pressure switch. • The voltage to the pump is low. Check for corroded or loose wiring connections or low battery.
Reduction in water flow from the bilge pump.	<ul style="list-style-type: none"> • The strainer is clogged. Clean strainer. • The pump is defective. Repair or replace the pump. • Impeller screen plugged with debris. Clean screen at the base of the pump. • The discharge hose is pinched or clogged. Check discharge hose and clean or repair. • Low voltage to the pump. Check the battery and wire connections.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
<p>The automatic switch on the bilge pump does not activate the pump .</p>	<ul style="list-style-type: none"> • The fuse or circuit breaker for the automatic switch has tripped or blown. Replace the fuse or reset the circuit breaker. • The battery is dead. Charge or replace the battery. • The pump impeller is jammed by debris. Clean pump impeller housing. • The wire connections in the bilge have corroded. Replace connectors and secure above the bilge waterline. • The automatic switch is defective. Replace the switch. • The pump is defective. Replace pump.
<p>The bilge pump will not run when the manual switch is activated.</p>	<ul style="list-style-type: none"> • The circuit breaker supplying the switch has tripped. Reset the circuit breaker. Replace if defective. • The battery switch is off. Turn on the battery switch. • The pump impeller is jammed by debris. Clean pump impeller housing. • The wire connections in the bilge have corroded. Replace connectors and secure above the bilge waterline. • The switch is defective. Replace the switch. • The pump is defective. Replace pump.
<p>Head will not flush.</p>	<ul style="list-style-type: none"> • The fuse for the head circuit is blown. Replace the fuse. • The holding tank is full. Pump out the holding tank. • There is bad connection at the head pump or the switch. Repair the connection. • The head pump is defective. Replace the pump.
<p>Excessive odor from marine head.</p>	<ul style="list-style-type: none"> • Back pressure in the holding tank. Pump out holding tank and clean the vent and vent hose. • No deodorizer in the holding tank. Add deodorizer to the holding tank each time it is pumped out. • The waste in the tank is over two weeks old. Pump the holding tank if it has contained waste for two weeks or more.
<p>Holding tank will not empty.</p>	<ul style="list-style-type: none"> • Holding tank vent is clogged. Clean the vent and vent hose. • There is a vacuum leak in the hose from the holding tank to the deck pump out fitting. Tighten loose fittings or replace damaged hoses.
<p>The air conditioner runs for a short time & then cuts out.</p>	<ul style="list-style-type: none"> • The intake scoop strainer for the raw water system is clogged with weeds or debris. Back down the boat to clear debris or clean the scoop strainer. • The air conditioner pump sea strainer is clogged. Clean the strainer. • The raw water supply thru hull valve is closed. Open the valve. • The raw water system is air-bound. Make sure the thru hull valve is open and run the boat above 15 m.p.h. The speed scoop on the thru hull fitting will force the air lock out of the system. • The air conditioner raw water pump is not pumping and needs to be repaired or replaced.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
The refrigerator compressor runs frequently and the house battery life seems shorter than it should be whenever the refrigerator is operating on DC power.	<ul style="list-style-type: none"> • The thermostat in the refrigerator is set too cold. Check the temperature in the refrigerator and set the thermostat to a warmer setting if necessary. • The door gasket is dirty or moldy and not sealing properly. Clean or replace the door seal. • The house batteries are weak and not providing the proper voltage to the refrigerator compressor. Replace the batteries. • The refrigerator is defective. Replace the refrigerator.
The carbon monoxide detector sounds the alarm when the engines or generator are running.	<ul style="list-style-type: none"> • The canvas curtains are up and none of the forward facing vents are open, allowing carbon monoxide to accumulate in the cockpit and cabin. Open the deck hatch, clear connector and side curtains to provide proper ventilation. • The boat is operating at slow speed and the wind is on the stern pushing CO into the cockpit and cabin. Increase boat speed or change heading if possible. • The carbon monoxide detector is defective and needs to be calibrated by the manufacturer or replaced. Have the boat checked by a professional before condemning the CO monitor.
No AC power to cabin breaker panel and shore cords are properly connected.	<ul style="list-style-type: none"> • The breakers at the shore outlet are off. Activate breakers.. • The shore power cord is damaged or defective. Replace the cord. • The ELCI at the inlet connection has detected a fault in the electrical system and the breaker has tripped. Contact a qualified marine electrician to find and correct the problem.
The Main Breaker for AC Power trips when activating the system from shore power.	<ul style="list-style-type: none"> • The AC accessory breakers are on and the power surge is tripping the breaker. Turn off all AC accessory breakers and reactivate main breaker. • The main breaker is defective. Contact a qualified marine electrician to replace the breaker.
The AC main breaker activates the panel but trips while using accessories.	<ul style="list-style-type: none"> • There are too many AC accessories activated causing excess amperage draw. Manage AC accessory use to reduce excess amperage draw. • Voltage supplied from the shore outlet is low or high. Check the voltage. Contact the marina operator or qualified marine electrician to correct the problem. • The main breaker is defective. Contact a qualified marine electrician to replace the breaker.
No AC power at cabin outlets	<ul style="list-style-type: none"> • Outlet breaker in cabin AC panel is off. Activate breaker. • Ground fault interrupter has tripped. Push reset button on outlet to reset. • Accessory powered by the outlet has a fault that is tripping the interrupter. Turn the breaker in the cabin AC panel off and contact a qualified marine electrician to repair the defective accessory. Replace defective accessory. • The GFI outlet is defective. Contact a qualified marine electrician to replace the outlet.

PROBLEM	CAUSE AND SOLUTION
ACCESSORY PROBLEMS	
The optional generator will not start.	<ul style="list-style-type: none">• House batteries are not charged. Charge or replace battery.• The generator fuel supply valve is off. Turn on fuel supply valve.• The fuel level is too low in the fuel tank. Fill the fuel tank.
The generator runs for a short time and shuts down.	<ul style="list-style-type: none">• There is a problem with the generator and the emergency shut down system has activated to shut down the generator. Find and correct the problem, then restart the generator.• The fuel level is too low in the fuel tank that supplies the generator. Fill the fuel tank.• The generator is overloaded. Manage AC accessory use to reduce excess amperage draw.

Everglades



All Channels Lead to Everglades Boats

Everglades Boats
544 Air Park Road
Edgewater, Florida 32132